
README.TXT

Adaptec Storage Manager (ASM)
as of December 5, 2008

Please review this file for important information about issues and erratas that were discovered after completion of the standard product documentation. In the case of conflict between various parts of the documentation set, this file contains the most current information.

Note: Adaptec Storage Manager version 6.10.18350 has been replaced with version 6.10.18359.

The following information is available in this file:

1. Software Versions and Documentation
 - 1.1 Adaptec Storage Manager
 - 1.2 Documentation
2. Installation and Setup Notes
 - 2.1 Supported Operating Systems
 - 2.2 Minimum System Requirements
 - 2.3 General Setup Notes
 - 2.4 Linux Setup Notes
 - 2.5 VMware Setup Notes
3. General Cautions and Notes
 - 3.1 General Cautions
 - 3.2 General Notes
4. Operating System-Specific Issues and Notes
 - 4.1 Windows - All
 - 4.2 Windows 64-Bit
 - 4.3 Windows Vista Business and Ultimate
 - 4.4 Linux
 - 4.5 FreeBSD
 - 4.6 Linux and FreeBSD
 - 4.7 VMware
5. RAID Level-Specific Notes
 - 5.1 RAID 1 and RAID 5 Notes
 - 5.2 RAID 10 Notes
 - 5.3 RAID x0 Notes
6. Power Management Issues and Notes
7. ARCCONF Notes
8. Other Issues and Notes

1. Software Versions and Documentation

- 1.1. Adaptec Storage Manager Version 6.1
- 1.2. Documentation on this CD

PDF format*:

- Adaptec Storage Manager User's Guide for Direct Attached Storage
- Adaptec Storage Manager User's Guide for iSCSI Storage
- Adaptec RAID Controller Command Line Utility User's Guide

*Requires Adobe Acrobat Reader 4.0 or later

HTML and text format:

- Adaptec Storage Manager Online Help
- Page 1

readme.txt

- Adaptec Storage Manager README.TXT file
- Adaptec Ontarget README_ONTARGET.TXT file

2. Installation and Setup Notes

- The Adaptec RAID Controllers Installation and User's Guide contains complete installation information for direct attached RAID controllers and drivers. The Adaptec Storage Manager User's Guide contains complete instructions for all utilities and Adaptec Storage Manager software for direct attached and iSCSI storage.

2.1 Supported Operating Systems

- Microsoft Windows 32-Bit:
 - o Windows Vista - All versions
 - o Windows Server 2008
 - o Windows Server 2003 Enterprise, Standard, and Web Edition*
 - o Windows XP Professional*
- Microsoft Windows 64-Bit:
 - o Windows Vista Ultimate and Business
 - o Windows Server 2008
 - o Windows Server 2003 Enterprise, Standard, and Web Edition*
 - o Windows XP Professional*
- Linux 32-Bit:
 - o Red Hat Enterprise Linux 4.6*
 - o Red Hat Enterprise Linux 5.2*
 - o SuSE Linux Enterprise Server 9
 - o SuSE Linux Enterprise Server 10
 - o VMware ESX Server 3.0.2, 3.5
- Linux 64-Bit:
 - o Red Hat Enterprise Linux 4.6*
 - o Red Hat Enterprise Linux 5.2*
 - o SuSE Linux Enterprise Server 9*
 - o SuSE Linux Enterprise Server 10*
- UnixWare:
 - o SCO UnixWare 7.1.4
- OpenServer:
 - o SCO OpenServer 6.0
- Solaris:
 - o Sun Solaris 10 Update 4
- FreeBSD:
 - o FreeBSD 6.3, 7.0

readme.txt

NOTE: The ASM installer for FreeBSD is available as a web release only. You can download ASM for FreeBSD from the Adaptec web site at www.adaptec.com.

*Out-of-box and current quarterly update or service pack

2.2 Minimum System Requirements

- o Intel Pentium Compatible 1.2 GHz processor
- o 512 MB RAM
- o 135 MB hard disk drive space
- o Greater than 256 color video mode

2.3 General Setup Notes

- You can configure Adaptec Storage Manager settings on other servers exactly as they are configured on one server. To replicate the Adaptec Storage Manager Enterprise view tree and notification list, do the following:

1. Install Adaptec Storage Manager on one server.
2. Start Adaptec Storage Manager. Using the 'Add remote system' action, define the servers for your tree.
3. Open the Notification Manager. Using the 'Add system' action, define the notification list.
4. Exit Adaptec Storage Manager.
5. Copy the following files onto a diskette from the directory where the Adaptec Storage Manager is installed:

RaidMSys.ser --> to replicate the tree
RaidNLst.ser --> to replicate the notification list
RaidSMTP.ser --> to replicate the SMTP e-mail notification list
RaidJob.ser --> to replicate the jobs in the Task Scheduler

6. Install Adaptec Storage Manager on the other servers.
7. Copy the files from the diskette into the directory where Adaptec Storage Manager is installed on the other servers.

2.4 Linux Setup Notes

- To run Adaptec Storage Manager under Red Hat Enterprise Linux for x64, the Standard installation with "Compatibility Arch Support" is required.

- To install Adaptec Storage Manager on Red Hat Enterprise Linux, you must install two packages from the Red Hat installation CD:

- o compat-libstdc++-7.3-2.96.122.i386.rpm
- o compat-libstdc++-devel-7.3-2.96.122.i386.rpm

NOTE: The version string in the file name may be different than above. Be sure to check the version string on the Red Hat CD.

For example, type:

```
rpm --install /mnt/compat-libstdc++-7.3-2.96.122.i386.rpm
```

readme.txt

where mnt is the mount point of the CD-ROM drive.

- To install Adaptec Storage Manager on Red Hat Enterprise Linux 4, you must install the following package from the Red Hat installation CD:

- o xorg-x11-deprecated-libs-6.8.1-23.i386.rpm

NOTE: The version string in the file name may be different than above. Be sure to check the version string on the Red Hat CD.

- To install Adaptec Storage Manager on Red Hat Enterprise Linux 5, you must install one of these packages from the Red Hat installation CD:

- o libXp-1.0.0-8.i386.rpm (32-Bit)
 - o libXp-1.0.0-8.x86.rpm (64-Bit)

- To install Adaptec Storage Manager on Novell Linux Desktop 9 Service Pack 1 for 64-bit systems, you must install two packages from the Novell Linux installation CD:

- liblcms-devel-1.12-55.2.x86_64.rpm
 - compat-32bit-9-200502081830.x86_64.rpm

NOTE: The version string in the file name may be different than above. Be sure to check the version string on the Novell Linux CD.

2.5 VMware Setup Notes

- To install and use Adaptec Storage Manager on the VMware ESX Server:

1. Mount the Adaptec Storage Manager installation CD:

```
mount -r /dev/cdrom /mnt/linux/
```

2. Change to the manager directory on the CD-ROM:

```
cd /mnt/cdrom/linux/manager
```

3. Type the following command to install the 32-bit Linux Adaptec Storage Manager on the VMware ESX Server:

```
rpm --install ./StorMan*.rpm
```

4. Type the following command to open the range of ports required by Adaptec Storage Manager to connect remotely:

```
esxcfg-firewall -o 34571:34581,tcp,in,"StorMan"
```

5. Install Adaptec Storage Manager on a Windows or Linux machine.

6. From the Windows or Linux client, connect to the Adaptec Storage Manager Agent on the VMware ESX Server using the ASM GUI.

- The Adaptec Storage Manager Agent on the VMware ESX Server cannot be monitored from a guest operating system.

3. Adaptec Storage Manager General Cautions and Notes

3.1 General Cautions

- This release supports a maximum of 8 concurrent online capacity expansion (OCE) tasks in the RAID array migration wizard.
- While building or clearing a logical drive, do not remove and re-insert any drive from that logical drive. Doing so may cause unpredictable results.
- Do not move disks comprising a logical drive from one controller to another while the power is on. Doing so could cause the loss of the logical drive configuration or data, or both. Instead, power off both affected controllers, move the drives, and then restart.
- When using Adaptec Storage Manager and the CLI concurrently, configuration changes may not appear in the Adaptec Storage Manager GUI until you refresh the display (by pressing F5).

3.2 General Notes

- Adaptec Storage Manager requires the following range of ports to be open for remote access: 34570-34580 (TCP), 34570 (UDP), 34577-34580 (UDP).
- Adaptec Storage Manager generates log files automatically to assist in tracking system activity. The log files are created in the directory where Adaptec Storage Manager is installed.
 - o RaidEvt.log - Contains the information reported in Adaptec Storage Manager event viewer for all local and remote systems.
 - o RaidEvtA.log - Contains the information reported in Adaptec Storage Manager event viewer for the local system.
 - o RaidNot.log - Contains the information reported in the Notification Manager event viewer.
 - o RaidErr.log - Contains Java messages generated by Adaptec Storage Manager.
 - o RaidErrA.log - Contains Java messages generated by the Adaptec Storage Manager agent.

Information written to these files is appended to the existing files to maintain a history. However, when an error log file reaches a size of 5 Mbytes, it is copied to a new file with the extension .1 and the original (that is, the .LOG file) is deleted and recreated. For other log files, a .1 file is created when the .LOG file reaches a size of 1 Mbyte. If a .1 file already exists, the existing .1 file is destroyed.

- In the Event viewer, Adaptec Storage Manager reports both the initial build task for a logical drive and a subsequent Verify/Fix as a "Build/Verify" task.
- When displaying information about a physical device, the device, vendor and model information may be displayed incorrectly.
- After using a hot spare to successfully rebuild a redundant

readme.txt

logical drive, Adaptec Storage Manager will continue to show the drive as a global hot spare. To remove the hot spare designation, delete it in Adaptec Storage Manager.

4. Operating System-Specific Issues and Notes

4.1 Windows - All

- The Java Virtual Machine has a problem with the 256-color palette. (The Adaptec Storage Manager display may be distorted or hard to read.) Set the Display Properties Settings to a color mode with greater than 256 colors.
- When you shut down windows, you might see the message "unexpected shutdown". Windows displays this message if the Adaptec Storage Manager Agent fails to exit within 3 seconds. It has no affect on file I/O or other system operations and can be ignored.

4.2 Windows 64-Bit

- RAID controllers do not produce an audible alarm on the following 64-bit windows operating systems:
 - o Windows XP Professional x64 Edition
 - o Windows Server 2003 x64 Edition (all versions)

4.3 Windows Vista Business and Ultimate (64-bit versions)

- Flashing a RAID controller on windows Vista 64-bit systems is not supported in this release of Adaptec Storage Manager.

NOTE: Although you can run the image update wizard from Adaptec Storage Manager on a windows Vista 64-bit system, the wizard does not run to completion.

4.4 Linux

- When you delete a logical drive, the operating system can no longer see the last logical drive. WORKAROUND: To allow Linux to see the last logical drive, restart your system.
- The controller does not support attached CD drives during OS installation.
- On certain versions of Linux, you may see messages concerning font conversion errors. Font configuration under X-windows is a known JVM problem. It does not affect the proper operation of the Adaptec Storage Manager software. To suppress these messages, add the following line to your .xdefaults file:

```
stringConversionWarnings: False
```

4.5 FreeBSD

- On FreeBSD systems, JBOD disks created with Adaptec Storage Manager are not immediately available to the OS. You must reboot the system before you can use the JBOD.

4.6 Linux and FreeBSD

- If you cannot connect to a local or remote Adaptec Storage Manager

readme.txt

installed on a Linux or FreeBSD system, verify that the TCP/IP hosts file is configured properly.

1. Open the /etc/hosts file.

NOTE: The following is an example:

```
127.0.0.1 localhost.localdomain localhost matrix
```

2. If the hostname of the system is identified on the line with 127.0.0.1, you must create a new host line.
3. Remove the hostname from the 127.0.0.1 line.

NOTE: The following is an example:

```
127.0.0.1 localhost.localdomain localhost
```

4. On a new line, type the IP address of the system.
5. Using the Tab key, tab to the second column and enter the fully qualified hostname.
6. Using the Tab key, tab to the third column and enter the nickname for the system.

NOTE: The following is an example of a completed line:

```
1.1.1.1 matrix.localdomain matrix
```

where 1.1.1.1 is the IP address of the server and matrix is the hostname of the server.

7. Restart the server for the changes to take effect.

4.7 VMware

- After making array configuration changes in VMware, you must run the "esxcfg-rescan" tool manually at the VMware console to notify the operating system of the new target characteristics and/or availability. Alternatively, you can rescan from the Virtual Infrastructure Client: click on the host in the left panel, select the Configuration tab, choose "Storage Adapters", then, on the right side of the screen, click "Rescan".

5. RAID Level-Specific Notes

5.1 RAID 1 and RAID 5 Notes

- During a logical device migration from RAID 1 or RAID 5 to RAID 0, if the original logical drive had a spare drive attached, the resulting RAID 0 retains the spare drive. Since RAID 0 is not redundant, you can remove the hot spare.

5.2 RAID 10 Notes

- You cannot change the priority of a RAID-10 verify. Setting the priority at the start of a verify has no effect. The priority is still shown as high. Changing the priority of a running verify on a RAID-10 changes the displayed priority until a rescan is done, then the priority shows as high again.

readme.txt

- Performing a Verify or Verify/Fix on an RAID 10 displays the same message text in the event log: "Build/Verify started on second level logical drive of 'LogicalDrive_0.'" You may see the message three times for a Verify, but only once for a Verify/Fix.
- During a migration from a RAID 0 to any redundant logical drive, like RAID 5 or 10, Adaptec Storage Manager shows the status as "Degraded Reconfiguring" for a moment, then the status changes to "Reconfiguring." The "Degraded" status does not appear in the event log.

5.3 RAID x0 Notes

- After building or verifying a leg of a second-level logical drive, the status of the second-level logical drive is displayed as a "Quick Initialized" drive.

6. Power Management Issues and Notes

- You must use a compatible combination of Adaptec Storage Manager and controller firmware and driver software to use the power management feature. All software components must support power management. You can download the latest controller firmware and drivers from the Adaptec Web site at www.adaptec.com.
- Power management is not supported under FreeBSD.

7. ARCCONF Notes

- ARCCONF requires the latest drivers to operate properly. Failure to update the drivers may result in the console hanging after a command is issued.
- With Linux kernel versions 2.4 and 2.6, the ARCCONF DELETE <logical_drive> command may fail with a Kernel Oops error message. Even though the drives are removed from the Adaptec Storage Manager GUI, they may not really be deleted. Reboot the controller; then, issue the ARCCONF DELETE command again.

8. Other Issues and Notes

- If you remove a disk drive from an enclosure and that drive is not part of any logical device, ASM will not auto-detect the disk when the same drive is re-inserted into the same slot in the enclosure. To correct the problem, manually rescan the controller in ASM: right click the controller in the Enterprise view, then select 'Rescan'.

Note that ASM will auto-detect the drive if:

- o The same drive is re-inserted into a different slot
 - o A different drive is inserted into the same slot
- Adaptec Storage Manager may fail to exit properly when you create 64 logical devices in the wizard. The exiting problem does not prevent the logical devices from being created.
 - When clearing a disk drive, do not try to include it in a new logical device while the clear process is in progress.

readme.txt

Doing so may have unpredictable results.

(c) 2008 Adaptec, Inc. All Rights Reserved. This software contains valuable trade secrets of Adaptec or its licensors. The software is protected under international copyright laws and treaties. This software may only be used in accordance with the terms of its accompanying license agreement. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without prior written consent of Adaptec, Inc., 691 South Milpitas Blvd., Milpitas, CA 95035.