

User's Guide
Microsemi Adaptec RAID Controller Command Line
Utility

Released
October 2017



Revision History

Issue	Issue Date	Details of Change
3	October 2017	Add Linux/Unix LogFiles for PLAYCONFIG and SAVECONFIG commands; add notes to RESCAN and SAVESUPPORTARCHIVE command sections; add SETCONTROLLERPARAM command; update GETSMARTSTATS command.
2	September 2016	Add UARTLOG CONSOLE command; add PPC Linux and pre-boot plugin installation; add static-linked arcconf installation for Linux x64.
1	April 2016	Add new commands; TASK uninit ALL; new GETCONFIG component properties; Logical Drive, HDD, and Backup System Status and Error Conditions.

Contents

Microsemi Adaptec® Product Support.....	6
Software License Agreement.....	7
1 Getting Started with the Command Line Utility.....	10
1.1 Installing the Command Line Utility.....	10
1.1.1 Downloading the Installation Packages.....	10
1.1.2 Installing on Windows.....	11
1.1.3 Installing on Red Hat, Cent OS, SuSE, or Fedora Linux.....	11
1.1.4 Installing on Debian or Ubuntu Linux.....	11
1.1.5 Installing on Solaris.....	11
1.1.6 Installing on FreeBSD.....	12
1.1.7 Installing on VMware.....	12
1.1.8 Installing on Citrix XenServer.....	13
1.1.9 Installing on a Guest Operating System.....	13
1.1.9.1 Installing on a Windows Guest OS.....	13
1.1.9.2 Installing on a Linux Guest OS.....	13
1.1.10 Installing on PowerPC.....	14
1.2 Starting the Command Line Utility.....	14
2 Using the Command Line Utility.....	15
2.1 ARCCONF Commands.....	15
2.2 arccconf atapassword.....	17
2.3 arccconf backupunit.....	17
2.4 arccconf consistencycheck.....	18
2.5 arccconf copyback.....	18
2.6 arccconf cpld.....	19
2.7 arccconf create.....	20
2.8 arccconf delete.....	22
2.9 arccconf driverupdate.....	23
2.10 arccconf errorunable	23
2.11 arccconf expanderlist.....	24
2.12 arccconf expanderupgrade.....	24
2.13 arccconf failover.....	25
2.14 arccconf getconfig.....	26
2.15 arccconf getexception.....	27
2.16 arccconf getlogs.....	28
2.17 arccconf getperform.....	29
2.18 arccconf getsmartstats.....	30
2.19 arccconf getstatus.....	30
2.20 arccconf getversion.....	31
2.21 arccconf identify.....	31
2.22 arccconf imageupdate.....	32
2.23 arccconf key.....	33
2.24 arccconf list.....	33
2.25 arccconf modify.....	34
2.26 arccconf phyerrorlog.....	35
2.27 arccconf playconfig.....	36
2.28 arccconf preservcache.....	37

2.29	arccnf rescn.....	38
2.30	arccnf resetstatisticscounters.....	38
2.31	arccnf romupdate.....	39
2.32	arccnf saveconfig.....	40
2.33	arccnf savesupportarchive.....	40
2.34	arccnf seeprom.....	41
2.35	arccnf setalarm.....	42
2.36	arccnf setbiosparams.....	42
2.37	arccnf setboot.....	43
2.38	arccnf setcache.....	44
2.39	arccnf setconfig.....	45
2.40	arccnf setcontrollermode.....	46
2.41	arccnf setcontrollerparam.....	47
2.42	arccnf setcustommode.....	48
2.43	arccnf setmaxcache.....	49
2.44	arccnf setname.....	50
2.45	arccnf setncq.....	51
2.46	arccnf setperform.....	51
2.47	arccnf setphy.....	52
2.48	arccnf setpower.....	52
2.49	arccnf setpriority.....	54
2.50	arccnf setstate.....	54
2.51	arccnf setstatsdatacollection.....	56
2.52	arccnf setvmcredential.....	56
2.53	arccnf smp.....	57
2.54	arccnf task.....	57
2.55	arccnf uninit.....	59
2.56	arccnf verifywrite	59

Appendix A	getconfig Output Summary.....	61
------------	-------------------------------	----

Appendix B	Logical Drive, HDD, and Flash Backup System Status and Error Conditions.....	70
------------	--	----

Tables

Table 1 • ARCCONF Batch Environments15

Table 2 • ARCCONF Commands15

Table 3 • getconfig output summary61

Microsemi Adaptec® Product Support

If you have questions about installing or using your Microsemi Adaptec® product, check this document first—you will find answers to most of your questions. If you need further assistance, use the support options listed below. To expedite your service, have your computer in front of you.

Note: Please visit our Support site at start.microsemi.com for the most up to date contact information.

Self Help and Support in English

- Search the Microsemi Support Knowledgebase (ASK) at ask.microsemi.com for articles, troubleshooting tips, and frequently asked questions for your product.
- For support through email, submit your question at ask.microsemi.com.
- To contact Technical Support, visit our product support site at start.microsemi.com.

Technische Informationen und Support in Deutsch

- Suchen Sie in der Adaptec Support Knowledgebase (ASK) unter ask-de.microsemi.com nach Artikeln, Tipps zur Fehlerbehebung und häufig gestellten Fragen zu Ihrem Produkt.
- Support per Email erhalten Sie unter ask-de.microsemi.com.
- Um den Technischen Support zu kontaktieren, besuchen Sie uns bitte unter start.microsemi.com und klicken Sie auf „Support kontaktieren“, für Auswahlmöglichkeiten.

Техническая поддержка и информация на русском языке

- База знаний Microsemi (ASK) на сайте ask-ru.microsemi.com ask-ru.adaptec.com – статьи, советы по устранению неисправностей и часто задаваемые вопросы о Вашем продукте.
- Для поддержки по электронной почте отправьте Ваш запрос на сайте ask-ru.microsemi.com
- Для обращения в службу Технической Поддержки, пожалуйста, посетите наш web сайт start.microsemi.com и используйте ссылку "Contact Support".

日本語での技術情報とサポート

- ask.microsemi.co.jp のMicrosemi Support Knowledgebase (ASK)で、お使いの製品の情報 トラブルシューティングのヒント、よくある質問を検索してください。
- Eメールでのサポートには ask.microsemi.co.jp から質問を送ってください。
- テクニカルサポートへコンタクトするには、弊社ウェブサイトstart.microsemi.comをご覧ください、"Contact Support"をクリックして下さい。

Software License Agreement

PLEASE READ CAREFULLY: THE USE OF THIS SOFTWARE IS SUBJECT TO THE SOFTWARE LICENSE TERMS OF MICROSEMI CORPORATION, AND OTHER LICENSORS WHOSE SOFTWARE MAY BE BUNDLED WITH THIS PRODUCT.

BY YOUR USE OF THE SOFTWARE INCLUDED WITH THIS PRODUCT YOU AGREE TO THE LICENSE TERMS REQUIRED BY THE LICENSOR OF THAT SOFTWARE, AS SET FORTH DURING THE INSTALLATION PROCESS. IF YOU DO NOT AGREE TO THE LICENSE TERMS APPLICABLE TO THE SOFTWARE, YOU MAY RETURN THE ENTIRE UNUSED PRODUCT FOR A FULL REFUND.

In return for acquiring a license to use the Microsemi software, which may include software from third party licensors and patches made available by Microsemi ("Software"), and the related documentation, you agree to the following terms and conditions:

1. License. This Agreement grants you, the Licensee, a license to:
 - a. Use the Software on a single computer system, which is not intended for use by more than five (5) users; and:
 - b. Make one copy of the Software in machine readable form solely for back-up purposes, provided you reproduce Microsemi's copyright proprietary legends. Notwithstanding the foregoing, the Software may be used on the home, laptop or other secondary computer of the principal user of the Software, and an additional copy of the Software may be made to support such use. As used in this license, the Software is "in use" when it is either loaded into RAM or installed on a hard disk or other permanent memory device. The Software may be "in use" on only one computer at any given time. (Different license terms and fees are applicable for networked or multiple user applications.) As a specific condition of this license, you agree to use the Software in compliance with all applicable laws, including copyright laws, and that you will not copy, transmit, perform or distribute any audio or other content using the Software without obtaining all necessary licenses or permissions from the owner of the content.
2. Restrictions. You may not distribute copies of the Software to others or electronically transfer the Software from one computer to another over a network. You may not post or otherwise make available the Software, or any portion thereof, in any form, on the Internet. You may not use the Software in a computer service business, including in time sharing applications. The Software contains trade secrets and, in order to protect them, you may not decompile, reverse engineer, disassemble, or otherwise reduce the Software to a human-perceivable form. YOU MAY NOT MODIFY, ADAPT, TRANSLATE, RENT, LEASE, LOAN, RESELL FOR PROFIT, DISTRIBUTE, NETWORK OR CREATE DERIVATIVE WORKS BASED UPON THE SOFTWARE OR ANY PART THEREOF.
3. Ownership of Software. As Licensee, you own the media upon which the software is recorded or fixed, but Microsemi and its licensors retain title and ownership of the Software recorded on the original media and all subsequent copies of the Software, regardless of the form or media in which or on which the original and other copies may exist. This license is not a sale of the Software or any copy.
4. Confidentiality. You agree to maintain the Software in confidence and that you will not disclose the Software to any third party without the express written consent of Microsemi. You further agree to take all reasonable precautions to preclude access of unauthorized persons to the Software.
5. Term. This license is effective until January 1, 2045, unless terminated earlier. You may terminate the license at any time by destroying the Software (including the related documentation) together with all copies or modifications in any form. Microsemi will have the right to terminate our license immediately if you fail to comply with any term or condition of this Agreement. Upon any termination, including termination by you, you must destroy the Software (including the related documentation), together with all copies or modifications in any form.

6. **Special Terms Applicable to Databases.** Where a database is included with the Software, you acknowledge that it is licensed only in connection with the use of the Software to perform disc creation, and that the database and all data derived therefrom must be maintained in confidence in accordance with the provisions of Section 4. This license does not grant you any rights to distribute or disclose such database or data.
7. **Limited Warranty.** Microsemi and its Licensor warrant only that the media upon which the Software is furnished will be free from defects in material or workmanship under normal use and service for a period of thirty (30) days from the date of delivery to you. MICROSEMI AND ITS LICENSORS DO NOT AND CANNOT WARRANT THE PERFORMANCE OR RESULTS YOU MAY OBTAIN BY USING THE SOFTWARE OR DOCUMENTATION. THE FOREGOING STATES THE SOLE AND EXCLUSIVE REMEDIES MICROSEMI AND ITS LICENSORS WILL PROVIDE FOR BREACH OF WARRANTY. EXCEPT FOR THE FOREGOING LIMITED WARRANTY, MICROSEMI AND ITS LICENSORS MAKE NO WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED, AS TO NON-INFRINGEMENT OF THIRD PARTY RIGHTS, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow the exclusion of implied warranties or limitations on how long an implied warranty may last, so the above limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.
8. **The entire liability of Microsemi and its licensors, and your exclusive remedy for a breach of this warranty, shall be:**
 - a. The replacement of any media not meeting the above limited warranty which is returned to Microsemi; or
 - b. if Microsemi or its distributor is unable to deliver replacement media which is free from defects in materials or workmanship, you may terminate this Agreement by returning the Software and your money will be refunded.
9. **Limitation of Liability.** IN NO EVENT WILL MICROSEMI OR ITS LICENSORS BE LIABLE TO YOU FOR ANY INCIDENTAL, CONSEQUENTIAL OR INDIRECT DAMAGES, INCLUDING ANY LOST PROFITS, LOST SAVINGS, OR LOSS OF DATA, EVEN IF MICROSEMI OR A LICENSOR HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, OR FOR ANY CLAIM BY ANY OTHER PARTY. Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation or exclusion may not apply to you.
10. **Export.** You acknowledge that the laws and regulations of the United States and other countries may restrict the export and re-export of the Software. You agree that you will not export or re-export the Software or documentation in any form in violation of applicable United States and foreign law.
11. **Government Restricted Rights.** The Software is subject to restricted rights as follows. If the Software is acquired under the terms of a GSA contract: use, reproduction or disclosure is subject to the restrictions set forth in the applicable ADP Schedule contract. If the Software is acquired under the terms of a DoD or civilian agency contract, use, duplication or disclosure by the Government is subject to the restrictions of this Agreement in accordance with 48 C.F.R. 12.212 of the Federal Acquisition Regulations and its successors and 49 C.F.R. 227.7202-1 of the DoD FAR Supplement and its successors.
12. **General.** You acknowledge that you have read this Agreement, understand it, and that by using the Software you agree to be bound by its terms and conditions. You further agree that it is the complete and exclusive statement of the agreement between Microsemi and you, and supersedes any proposal or prior agreement, oral or written, and any other communication between Microsemi and you relating to the subject matter of this Agreement. No additional or any different terms will be enforceable against Microsemi unless Microsemi gives its express consent, including an express waiver of the terms of this Agreement, in writing signed by an officer of Microsemi. You assume full responsibility for the use of the Software and agree to use the Software legally and responsibly. This Agreement shall be governed by California law, except as to copyright matters, which are covered by Federal law. This Agreement is deemed entered into at Sunnyvale, California by both parties. Should any provision of this Agreement be declared unenforceable in any jurisdiction, then such

provision shall be deemed severable from this Agreement and shall not affect the remainder hereof.
All rights in the Software not specifically granted in this Agreement are reserved by Microsemi.

Should you have any questions concerning this license, contact:

Microsemi Corporation
Legal Department
One Enterprise
Aliso Viejo, CA 92656
(949) 380-6100

1 Getting Started with the Command Line Utility

This chapter explains how your Microsemi® Adaptec® RAID controllers support the use of the ARCCONF command line utility.

This chapter explains how your Microsemi SmartHBA-SA controller supports the use of the ARCCONF command line utility.

This utility allows you to:

- Create and delete logical drives
- Display and modify configuration settings
- Copy configurations from one computer to another
- Recover from a failed physical device and rebuild an affected logical drive
- Flash new firmware and BIOS onto the controller
- Enable the controller to check the removal and connection of any disk drives
- Provides access to the status and event logs of a controller
- Isolate problems and determine their causes

1.1 Installing the Command Line Utility

You can install ARCCONF with the Microsemi Adaptec maxView Storage Manager application. If you prefer to install just the command line utility, without installing the maxView Storage Manager GUI, you can install just the ARCCONF executable for your operating system.

Follow the instructions in this section to install ARCCONF on the supported operating systems with maxView Storage Manager. (For more information about maxView Storage Manager, see the *maxView Storage Manager User's Guide*.)

Follow the instructions in this section to install ARCCONF on the supported operating systems.

Note: On FreeBSD systems, you must use ARCCONF to perform storage management tasks. FreeBSD does not support the maxView Storage Manager GUI. For more information, see [Downloading the Installation Packages](#) and [Installing on FreeBSD](#) on page 12.

1.1.1 Downloading the Installation Packages

Complete these steps to download the installation package for your operating system(s):

1. Open a browser window, then type `start.adaptec.com` in the address bar.
2. Select your RAID controller family (Series 7, Series 8, and so on) and controller model.
3. Select **Storage Manager Downloads**, then select the appropriate installer package from the list; for instance, maxView Storage Manager for Windows x64 or maxView Storage Manager for Linux.

Note: To install ARCCONF without the GUI, select **Adaptec ARCCONF Command Line Utility** from the list of installers. This package includes the ARCCONF executable for Windows, Linux, Solaris, and FreeBSD. It also includes a statically-linked ARCCONF executable, which allows you to run the program without any OS library dependencies.

4. Click **Download Now** and accept the license agreement.
5. When the download completes, extract the contents of the installer archive file to a temporary location. If the archive includes installers for multiple operating system versions (VMware, for instance), each installer is stored in a separate folder.

Note: If you are installing maxView Storage Manager and ARCCONF on a different machine—for instance, you downloaded the Linux installer onto a Windows machine—copy the installer from the download location to a temporary location on the target machine. Use whatever method you prefer to copy the file: USB flash drive; network transfer; Telnet/SSH; whatever is most convenient.

- Continue with the installation instructions for your operating system.

1.1.2 Installing on Windows

To install ARCCONF on Windows systems:

- Open Windows Explorer or My Computer, then change to the directory where the Windows setup program is located (see [Downloading the Installation Packages](#) on page 10 for details).
- Double-click the setup program for your operating system version:

Options	Description
Windows 64-bit	setup_asm_x64.exe

 The Installation wizard opens.
- Click **Next** to begin the installation, click **I accept...**, then click **Next**.
- Add the following configuration settings:
 - CIM Server Port: 5988.
 - Web Server Port: 8443.
- Click **OK** on the password verification window and on the CIM Server and Web Server port number verification window.
- In the Features window, select **GUI**, **Agent**, and **CLI Tools**. Then click **Next**.
- Follow the on-screen instructions to complete the installation.

1.1.3 Installing on Red Hat, Cent OS, SuSE, or Fedora Linux

To install ARCCONF on Red Hat, Cent OS, SuSE, or Fedora Linux:

- In a shell window, change to the directory where the Linux installer package is located (see [Downloading the Installer Package](#) for details).
- Run the .bin file for your operating system version (where xxxxx=build number):

Options	Description
Linux 64-bit	./StorMan-2.02-xxxxx.x86_64.bin
- When prompted for configuration details, enter the following:
 Enter the CIM Server HTTP Port: [default:5988]
 When the installation completes a confirmation message is displayed.

1.1.4 Installing on Debian or Ubuntu Linux

To install ARCCONF on Debian or Ubuntu Linux:

- In a shell window, change to the directory where the Debian or Ubuntu installer package is located (see [Downloading the Installation Packages](#) on page 10 for details).
- Install the .deb package for your operating system version (where xxxxx=build number):

Options	Description
Linux 64-bit	dpkg -i StorMan-2.02-xxxxx_amd64.deb
- Enter the following configuration details:
 Enter the CIM Server HTTP Port: [default:5988].
 When the installation completes a confirmation message is displayed.

1.1.5 Installing on Solaris

To install ARCCONF on Solaris:

- On the Solaris machine, change to the directory where the Solaris installer package is located (see [Downloading the Installer Package](#) for details).

2. Install maxView Storage Manager:
`pkgadd -d StorMan.pkg`
3. At the prompt to continue, select `y`, then press `Enter`.
4. Enter the following configuration details:
 Enter your username [default: root].
 Enter your operating system password.
 Enter the CIM Server HTTP Port: [default:5988].
 When the installation completes a confirmation message is displayed.

1.1.6 Installing on FreeBSD

To install ARCCONF on FreeBSD:

1. Copy the `arccconf` executable from the original download location to your FreeBSD system (see [Downloading the Installer Package](#) for details).
2. Verify that the file has 'execute' privilege.

1.1.7 Installing on VMware

Use the following procedure to install the `.vib` files for VMware ESXi 5.5 or VMware ESXi 6.0. Perform the installation from a remote system running a Telnet/SSH client. Use a terminal emulator to access the ESXi server remotely.

1. Copy the following files from the installer download location to the `/tmp` directory on your local ESXi server (see [Downloading the Installation Packages](#) on page 10 for details):

- `vmware-esx-provider-arccconf.vib`
- `vmware-esx-provider-arcsmis.vib`

The `arccconf.vib` is for command line communication.

The `arcsmis.vib` is for remote management communication.

2. Check for existing installation of `arccconf`.
`esxcli software vib list | grep arccconf`
3. Remove the existing `arccconf` package.
`esxcli software vib remove -n arccconf`
 When the package is removed, you receive the message "Reboot Required: false."
4. Check for an existing installation of `arc-cim-provider`.
`esxcli software vib list | grep arc-cim-provider`
5. Remove the existing `arc-cim-provider` package.
`esxcli software vib remove -n arc-cim-provider`
 When the package is removed, you receive the message "Reboot Required: true."
6. Set the installation acceptance level to either `PartnerSupported` or `CommunitySupported`:
`esxcli software acceptance set --level=PartnerSupported`
7. Install the `arccconf` package.
`esxcli software vib install --no-sig-check -v /tmp/vmware-esx-provider-arccconf.vib`
 When the package is installed, you receive the message "Reboot Required: false."
8. Install the `arc-cim-provider` package.
`esxcli software vib install --no-sig-check -v /tmp/vmware-esx-provider-arc-cim-provider.vib`
 When the package is installed, you receive the message "Reboot Required: true."
9. Reboot the system.
10. Continue the installation with [Installing on a Guest Operating System](#) on page 13.

1.1.8 Installing on Citrix XenServer

Use the following procedure to install the maxView Storage Manager support package on a Citrix XenServer host. This package installs and configures all the components necessary to run maxView Storage Manager and ARCCONF from a XenServer guest operating system.

Note: Before installing the maxView support package on the XenServer host, you *must* install the XenServer Integration Suite Supplemental Pack. Do not continue until you complete this task. See your XenServer installation guide for details.

1. Copy the XenServer module rpm from the installer download location to your XenServer /tmp directory (see [Downloading the Installer Package](#) for details).
2. Install the rpm package for your operating system version (xxxxx=build number).

Options	Description
---------	-------------

XenServer 64-bit	rpm -i StorMan-2.02-xxxxx_amd64.rpm
-------------------------	-------------------------------------

3. Continue with [Installing on a Guest Operating System](#) on page 13.

1.1.9 Installing on a Guest Operating System

This section describes how to install ARCCONF on a VMware or Citrix XenServer guest operating system.

1.1.9.1 Installing on a Windows Guest OS

To install ARCCONF on a Windows Guest OS running on VMware or Citrix XenServer:

1. On the VMware or XenServer guest OS, change to the directory where the Guest OS installer package is located (see [Downloading the Installer Package](#) for details).
2. Double-click the setup program for your operating system:

Options	Description
---------	-------------

Windows GOS 64-bit	setup_maxview_gos_x64.exe
---------------------------	---------------------------

The Installation wizard opens.

3. Choose the hypervisor type (ESXi Server or XenServer), then click **Next**.
4. Enter the following configuration details:
 - a) Host IP Address (ESXi or XenServer host)
 - b) Web Server Port: 8443
 - c) ESXi or XenServer Host user name (default: root)
 - d) ESXi or XenServer Host operating system password/password confirmation
5. Click **Next**, then click **Install**.

When the installation is complete you receive a confirmation message.

1.1.9.2 Installing on a Linux Guest OS

To install ARCCONF on a Linux Guest OS running on VMware or Citrix XenServer:

1. On the VMware or XenServer Guest OS, change to the directory where the Linux installer package is located (see [Downloading the Installer Package](#) for details).
2. Run the installer for your operating system version.

Options	Description
---------	-------------

Linux GOS 64-bit	./Storman-2.02.GOS86_64.bin
-------------------------	-----------------------------

3. At the prompt, choose the GOS type. Enter 1 for ESXi, 2 for XenServer:
Select the GOS Type. 1.ESXi Server 2.XenServer:
4. Enter the following configuration details:
Hypervisor IP address

Hypervisor username [default: root]
 Hypervisor password
 Event Listener Port [default: 65500]

When the installation is complete you receive a confirmation message.

1.1.10 Installing on PowerPC

- Installing ARCCONF on PowerPC:
 - Installing on RHEL PowerPC 64-bit


```
rpm -i Arcconf-2.02-xxxxx.ppc64le.rpm
```
 - Installing on Ubuntu PowerPC 64-bit


```
dpkg -i Arcconf-2.02-xxxxx.ppc64el.deb
```
 - Installing on SLES PowerPC 64-bit


```
rpm -i Arcconf-2.02-xxxxx.ppc64le.rpm
```
- Installing ARCCONF in Petitboot:
 - Extract package `arcconf-2.02-xxxxx.tar.xz` in the folder of your choice.

Where xxxxx is the installer version.

1.2 Starting the Command Line Utility

1. To start ARCCONF, enter one of the following commands:

Options	Description
Windows	<code><install_dir>\arcconf.exe</code>
Linux	<code>/usr/<install_dir>/arcconf</code> <code>/<install_dir>/arcconf</code>
Solaris	<code>/opt/StorMan/arcconf</code>
FreeBSD	<code>/<install_dir>/arcconf</code>
VMware	<code>/usr/StorMan/arcconf</code>
VMware ESXi with Remote ARCCONF	<code>/usr/RemoteArcconf/arcconf</code>
XenServer	<code>/usr/StorMan/arcconf</code>

where `Install_dir` is the directory where the utility is installed.

2. To see a list of available commands, type `ARCCONF` at the prompt. For help with a specific command, type `ARCCONF <command_name> help`.

2 Using the Command Line Utility

This chapter explains how to use the command line utility interactively or in batch mode. With interactive mode, enter commands at the prompt. In batch mode, create scripts and run the script in the appropriate shell, as described in the table below.

Table 1 • ARCCONF Batch Environments

Environment	Batch File	Run Script
Windows	.bat	CMD.EXE
Linux/Unix	.sh	sh / bash

In either mode, if your command fails, you immediately see an error message of Command failed. Other script messages that you can get are Command completed successfully, or Command aborted.

The return values for each command are the same:

0x00: SUCCESS

0x01: FAILURE - The requested command failed

0x02: ABORT - The command was aborted because parameters failed validation

0x03: INVALID_ARGUMENTS - The arguments are incorrect. (Displays COMMAND help)

To view a list of commands at the command line, type ARCCONF and press Enter.

To access the online help for a specific command, type ARCCONF <command>, then press Enter.

2.1 ARCCONF Commands

The following commands are available in ARCCONF. The commands are described on the following pages, in alphabetical order.

Table 2 • ARCCONF Commands

atapassword	getlogs	resetstatisticscounters	setncq
backupunit	getperform	romupdate	setperform
consistencycheck	getsmartstats	saveconfig	setphy
copyback	getstatus	savesupportarchive	setpower
cpId	getversion	seeprom	setpriority
create	identify	setalarm	setstate
delete	imageupdate	setbiosparams	setstatsdatacollection
driverupdate	key	setboot	setvmcredential
errortunable	list	setcache	task
expanderlist	modify	setconfig	uninit
expanderupgrade	phyerrorlog	setcontrollermode	verifywrite
failover	playconfig	setcontrollerparam	
getconfig	preserveconfig	setcustommode	
getexception	rescan	setmaxcache	
		setname	

Note: In the command syntax descriptions, <> indicates a required parameter and [] indicates an optional parameter.

2.2 **arcconf atapassword**

Description

Sets or clears the drive's password for SATA drives. See *arcconf task* for more information about Secure Erase.

Syntax

```
ARCCONF ATAPASSWORD <Controller#> SET <new password> <Channel# ID#> ...
ARCCONF ATAPASSWORD <Controller#> CLEAR <current password> <Channel# ID#> ...
```

Parameters

new password | current password

New password, current password.

Channel/ID

Lists the space-delimited channel number and device number (ID) pairs for each drive on which to set or clear the password.

Examples

```
ARCCONF ATAPASSWORD 1 SET uR8ryx 0 1
ARCCONF ATAPASSWORD 1 CLEAR uR8ryx 0 1
```

2.3 **arcconf backupunit**

Description

Resets the hard error flag on the AFM-700 Flash Backup module, and erases the lifetime calculation records. A hard error disables the backup module *permanently*, across power cycles, until the hard error flag is cleared. The error flag is set when any of the following events occur:

- Initialization failure
- Backup failure due to an uncorrectable ECC error
- Backup failure due to a lack of good blocks in the AFM Flash
- Backup failure due to bad meta-data
- Backup failure due to a hardware failure
- Restore failure due to an uncorrectable ECC error
- Restore failure due to a DMA timeout
- Restore failure due to a hardware failure
- AFM Flash erase failure of the meta-data
- AFM Flash erase failure due to a hardware failure

Note: A reboot is necessary for change to take effect.

Syntax

```
ARCCONF BACKUPUNIT <Controller#> reset
```

Parameters

Controller#

The controller number.

Examples

```
ARCCONF BACKUPUNIT 1 reset
```

2.4 arcconf consistencycheck

Description

Toggles the background consistency check modes of the controller.

Syntax

```
ARCCONF CONSISTENCYCHECK <Controller#> <on|off|period <DAYS>> [noprompt]
ARCCONF CONSISTENCYCHECK <Controller#> <on [Delay]|off> [noprompt]
ARCCONF CONSISTENCYCHECK <Controller#> PARALLELCOUNT <Count>
```

Parameters

Controller#

Controller number.

On [Delay] | Off

Turns background consistency check on, with optional 1-30 second delay period. The delay period sets the controller idle time, after which the consistency check will start. A value of 0 disables the consistency check (effectively, the same as setting the parameter to Off). If Delay is unspecified, the consistency check mode is set to HIGH. If Delay is specified, the consistency check mode is set to IDLE, for specified period.

On | Off

Turns background consistency check on or off. A value of 0 disables the consistency check (effectively, the same as setting the parameter to Off).

Period <DAYS>

Sets the number of days to complete the background consistency check. The minimum value is 10 days (quick), the maximum is 365 days (slow). Setting the period automatically turns background consistency check on.

PARALLELCOUNT <Count>

Sets the parallel surface scan count for the controller. A value of 1 disables the consistency check.

Noprompt

Optional parameter that suppresses the confirmation prompt.

Examples

```
ARCCONF CONSISTENCYCHECK 1 PERIOD 30
ARCCONF CONSISTENCYCHECK 1 ON 20
ARCCONF CONSISTENCYCHECK 1 OFF
ARCCONF CONSISTENCYCHECK 1 PARALLELCOUNT 4
```

2.5 arcconf copyback

Description

Enables or disables the copyback feature, which attempts to keep drives in the original slot order after rebuilds.

Syntax

```
ARCCONF COPYBACK <Controller#> <ON|OFF>
```

Parameters

Controller#

The controller number

On enables the copyback feature

Off disables the copyback feature

Examples

```
ARCCONF COPYBACK 1 ON
```

2.6 arccnf cpld

Description

Updates the CPLD image from flash.

Syntax

```
ARCCONF CPLD <Controller#> FLASHUPDATE [noprompt] [nologs]  
ARCCONF CPLD <Controller#> FORCERELOAD [noprompt] [nologs]
```

Parameters

Controller#

The controller number.

FLASHUPDATE

Updates the CPLD image from flash.

FORCERELOAD

Forces the CPLD image to reload.

Noprompt

Optional parameter that suppresses confirmation prompt.

Nologs

Optional parameter that suppresses logging of warning/error messages.

Examples

```
ARCCONF CPLD 1 FLASHUPDATE
```

2.7 arccnf create

Description

Creates a new logical drive, maxCache Device, or JBOD and, optionally, enables logical drive read caching, write caching, and maxCache SSD caching. You must provide the channel and device ID of the physical devices.

On redundant logical drives, ARCCONF performs autosynchronization.

ARCCONF presents JBODs as physical devices, not logical drives.

Syntax

```
ARCCONF CREATE <Controller#> <LOGICALDRIVE|MAXCACHE> [Options] <Size> <RAID#>
<CHANNEL# DRIVE#> [CHANNEL# DRIVE#] ... [noprompt] [nologs]
ARCCONF CREATE <Controller#> LOGICALDRIVE RVOLUME <LD#> <LD#> [LD#] ...
[noprompt] [nologs]
ARCCONF CREATE <Controller#> JBOD <CHANNEL# DRIVE#> [CHANNEL# DRIVE#] ...
[noprompt] [nologs]

ARCCONF CREATE <Controller#> LOGICALDRIVE [Options] <Size> <RAID#> <CHANNEL#
DRIVE#> [CHANNEL# DRIVE#] ... [noprompt] [nologs]
ARCCONF CREATE <Controller#> LOGICALDRIVE [Options] <Size> <RAID#> ARRAY
<Array#> [noprompt] [nologs]
```

Syntax

```
ARCCONF CREATE <Controller#> LOGICALDRIVE [Options] <Size> <RAID#> <CHANNEL#
DRIVE#> [CHANNEL# DRIVE#] ... [noprompt] [nologs]
ARCCONF CREATE <Controller#> LOGICALDRIVE RVOLUME <LD#> <LD#> [LD#] ...
[noprompt] [nologs]
ARCCONF CREATE <Controller#> JBOD <CHANNEL# DRIVE#> [CHANNEL# DRIVE#] ...
[noprompt] [nologs]
```

Parameters

Controller#

The controller number.

Logical Drive, maxCache

Indicates a logical drive or maxCache Device, with the following options:

- Stripesize <STRIPE>—Allows the logical drive stripe size to be built. Optional parameters for specifying a stripe size. STRIPE is specified in kilobytes 8, 16, 32, 64, 128, 256, 512 and 1024 are supported. The default is 256KB.
- Legs <LEG>—Optional parameters for specifying number of legs. Value is an integer.
- LEG—Number of legs for RAID level 50 or 60.
 - RAID 50—2-16 legs, 3-32 drives/leg, 128 drives max.
 - RAID 60—2-16 legs, 4-16 drives/leg, 128 drives max.
- Name <NAME>—Optional parameter for specifying the alias name of a logical device that is displayed in the utilities. Value is a string of up to 16 characters.
- Priority <PRIORITY>—Initialization Priority for logical drive to be created. Valid options are: HIGH, MED, or LOW.
- Method <METHOD>—Initialization method for the logical drive. Valid options include: BUILD, CLEAR, QUICK, SKIP DEFAULT. Use SKIP for recovery only (to skip the initialization step).
- LDcache—Sets the cache state for the logical drive:
 - LON - cache on
 - LOFF - cache off

- **VerifyWithOS <True | False>**—(*Windows only*) Wait for logical devices to be exposed to Windows OS:
 - True - wait for the logical device to be exposed to the OS
 - False - do not wait for the logical device to be exposed to the OS
- **Rcache**—Sets the logical drive read cache mode:
 - RON - read cache on
 - ROFF - read cache off
- **Wcache**—Sets the logical drive write cache mode:
 - WT - write-through disabled
 - WB - write-back enabled
 - WBB - write-back enabled (when protected by battery or flash backup module)
- **MaxCacheReadCache**—Sets the logical drive SSD read cache mode:
 - ION - maxCache on
 - IOFF - maxCache off
- **MaxCacheWriteCache**—Sets the logical drive SSD write cache mode:
 - ION - maxCache on
 - IOFF - maxCache off
- **MaxCacheWritePolicy**—Sets the maxCache write cache policy:
 - WB - write back enabled. maxCache will store the data on the SSD and write it back to the hard disks when there is little or no impact on performance. This is the default policy.
 - INSTWB - instant write back enabled. In addition to the default policy, maxCache will create “dirty pages” on-the-fly for full-stripe writes if there is room on the SSD and the number of dirty pages is below the threshold.
 - WT - write through enabled. Similar to instant write back, but full-stripe writes go to both the cache and hard disk and no dirty pages are created on-the-fly.

This argument is valid only if MaxCacheWriteCache is ION.

Note: For more information about write cache policy, see [arconf setmaxcache](#) on page 49.

Array <Array#>

Array number on which to create the logical drive, with the following options:

- **Sectors <sectors>** - Sectors per track of the logical device. Valid options are 32 and 63.
- **SSDSmartPath <enable | disable>** - Enables or disables logical device acceleration. Default is enabled.
- **SSDOverProvisioningOptimization <enable | disable>** - Initializes solid state drives that support the rapid parity initialization feature.

Size

Indicates the size of the logical drive in megabytes. Use MAX to set size to available space. Use MAXMBR to set the size to 2TB.

RAID#

Indicates the RAID level for the new logical drive: 0, 1, 1E, 10, 5, 5EE, 50, 6, 60, and volume are supported. For maxCache, 0, 1, 1E, 5 and Simple_Volume are supported. 0, 1, 10 and 5 are supported.

Note: For a complete list of supported RAID levels for your controller, refer to the product release notes.

Channel# Drive#

Lists the space-delimited channel number and device number pairs for each device to add to the logical drive or maxCache Device. For maxCache, the devices must be SSDs.

Rvolume

RAID level for a RAID volume logical drive.

LD#

Logical drive numbers for two or more logical drives to be concatenated into the RAID volume. RAID levels 0, 1, and 5 are supported for RVOLUME members. All RVOLUME members must be the same RAID level.

Noprompt

No prompt for confirmation

Examples

```
ARCCONF CREATE 1 LOGICALDRIVE STRIPESIZE 64 MAX 0 1 0 2 0 3 2 NOPROMPT
ARCCONF CREATE 1 JBOD 0 1 NOPROMPT
ARCCONF CREATE 1 LOGICALDRIVE ssdsmartpath enable ssdoverprovisioningoptimization enable
1024 0 ARRAY 0
```

2.8 arccnf delete

Description

Deletes a logical drive, JBOD, or maxCache logical device or array. All data stored on the logical drive or JBOD will be lost. Spanned drives cannot be deleted with this function.

Syntax

```
ARCCONF DELETE <Controller#> LOGICALDRIVE <LD#> <LD#> ...|ALL
[PRESERVEPARTITION] [noprompt] [nologs]
ARCCONF DELETE <Controller#> JBOD <CHANNEL# DRIVE#> [CHANNEL# DRIVE#] ...
[nologs]
ARCCONF DELETE <Controller#> JBOD ALL [noprompt]
ARCCONF DELETE <Controller#> MAXCACHE
```

Syntax

```
ARCCONF DELETE <Controller#> LOGICALDRIVE <LD#> <LD#> ...|ALL [noprompt]
[nologs]
ARCCONF DELETE <Controller#> ARRAY <arr#> [noprompt] [nologs]
ARCCONF DELETE <Controller#> ARRAY ALL [noprompt] [nologs]
```

Syntax

```
ARCCONF DELETE <Controller#> LOGICALDRIVE <LogicalDrive#> <LD#> <LD#> [noprompt]
ARCCONF DELETE <Controller#> JBOD <CHANNEL# DRIVE#> [CHANNEL# DRIVE#] ...
[noprompt]
ARCCONF DELETE <Controller#> LOGICALDRIVE|JBOD ALL [noprompt]
```

Parameters

Controller#

Controller# is the controller number

LD#

LogicalDrive# is the number of the logical drive to be deleted.

arr#

arr# is the number of the array to be deleted.

PRESERVEPARTITION

Deletes logical drives without partitions. Applicable ONLY for ALL or multiple LD#.

LogicalDrive|JBOD ALL

Deletes all logical drives or JBODs.

MAXCACHE

Deletes the maxCache Device.

Noprompt

Optional parameter that suppresses alert messages.

Examples

```
ARCCONF DELETE 1 LOGICALDRIVE 1 2 3
ARCCONF DELETE 1 LOGICALDRIVE 0 1 PRESERVEPARTITION
ARCCONF DELETE 1 JBOD ALL
ARCCONF DELETE 1 ARRAY 0
ARCCONF DELETE 1 ARRAY ALL
```

2.9 arcconf driverupdate

Description

Updates the Windows device driver for the controller.

Note: This command is available on Windows systems only.

Syntax

```
ARCCONF DRIVERUPDATE <DirName> [nologs]
```

Parameters

DirName

Absolute path to directory containing the Windows driver.

Nologs

Optional parameter that suppresses log output.

Examples

```
ARCCONF DRIVERUPDATE C:\WINDOWSALL
```

2.10 arcconf errortunable

Description

Sets the tunable error profile for the controller. Contact Microsemi Adaptec Support for more information about using this command to set up a tunable error profile.

Syntax

```
ARCCONF ERRORTUNABLE <Controller#> SETPROFILE <Profile#>
ARCCONF ERRORTUNABLE <Controller#> GETPARAMS [Profile#] [SAVE [filename]]
[noprompt]
ARCCONF ERRORTUNABLE <Controller#> CONFIGPARAMS FILE [filename]
ARCCONF ERRORTUNABLE <Controller#> CONFIGPARAMS <Param1> <Value1> [Param2]
[Value2] ...
```

Parameters

Controller#

Controller number

GETPARAMS

Returns the parameters for the current profile on the controller.

Profile#

Profile number:

1. Aggressive
2. Normal
3. Relaxed

PARAM/VALUE...

A list of param/value pairs:

- MAX_ALLOWED_CRC_ERROR_COUNT
- CRC_ERROR_DURATION_SEC
- MAX_ALLOWED_NOT_READY_COUNT
- MAX_ALLOWED_SEL_TIMEOUT_COUNT
- MAX_ALLOWED_ASYNC_FREEZE_COUNT
- ASYNC_FREEZE_DURATION_SEC
- NEXUS_BUSY_DURATION_SEC
- MAX_IO_TIMEOUT_SEC
- PER_ITERATION_IO_TIMEOUT_SEC
- MAX_RETRY_COUNT
- ALLOW_BBR_ON_WRITE_FAILURE
- MAX_ALLOWED_MEDIUM_ERROR_COUNT
- MEDIUM_ERROR_DURATION_SEC

SAVE and FILE <File name>

Path to tunable parameter definition file. The default filename is `ErrorTunableParams.cfg`.

Examples

```
ARCCONF ERRORTUNABLE 1 SETPROFILE 1
ARCCONF ERRORTUNABLE 1 GETPARAMS 2 SAVE C:\abc.cfg
ARCCONF ERRORTUNABLE 1 CONFIGPARAMS FILE C:\abc.cfg
ARCCONF ERRORTUNABLE 1 CONFIGPARAMS CRC_ERROR_DURATION_SEC 10
```

2.11 arccnf expanderlist

Description

Returns a list of disk drive expanders on a controller.

Syntax

```
ARCCONF EXPANDERLIST <Controller#>
```

Parameters

Controller#

Controller number.

Examples

```
ARCCONF EXPANDERLIST 1
```

2.12 arccnf expanderupgrade

Description

Allows new firmware to be flashed to an enclosure or expander.

Note: Some controllers do not support this operation.

Syntax:

```
ARCCONF EXPANDERUPGRADE <Controller#> ENCLOSURE <Connector# Channel# ID#>
[ChunkSize#] <UpgradeType> <Filename> [Mode#] [noprompt]
```

Parameters

Controller#

Controller number.

Channel#

Channel number of the device to be updated.

ID#

Device number of the device to be updated.

Connector#

Connector number of the device to be updated.

ChunkSize#

Chunk size, in bytes, to be used to update the firmware. Default is 65536 bytes.

Filename

Name of the firmware update file.

UpgradeType

EXPANDER—update the firmware image on the expander or enclosure

MFG—update the manufacturing image (BOOT SEEPROM) on the expander or enclosure

CPLD—update the CPLD image on the expander or enclosure

Note: MFG and CPLD upgrade types are supported on the Microsemi Adaptec AEC-82885T expander only.

Mode#

The Mode parameter applies to EXPANDER and MFG upgrade types only. Valid values are:

- 02h—download microcode only; requires system reset or power cycle to activate (default)
- 06h—download microcode with offsets and activate
- 07h—download microcode with offsets, save, and activate
- 0Eh—download microcode with offsets and defer activation
- 0Fh—activate deferred microcode

Noprompt

Optional parameter that suppresses alert messages.

Examples

```
arcconf EXPANDERUPGRADE 1 ENCLOSURE 2 0 0 1024 EXPANDER C:\FirmwareImage.bin 7
arcconf EXPANDERUPGRADE 1 ENCLOSURE 2 0 0 512 MFG C:\FirmwareImage.rom 6
arcconf EXPANDERUPGRADE 1 ENCLOSURE 2 0 0 256 CPLD C:\CPLDImage.bin noprompt
```

2.13 arcconf failover

Description

Turns automatic failover on and off.

Syntax

```
ARCCONF FAILOVER <Controller#> <on|off>
```

Parameters

Controller#

The controller number.

On

Turns the controller failover mode on.

Off

Turns the controller failover mode off.

Examples

```
ARCCONF FAILOVER 1 ON
```

2.14 **arcconf getconfig**

Description

Lists information about controllers, logical devices, physical drives, and flash backup systems, including:

- Controller type, status, World Wide Name (WWN), and mode
- Cache preservation status: enabled/disabled, % of cache pages preserved
- BIOS, boot block, device driver, and firmware versions
- Logical drive and array status, RAID level and size
- Logical drive mount points
- RAID 10 segment and group information
- maxCache status, fetch and flush rate policy, read/write balance, SSD information
- Device type, device ID, presence of PFA
- Physical device state, mount point (for drives with OS partition)
- Enclosure information: fan, power supply, and temperature status
- SGPIO virtual SEP information (virtual enclosure device for SGPIO backplanes)
- Flash backup information (for AFM-700 flash backup module): status, charge level, temperature readings, max voltage, current, estimated life, errors, and serial number
- Connector/Lane/Phy mapping

Also displays controller BIOS settings if you do not include a device-type keyword.

Note: When displaying adapter information (AD keyword), the Controller Status field is set to `Ok` or `Not Ok`. Its value is set to `Not Ok` only if:

1. Communication with the controller fails. This occurs when the driver returns an error code after attempting to send a command to the controller.
2. A logical drive was created with a newer version of `arcconf`. Update to the latest utilities.
3. The controller mode (RAID/Mixed/HBA) is supported by the hardware, but not the firmware. Usually, this means that an older version of `arcconf` is being used against a newer controller. Update to the latest utilities.

For more information, see [getconfig Output Summary](#) on page 61.

Syntax

```
ARCCONF GETCONFIG <Controller#> [AD|LD [LD#]|PD|MC|AL|CN]
```

```
ARCCONF GETCONFIG <Controller#> [AD|PD|AL|CN]
ARCCONF GETCONFIG <Controller#> [AD|LD [LD#]]|PD|AL]
ARCCONF GETCONFIG <Controller#> [AR [AR#]]|CN]
```

Parameters

Controller#

Controller number

LD#

Display information about the specified logical device

AR#

Display information about the specified array

AD/PD/AL...

- AD—Adapter information only
- LD—Logical drive information only
- AR—Array information only
- PD—Physical device information only
- MC—maxCache information only
- CN—Connector information only
- AL—All information

Examples

```
ARCCONF GETCONFIG 1
-----
Controller BIOS Setting Information
-----
Runtime BIOS                : Enabled
Array BBS Support           : Enabled
Physical Drives Displayed during POST : Disabled
Backplane Mode              : SGPIO
MissingDrvCount             : 8
...

ARCCONF GETCONFIG 1 LD 0
ARCCONF GETCONFIG 1 CN
ARCCONF GETCONFIG 1 AR 1
```

2.15 arconf getexception

Description

Prints the exception (errors/warnings) on the controller.

Syntax

```
ARCCONF GETEXCEPTION <Controller#> [ AD | LD | PD | AL] [on/off][nologs]
```

Parameters

Controller#

The controller number.

On/Off

Turns warning exceptions on and off.

AD/LD/PD/AL

- AD—Controller exceptions only
- LD—Logical drive exceptions only

- PD—Physical drive exceptions only
- AL—All exceptions

Examples

```
ARCCONF GETEXCEPTION 1 PD
ARCCONF GETEXCEPTION 1 AL
ARCCONF GETEXCEPTION 1 off
```

2.16 arccnf getlogs

Description

Provides access to controller status, event logs, and usage statistics, including:

- A log of device errors that the controller encountered
- A log that records any occurrences of defunct devices
- A log of special events that may have occurred (rebuilt, LDMs, etc.)
- A log of controller usage statistics, including Inter-I/O Read and Write times and I/O Completion Read and Write times
- A log of cache statistics for one or all logical drives
- A log of supported hardware components on the controller

Syntax

```
ARCCONF GETLOGS <Controller#> <Type1> [clear|tabular] [nologs]
ARCCONF GETLOGS <Controller#> <Type2> [tabular] [nologs]
ARCCONF GETLOGS <Controller#> <Type3> LOGICALDRIVE [<LD#>|ALL] [tabular]
[nologs]
ARCCONF GETLOGS <Controller#> <Type4> <HardwareType#> [nologs]
ARCCONF GETLOGS <Controller#> DEVICE <clear> <ErrorType#> [<Channel# ID#>|ALL]
[nologs]

ARCCONF GETLOGS <Controller#> <Type1> [clear|tabular] [nologs]
ARCCONF GETLOGS <Controller#> <Type2> [tabular] [nologs]
ARCCONF GETLOGS <Controller#> <Type4> <HardwareType#> [nologs]
ARCCONF GETLOGS <Controller#> DEVICE <clear> <ErrorType#> [<Channel# ID#>|ALL]
[nologs]
```

Parameters

Controller#

Controller number.

Type1

One of the following:

- DEVICE—device error log
- DEAD—dead (failed) drive log
- EVENT—controller event log

Type2

One of the following:

- STATS—controller statistics data

Type3

One of the following:

- CACHE—cache statistics data for all or a single logical drive

Type4

One of the following:

1. Green Backup
2. Cache Memory
3. NVSRAM

ErrorType

One of the following:

- 1 - Parity Error Counter
- 2 - Link Failure Counter
- 3 - Hardware Error Counter
- 4 - Aborted Commands Counter
- 5 - Medium Error Counter
- 6 - SMART Warning Counter

Clear

Clears the specified log from the controller or a specific error counter for one or all physical drives on a controller.

Channel/ID

Channel and number of the physical device on the controller.

Tabular

Displays the log or statistics in tabular format.

Examples

```
ARCCONF GETLOGS 1 EVENT
ARCCONF GETLOGS 1 STATS tabular
ARCCONF GETLOGS 1 DEVICE clear 3 ALL
ARCCONF GETLOGS 1 CACHE LOGICALDRIVE 0
```

2.17 arconf getperform

Description

Fetches the parameters that define a logical drive performance mode. Default is the current mode.

Syntax

```
ARCCONF GETPERFORM <Controller#> [Performance Mode] [Save [Filename]] [Nologs]
```

Parameters

Controller#

Controller number.

Performance Mode

One of the following:

- 1 - Default/Dynamic mode
- 2 - OLTP/Database
- 3 - Big Block Bypass mode
- 4 - User defined mode

Save

Saves the performance mode parameters in a file.

Filename

Name of the file in which to save the parameters. If not specified, the default filename is `PerformanceMode.cfg`.

Nologs

Suppresses creation of logs for this command.

Examples

```
ARCCONF GETPERFORM 1 2
```

2.18 **arccnf getsmartstats**

Description

Displays SMART statistics for the hard drives and Solid State Drives (SSDs) on a controller.

Note: For more information about SMART statistics, see the maxView Storage Manager User's Guide.

Syntax

```
ARCCONF GETSMARTSTATS <Controller#> [forcespinup] [Tabular]
```

Parameters

Controller#

Controller number.

Tabular

Creates output in tabular format.

Force Spin Up

Read SMART statistics from hard drives when SMART poll is disabled on the controller.

Examples

```
ARCCONF GETSMARTSTATS 1
ARCCONF GETSMARTSTATS 1 TABULAR
```

2.19 **arccnf getstatus**

Description

The GETSTATUS function displays the status of any background command that is currently running, including information about the most recent rebuild, synchronization, logical-drive migration, and compaction/expansion. The information includes the type of operation, status, logical drive number and logical drive size (for a logical device), channel ID/device ID (for a physical drive), and percentage of the operation completed.

Note:

1. GETSTATUS reports currently active operations for ARCCONF commands and commands issued from maxView Storage Manager.
2. GETSTATUS reports verify, clear, initialize, and secure erase operations on physical devices.
3. GETSTATUS reports the status of controller rescan operations.

4. GETSTATUS only reports active operations. It does not display information if the operation is completed.

Syntax

```
ARCCONF GETSTATUS <Controller#> [nologs]
```

Parameters

Controller#

Controller# is the controller number

Examples

```
ARCCONF GETSTATUS 1
```

2.20 arconf getversion

Description

Lists version information for all controllers or a specific controller's software components, including information about the BIOS, driver, firmware currently running, and firmware that will run after a reboot.

Note: The firmware version that will run after a reboot is called the “staged” firmware.

Syntax

```
ARCCONF GETVERSION
ARCCONF GETVERSION <Controller#>
```

Parameters

Controller#

Controller# is the controller number

Examples

```
ARCCONF GETVERSION
ARCCONF GETVERSION 1
```

2.21 arconf identify

Description

Identifies a physical device, logical device, or maxCache device by blinking its LEDs.

Syntax

```
ARCCONF IDENTIFY <Controller#> LOGICALDRIVE <LogicalDrive#> [START|STOP]
[nologs]
```

```

ARCCONF IDENTIFY <Controller#> DEVICE <Channel# ID#> ... [START|STOP] [nologs]
ARCCONF IDENTIFY <Controller#> MAXCACHE [START|STOP] [nologs]

ARCCONF IDENTIFY <Controller#> LOGICALDRIVE <LogicalDrive#> [TIME <BlinkTime>]
[nologs]
ARCCONF IDENTIFY <Controller#> DEVICE <Channel# ID#> ... [TIME <BlinkTime>]
[nologs]
ARCCONF IDENTIFY <Controller#> ARRAY <Array#> [TIME <BlinkTime>] [nologs]
ARCCONF IDENTIFY <Controller#> ALL [STOP]

ARCCONF IDENTIFY <Controller#> DEVICE <Channel# ID#> [TIME <BlinkTime>] [nologs]
ARCCONF IDENTIFY <Controller#> ALL [STOP]

```

Parameters

Controller#

Controller number

LogicalDrive#

Number of the logical drive to be identified

Array#

Array number

Channel# ID#

Channel number and ID number for the physical device(s) to be identified

ALL

Blinks all physical devices on the controller for 1 hour or until the STOP command is issued

TIME <BlinkTime>

Time, in seconds, for the LEDs to continue blinking

START

Starts blinking the device until the STOP command is issued

STOP

Stops blinking the device

Examples

```

ARCCONF IDENTIFY 1 DEVICE 0 0
ARCCONF IDENTIFY 1 DEVICE 0 1 START
ARCCONF IDENTIFY 1 DEVICE 0 1 STOP
ARCCONF IDENTIFY 1 MAXCACHE START
ARCCONF IDENTIFY 1 ARRAY 0 TIME 30
ARCCONF IDENTIFY 1 ALL
ARCCONF IDENTIFY 1 ALL STOP

```

2.22 arccnf imageupdate

Description

Allows new firmware to be flashed to the hard drive.

Syntax:

```

ARCCONF IMAGEUPDATE <Controller#> DEVICE <Channel# ID# ChunkSize# Filename>
[Mode#] [BufferID#] [noprompt]

```

Parameters

Controller#

Controller number.

Channel#

Channel number of the device to be updated.

ID#

Device number of the device to be updated.

ChunkSize#

Chunk size, in bytes, to be used to update the firmware. The minimum chunk size is 32768.

Note: For SATA drives, the chunk size must be a multiple of 512.

Filename

Name of the firmware update file.

Mode#

Firmware update mode. Valid values for physical drives are:

- 3-(SATA) Download with offsets and save image for immediate and future use
- 7-(SAS) Download microcode with offsets, save, and activate

BufferID#

Mandatory for tape drive firmware update.

Noprompt

Optional parameter that suppresses alert messages.

Examples

```
ARCCONF IMAGEUPDATE 1 DEVICE 0 0 16384 ados.lod 3
```

2.23 **arccconf key**

Description

Loads a feature key onto a Microsemi Adaptec controller.

Syntax

```
ARCCONF KEY <Controller#> SET <Key#>
```

Parameters**Controller#**

The controller number.

Key#

The key number provided by Microsemi.

Examples

```
ARCCONF KEY 1 SET ABCDEFGHIJKLMNOPQRSTUVWXYZ
```

2.24 **arccconf list**

Description

Lists all controllers in the system, or the configuration of a specific controller.

Syntax

```
ARCCONF LIST [Controller#]
```

Parameters

Controller#

The controller number.

Examples

```
ARCCONF LIST
ARCCONF LIST 1
```

2.25 arcconf modify

Description

Morphs a logical device from one raid level to another (RAID Level Migration). Expands a logical device from original size to one with larger capacity (Online Capacity Expansion).

Expands, shrinks or moves an array, or moves a logical device to a new array.

Syntax

```
ARCCONF MODIFY <Controller#> FROM <LogicalDrive#>
TO [Options] <Size> <RAID#> <CHANNEL# ID#> [CHANNEL# ID#] ... [noprompt]

ARCCONF MODIFY <Controller#> ARRAY <Array#> MOVE <Channel# ID#> [Channel# ID#]
... [nologs]
ARCCONF MODIFY <Controller#> ARRAY <Array#> HEAL <Channel# ID#> [Channel# ID#]
... [nologs]
ARCCONF MODIFY <Controller#> LOGICALDRIVE <LD#> MOVEARRAY <Array#> [nologs]
ARCCONF MODIFY <Controller#> LOGICALDRIVE <LD#> NEWARRAY <Channel# ID#>
[Channel# ID#] ... [nologs]
```

Parameters

Controller#

The controller number

LogicalDrive#

The logical drive number to be modified

Array#

The array ID of the array to be modified

Options

One of the following:

- **Stripesize <size>**—indicates the stripe size in KB. Options are 8, 16, 32, 64, 128, 256, 512, and 1024. the default is 256KB.
- **Init_priority <priority>**—is the priority level of the modification. Options are low, med, and high.
- **Legs <leg>**— is the number of sub-arrays for a RAID level-50 or RAID level 60 array. Possible values are 2-16 legs and 3-16 drives/leg (to 48 drives maximum).

Size

- Size in MB.
- MAX indicates that you want to use all available space on the disk.

RAID#

RAID level for the logical drive: 0, 1, 10, 5, 6, 50, 60, and simple_volume. 0, 1, 10 and 5 are supported.

Channel# ID#

Channel number and device ID for the device

Note: The CHANNEL# and ID# parameters are the list of devices that will contain the target modification object. Channel and ID are repeatable parameters. For RAID 1 to Simple Volume migration, CHANNEL# and ID# parameters are ignored.

MOVE

Moves an array to a new set of physical devices. Number of new physical devices must equal the number of physical devices in the original array.

HEAL

Replaces failed physical devices in the array with the specified devices

MOVEARRAY

Moves a logical device to an existing array

NEWARRAY

Moves a logical device to a new array created with the specified physical devices

modifyparitygroups

Reconfigures the logical device(s) parity groups based on the final number of physical devices in the array

noprompt

Suppresses the user prompt

Examples

```
ARCCONF MODIFY 1 FROM 2 TO 2048 0 0 123 0 124 0 117
ARCCONF MODIFY 1 ARRAY 1 MOVE 0 2 0 3
ARCCONF MODIFY 1 ARRAY 1 HEAL 0 0 0 1
ARCCONF MODIFY 1 LOGICALDRIVE 0 MOVEARRAY 1
ARCCONF MODIFY 1 LOGICALDRIVE 0 NEWARRAY 0 4 0 5
```

2.26 arccnf phyerrorlog

Description

Displays PHY error logs for physical devices on a controller or expander PHYs.

Syntax

```
ARCCONF PHYERRORLOG <Controller#> DEVICE <Channel# ID#>
ARCCONF PHYERRORLOG <Controller#> DEVICE ALL
ARCCONF PHYERRORLOG <Controller#> EXPANDER <ExpanderID#> <PHY#>
ARCCONF PHYERRORLOG <Controller#> EXPANDER <ExpanderID#> ALL

ARCCONF PHYERRORLOG <Controller#> DEVICE <Channel# ID#>
ARCCONF PHYERRORLOG <Controller#> DEVICE ALL
```

Parameters

Controller#

Controller number.

Channel/ID

Channel and number of the physical device on the controller.

ExpanderID#

Expander identifier.

PHY#

PHY identifier.

ALL

Displays PHY error log for all physical devices or expander PHYs.

Examples

```
ARCCONF PHYERRORLOG 1 DEVICE 0 0
ARCCONF PHYERRORLOG 1 DEVICE ALL
ARCCONF PHYERRORLOG 1 EXPANDER 1 ALL
```

2.27 arccnf playconfig**Description**

Configures a controller using a XML server template file produced by the SAVECONFIG command (see [arccnf saveconfig](#) on page 40). Use this command to deploy the same controller configuration on multiple servers in your storage space.

Note:

1. The XML server template file (default, saveconfig.xml) is editable. For example, you may need to change the disk drive capacity, logical drive size, or RAID level.
2. Drives from the same vendor with slightly different capacities (147 GB vs. 150 GB, for instance) are considered interchangeable. If the interchange results in a change in logical drive capacity, the drive is scaled, as needed. For example, if the new drives have 4% more capacity due to vendor or model changes, then all logical drives are increased in size by 4%.
3. Be sure to check the log file to verify that the controller was configured successfully. The exit codes, shown below, indicate the success or failure of the operation and if the system needs to be rebooted.

Code	Value	Meaning
SUCCESS	0	Configuration succeeded, no reboot is required.
FAILURE_GENERAL	1	An error occurred and the configuration could not be completed.
SUCCESS_REBOOT	2	Configuration succeeded, but a reboot is required.

Syntax

```
ARCCONF PLAYCONFIG <Config XML File> [LogFile] [FORCE ALL|LOGICALSIZE] [SLOTID]
ARCCONF PLAYCONFIG <Config XML File> [LogFile] [FORCE ALL] [SLOTID]
```

Parameters**Config XML File**

The pathname of the server template file.

LogFile

Sets the pathname of the error log file. By default, the error log is available at C:\PMCS\Logs\playconfig.log on Windows operating systems and at /var/log/playconfig.log on Linux/Unix operating systems.

FORCE

Forces deployment of the server even if the controller does not support all features, or the drive capacity does not match the configuration in the input XML file. Use FORCE ALL to force deployment of all features; use FORCE LOGICALSIZE to force deployment of just the logical drives.

SLOTID

Apply the configuration based on Slot ID instead of Device ID.

Examples

```
ARCCONF PLAYCONFIG server1_config.xml playconfig.log FORCE ALL
```

2.28 arccnf preservcache

Description

Toggles the controller's cache preservation policy; clears the preserved cache for one or more logical drives; and lists the logical drives with cache preservation enabled.

This command preserves the controller's DDR cache to prevent data loss in the event of a power failure or unsafe shutdown. "Dirty pages" (data that have not been committed to disk) are restored to the cache when power is restored and the logical drives on the controller are back online. Once the preserved cache is restored, the controller flushes the data to disk using its normal scheduling mechanism. You can clear the preserved dirty cache for one or more logical drives if you expect a failed enclosure or logical drive to remain offline.

Note: You cannot enable maxCache read and/or write caching on a controller with cache preservation enabled. The following operations are not permitted on a controller in the Cache Preserved state:

- Creating a logical drive
- Changing the Performance mode
- Running a consistency check
- Changing the RAID Level of a logical drive
- Forcing a logical drive online or offline
- Changing the cache page size

Syntax

```
ARCCONF PRESERVECACHE <Controller#> <ENABLE|DISABLE>
ARCCONF PRESERVECACHE <Controller#> CLEAR LOGICALDRIVE <LD#|ALL> [noprompt]
ARCCONF PRESERVECACHE LD [LD#]
```

Parameters

Controller#

Controller number.

LD#

The logical drive number. Use ALL to clear preserved dirty cache for all logical drives on the controller.

noprompt

No prompt for confirmation.

Examples

```
ARCCONF PRESERVECACHE 1 ENABLE
ARCCONF PRESERVECACHE 1 CLEAR LOGICALDRIVE ALL
ARCCONF PRESERVECACHE 1 LD 1
```

2.29 **arccnf rescan**

Description

Enables the controller to check for the removal of any disk drives in the ready state and to check for the connection of any new disk drives to the controller. Controller rescan runs in the background, asynchronously. When rescan is started, a message is displayed stating that the process is running in the background and may take 10 minutes to complete. Another message is displayed if a rescan is started while one is already in progress. Rescan status can be obtained with ARCCNF [getstatus](#); see [arccnf getstatus](#) on page 30 for more information.

Note:

When the SMART poll setting is disabled, the rescan will cause physical drives that are in reduced RPM or powered off states to spin up.

Syntax

```
ARCCNF RESCAN <Controller#> [nologs]
ARCCNF RESCAN ALL [nologs]
```

Parameters

Controller#

The controller number

ALL

Rescans all controllers in the system

Examples

```
ARCCNF RESCAN 1
ARCCNF RESCAN ALL
```

2.30 **arccnf resetstatisticscounters**

Description

Resets statistics counters for a controller and the logical and physical devices attached to it. Use this command to clear the counters and create fresh statistics, including (but not limited to):

- Read/Write Request Count
- Sectors Read/Written/Flushed
- Unaligned Reads/Writes
- Avg/Max Request Latency
- Max Queue Depth
- Max Request Latency
- Avg Dirty Cache Lines
- Avg Free Processor Ram
- Avg Locked Stripes
- Command Count

Syntax

```
ARCCONF RESETSTATISTICSCOUNTERS <Controller#>
```

Parameters

Controller#

The controller number

Examples

```
ARCCONF RESETSTATISTICSCOUNTERS 1
```

2.31 arcconf romupdate

Description

Allows new firmware and BIOS to be flashed to the controller. A reboot is required for the new firmware to take effect.

Note:

1. This command is supported on all OSs that support maxView Storage Manager.
2. You can download the .bin .ufi update files from the Support area at www.adaptec.com.
3. You can download the .bin update files at www.pmcs.com/myPMC

Syntax

```
ARCCONF ROMUPDATE <Controller#> <BaseName> [newversion <build#> [force]]  
[noprompt] [nologs]
```

Parameters

Controller#

The controller number.

BaseName

Absolute path to the controller programmable image update file.

Newversion <build#>

Specifies the version of the firmware build.

Force

An optional parameter used to force a down-level firmware update. Valid only if Newversion parameter is specified.

Noprompt

An optional parameter that suppresses the confirmation prompt.

Examples

```
ARCCONF ROMUPDATE 1 /usr/home/AC220001.UFI  
ARCCONF ROMUPDATE 1 /usr/home/AC220001.BIN  
ARCCONF ROMUPDATE 1 C:\firmwareImage\as483c.bin newversion 12345 force noprompt
```

2.32 **arccnf saveconfig**

Description

Note: This command is supported on all OSs that support maxView Storage Manager.

Saves the controller configuration to a XML server template file, including the controller type, operational settings, physical drive size, logical drive size, RAID level, and more. Use this file with the PLAYCONFIG command to deploy the same controller configuration to other servers in your storage space; see [arccnf playconfig](#) on page 36 for more information.

Note: Be sure to check the log file to verify that the configuration XML file was created successfully. The exit codes, shown below, indicate the success or failure of the operation.

Code	Value	Meaning
SUCCESS	0	Configuration XML generated successfully.
FAILURE_GENERAL	1	An error occurred and the configuration XML could not be generated.

Syntax

```
ARCCNF SAVECONFIG [Config XML File] [LogFile]
```

Parameters

Config XML File

The pathname of the server template file. The default name (if you omit this parameter) is C:\PMCS\Logs\saveconfig.xml on Windows operating systems and /var/log/saveconfig.xml on Linux/Unix operating systems.

LogFile

The pathname of the error log file. By default, the error log is available at C:\PMCS\Logs\saveconfig.log on Windows operating systems and /var/log/saveconfig.xml on Linux/Unix operating systems.

Examples

```
ARCCNF SAVECONFIG server1_config.xml C:\LOGS\SERVER1.LOG
```

2.33 **arccnf savesupportarchive**

Description

Saves configuration and status information to help Adaptec Customer Support diagnose a problem with your system. Saved information includes device logs, drive logs, event logs, error logs, controller logs, history logs, basecode logs, and SSD SMART statistics. (For more information about SMART statistics, see [arccnf getsmartstats](#) on page 30.)

By default, the log files are saved in the Support folder in the standard logs directory for your operating system (/var/log for Linux, the maxView Storage Manager install directory on Windows, and so on).

Note: Unlike the Save Support Archive feature in maxView Storage Manager, this command does not create a zip (“archive”) file. It simply saves the support files and logs in the Support folder.

Note:

When the SMART poll setting is disabled, Save Support Archive will cause physical drives that are in reduced RPM or powered off states to spin up.

Syntax

```
ARCCONF SAVESUPPORTARCHIVE [Path]
[Firmware|GUI|CIM|Arccconf|Storlib|Agent|Basecode]

ARCCONF SAVESUPPORTARCHIVE [Path] [Firmware|Arccconf|Storlib|Basecode]
```

Parameters**Path**

Path to store the log files.

Log type:

One of these log files:

- Firmware: saves Firmware logs
- GUI: saves GUI logs
- CIM: saves CIM logs
- Arccconf: saves Arccconf logs
- Storlib: saves StorLib logs
- Agent: saves Agent logs
- Basecode: saves basecode logs

Examples

```
ARCCONF SAVESUPPORTARCHIVE
ARCCONF SAVESUPPORTARCHIVE Firmware
ARCCONF SAVESUPPORTARCHIVE /var/log/maxView Storlib
```

2.34 arccconf seeprom

Description

Updates the SEEPROM on the controller.

Syntax:

```
ARCCONF SEEPROM <Controller#> UPDATE [noprompt] [nologs]
```

Parameters**Controller#**

Controller number.

Noprompt

Optional parameter that suppresses the confirmation message.

Nologs

Optional parameter that suppresses log output.

Examples

```
ARCCONF SEEPROM 1 UPDATE
```

2.35 **arccnf setalarm**

Description

Sets the state of the controller audible alarm, if present.

Syntax

```
ARCCNF SETALARM <Controller#> <on|off|silence|test>
```

Parameters

Controller#

The controller number

On

Enables the alarm

Off

Disables the alarm

Silence

Quiets the currently sounding alarm

Test

Triggers the alarm

Examples

```
ARCCNF SETALARM 1 TEST
ARCCNF SETALARM 1 SILENCE
```

2.36 **arccnf setbiosparams**

Description

Changes select BIOS settings, including:

- Array BBS support (BIOS Boot Specification)
- Runtime BIOS mode
- Drives displayed on POST
- Backplane mode
- Missing drive count

The command sub-functions are mutually exclusive; you can set only one option at a time.

Syntax

```
ARCCNF SETBIOSPARAMS <Controller#> RUNTIMEBIOS [enable | disable]
ARCCNF SETBIOSPARAMS <Controller#> ARRAYBBSUPPORT [enable | disable]
ARCCNF SETBIOSPARAMS <Controller#> DISPLAYEDONPOST [enable | disable]
ARCCNF SETBIOSPARAMS <Controller#> BACKPLANEMODE <mode>
ARCCNF SETBIOSPARAMS <Controller#> BIOSHALTONMISSINGDRIVECOUNT <count>

ARCCNF SETBIOSPARAMS <Controller#> POSTPROMPTTIMEOUT <timeout>
```

Parameters

Controller#

Controller number

Subfunction

Option	Description
RUNTIMEBIOS [enable disable]	When enabled, allows the controller to act as a bootable device. When disabled, allows another controller to act as a bootable device. Default is enable .
ARRAYBBSUPPORT [enable disable]	When enabled in systems that support BBS, the controller presents attached bootable devices up to the BIOS for boot device selection. Default is disable .
DISPLAYEDONPOST [enable disable]	When enabled, connected disk drives are displayed during system Power On Self Test (POST). Displaying the disk drives adds a few seconds to the overall POST time. Default is disable .
BACKPLANEMODE <mode>	Sets the backplane mode to 0-IBPI, 1-SGPIO, or 3-Disabled. Default is IBPI .
BIOSHALTONMISSINGDRIVE-COUNT <count>	The number of missing drives during POST. If => "count", halt. Count can have a value between 1-255; default is 8.
POSTPROMPTTIMEOUT <timeout>	Changes the F1/F2 POST prompt timeout for the controller during system boot. Timeout can have a value between 1-255.

Examples

```
ARCCONF SETBIOSPARAMS 1 RUNTIMEBIOS disable
ARCCONF SETBIOSPARAMS 1 BACKPLANEMODE 1
ARCCONF SETBIOSPARAMS 1 BIOSHALTONMISSINGDRIVECOUNT 5
ARCCONF SETBIOSPARAMS 1 ARRAYBBSUPPORT enable
ARCCONF SETBIOSPARAMS 1 POSTPROMPTTIMECOUNT 10
```

2.37 arconf setboot

Description

Sets the controller as a boot device for the system. This command is available only when the controller is offline.

Syntax

```
ARCCONF SETBOOT <Controller#> LOGICALDRIVE <LogicalDrive#> [TYPE <Boot Type>]
[nologs]
ARCCONF SETBOOT <Controller#> DEVICE <Channel# ID#> TYPE <Boot Type> [nologs]
ARCCONF SETBOOT <Controller#> ENABLE

ARCCONF SETBOOT <Controller#> DEVICE <Channel# ID#> TYPE <Boot Type> [nologs]
ARCCONF SETBOOT <Controller#> ENABLE
```

Parameters

Controller#

Controller number

LogicalDrive#

Logical drive number to mark as the boot device

Channel# ID#

Channel and ID of the physical device to mark as the boot device

TYPE <Boot Type>

Boot type of the logical or physical device:

- Primary - Primary boot logical/physical device
- Secondary - Secondary boot logical/physical device
- None - Non-bootable

ENABLE

Sets the controller as a boot controller

Examples

```
ARCCONF SETBOOT 1 LOGICALDRIVE 0 TYPE primary
ARCCONF SETBOOT 1 DEVICE 0 5 TYPE secondary
ARCCONF SETBOOT 1 ENABLE
```

2.38 arccnf setcache

Description

Changes the cache mode for a logical drive, or the write cache mode for all drives or a single physical drive on a controller.

Syntax

```
ARCCONF SETCACHE <Controller#> LOGICALDRIVE <LogicalDrive#> <logical mode>
[noprompt] [nologs]
ARCCONF SETCACHE <Controller#> DEVICE <Channel> <ID> <physical mode> [nologs]
ARCCONF SETCACHE <Controller#> DEVICEALL <policy> [noprompt] [nologs]

ARCCONF SETCACHE <Controller#> LOGICALDRIVE <LogicalDrive#> <logical mode>
[noprompt] [nologs]
ARCCONF SETCACHE <Controller#> DEVICEALL <policy> [noprompt] [nologs]
ARCCONF SETCACHE <Controller#> CACHERATIO <read#> <write#>
ARCCONF SETCACHE <Controller#> WAITFORCACHEROOM <enable | disable>
ARCCONF SETCACHE <Controller#> NOBATTERYWRITECACHE <enable | disable>
```

Parameters

Controller#

The controller number

LogicalDrive#

The number of the logical drive whose cache will be altered

Logical mode

Logical drive cache mode:

- RON - read cache on
- ROFF - read cache off
- WT - write through disabled
- WB - write back enabled
- WBB - write back enabled (when protected by battery or flash backup module)
- con - cache enabled
- coff - cache disabled

Channel/ID

Lists the space-delimited channel number and device number pairs for each device.

Physical mode

- WT - write through disabled

- WB - write back enabled

Policy

- Enable - write back for all physical drives
- Disable - write through for all physical drives
- drivespecific - set policy for individual physical drives

CACHERATIO <read#> <write#>

Sets the cache ratio for the controller:

- read# - Read cache percentage
- write# - Write cache percentage

WAITFORCACHEROOM

Wait for room in the read/write cache when full instead of automatically bypassing it in favor of higher performance. Enabling this feature prevents RAID 1 inconsistencies that occur whenever the host changes buffer contents during write operations.

- Enable - wait for room in the read/write cache
- Disable - do not wait for room in the read/write cache

NOBATTERYWRITECACHE

Enables write caching when a battery or supercapacitor is not present or fully charged. This setting applies to all logical drives on the controller; at least one logical drive must exist before usage.

- Enable - enable write caching on controller without fully charged battery or supercapacitor
- Disable - disable write caching on controller without fully charged battery or supercapacitor

Caution: Enabling write caching without a fully charged battery/supercapacitor may cause data loss in the event of a power failure.

Examples

```
ARCCONF SETCACHE 1 LOGICALDRIVE 1 RON
ARCCONF SETCACHE 1 DEVICE 0 0 WB
ARCCONF SETCACHE 1 DEVICEALL Enable
ARCCONF SETCACHE 1 CACHERATIO 60 40
ARCCONF SETCACHE 1 WAITFORCACHEROOM enable
ARCCONF SETCACHE 1 NOBATTERYWRITECACHE enable
```

2.39 arccnf setconfig

Description

Resets the controller configuration. Logical drives are deleted, hard disks are reset to the READY state, cache contents are lost, and controller settings are reset to default values.

Syntax

```
ARCCONF SETCONFIG <Controller#> DEFAULT [noprompt]
```

Parameters

Controller#

The controller number

Default

Restores the controller's default configuration.

Noprompt

No prompt for confirmation.

Examples

```
ARCCONF SETCONFIG 1 DEFAULT
```

2.40 **arccnf setcontrollermode**

Description

Sets the controller operating mode to any of the following:

- **RAID: Expose RAW (default)**—All RAID functions of the controller are enabled. Attached drives without Microsemi Adaptec meta-data are surfaced to the host operating system as RAW Pass Through devices (similar to JBODs on legacy Adaptec controllers).
- **Auto Volume Mode**—Attached drives without Microsemi Adaptec meta-data, but with an OS partition, are surfaced to the host operating system as RAW devices, where the RAID layer of the controller firmware is bypassed when the host issues commands to the device. Attached drives without Microsemi Adaptec meta-data and without OS partitions, are automatically configured as Simple Volumes (single drives with Microsemi Adaptec meta-data), with these settings:
 - Controller read caching is set to “Enabled” for rotating media.
 - Controller write caching is set to “Enabled (write-back) when protected by battery/ZMM” for rotating media.
 - Caching for non-rotating media is disabled.

In Auto Volume Mode, you can create up to a maximum of 128 Simple Volumes; no other RAID types are supported.

Note: Before you can change to Auto Volume mode, you must delete redundant RAID arrays, maxCache Devices, and hot spare drives (if any).

Auto-Volume Mode enables DRAM caching on rotating media to help reduce latency and accelerate performance, especially if combined with a custom performance mode, such as Big Block Bypass (see [arccnf setperform](#) on page 51 for more information).

- **HBA Mode**—The intent of this mode is to allow the RAID controller to act and be used as a Host Bus Adapter. All attached drives are surfaced as RAW devices. Changing into HBA mode is allowed only if there are no drives with Microsemi Adaptec meta-data attached to the controller. Uninitialize the drives before changing to HBA mode (see [arccnf uninit](#) on page 59). Uninitialized drives are also compatible with any HBA and can be exchanged with drives on the motherboard's SATA interface.

Note:

1. Before you can change to HBA mode, you must delete existing hot spare drives (if any).
2. In HBA mode, a hot-plugged drive is automatically configured as a RAW device. When a RAW device is pulled from the system, the controller does not delete internal data structures associated with the drive. However, the missing RAW device is not remembered across rescans.

- **RAID: Hide RAW**—All RAID functions of the controller are enabled, but RAW devices are not exposed to the operating system.
- **Simple Volume Mode**—Allows you to create Simple Volumes only, up to a maximum of 128 volumes; no other RAID types are supported.

Note: Before you can change to Simple Volume mode, you must delete existing RAID arrays, maxCache Devices, and hot spare drives (if any).

- **Smart HBA Mode**—RAID volumes and RAW (unconfigured) devices are exposed to the operating system.

Syntax:

```
ARCCONF SETCONTROLLERMODE <Controller#> <Controller Mode> [nologs]
```

Parameters

Controller#

Controller number.

Controller Mode

One of the following values:

- 0 - RAID: Expose RAW
- 1 - Auto Volume Mode
- 2 - HBA Mode
- 3 - RAID: Hide RAW
- 4 - Simple Volume Mode
- 5 - Smart HBA Mode

nologs

Suppresses log output for the command.

Examples

```
ARCCONF SETCONTROLLERMODE 1 2
ARCCONF SETCONTROLLERMODE 1 0
ARCCONF SETCONTROLLERMODE 1 4
ARCCONF SETCONTROLLERMODE 1 5
```

2.41 **arccnf setcontrollerparam**

Description

Changes a parameter of a controller.

Syntax

```
ARCCONF SETCONTROLLERPARAM <Controller#> SMARTPOLL <Enable | <Disable Raw>>
[nologs] [noprompt]
```

Parameters

Controller#

The controller number.

SMARTPOLL

Configure SMART poll setting on the controller.

- Disable Raw: Disable SMART poll for RAW physical drives only.
- Enable : Enable SMART poll for RAW physical drives only.

Examples

```
ARCCONF SETCONTROLLERPARAM 1 SMARTPOLL DISABLE RAW
```

2.42 **arcconf setcustommode**

Description

Sets the parameters for a user-defined performance mode. Contact Microsemi Adaptec Support for more information about using this command to set up a custom performance mode. See also [arcconf setperform](#) on page 51.

Syntax

```
ARCCONF SETCUSTOMMODE <Controller#> ENABLE <Flag1> [Flag2 ... ] [DISABLE Flag1
Flag2 ...] [PARAMS <Field1 Value1> [Field2 Value2] ..] [nologs]
ARCCONF SETCUSTOMMODE <Controller#> DISABLE <Flag1> [Flag2 ... ] [nologs]
ARCCONF SETCUSTOMMODE <Controller#> PARAMS <Field1 Value1> [Field2 Value2] ..
[nologs]
ARCCONF SETCUSTOMMODE <Controller#> FILE [File name] [nologs]
```

Parameters

Controller#

Controller number

ENABLE <Flag>, DISABLE <Flag>

A list of flags to enable or disable:

- REPPREFET (CACHE_REPRESSPREFETCHING)
- IOSORT (CACHE_IO_SORTING)
- INSLRU (CACHE_INSERT_LRU)
- DYNSHARE (CACHE_DYNAMIC_SHARING)
- RLOADBYPASS (CACHE_READ_LOAD_BYPASS_VALID)
- WLOADBYPASS (CACHE_WRITE_LOAD_BYPASS_VALID)
- WRITEBYPASS (CACHE_LARGE_WRITE_BYPASS)
- IOCOAL (IO_COALESCING)

PARAMS

A list of field/value pairs:

- MAXDIRTY (CACHE_MAX_DIRTY)
- DMDFLUSHTHR (CACHE_DEMAND_FLUSH_THRESHOLD)
- PAGESIZE (CACHE_PAGE_SIZE)
- RFINACTIVE (CACHE_RESERVED_FOR_INACTIVE)
- ADDWRITES (CACHE_ADDITIONAL_WRITES)
- MINFLUSHSTRIPE (CACHE_MIN_FLUSH_STRIPE)
- BYPASSWRIOSSIZE (CACHE_BYPASS_WRITE_IO_SIZE)
- IOLIMSASHDD (IO_LIMIT_SAS_HDD)
- IOLIMSASSSD (IO_LIMIT_SAS_SSD)
- IOLIMSATAHDD (IO_LIMIT_SATA_HDD)
- IOLIMSATASSD (IO_LIMIT_SATA_SSD)

FILE <File name>

Path to parameter definition file. The default parameter file is `PerformanceMde.cfg`.

Examples

```
ARCCONF SETCUSTOMMODE 1 ENABLE IOSORT DISABLE INSLRU
ARCCONF SETCUSTOMMODE 1 DISABLE REPPREFET
ARCCONF SETCUSTOMMODE 1 PARAMS PAGESIZE 3
ARCCONF SETCUSTOMMODE 1 FILE C:\Adaptec
```

2.43 arconf setmaxcache

Description

Enables/disables maxCache SSD caching for one or more logical drives; updates the maxCache write cache policy and “dirty page” threshold (data not committed to disk); adds Solid State Drives to the maxCache pool and removes SSDs from the pool; sets the maxCache read/write balance and cache fetch/flush rate; clears the maxCache pool.

Note: Before you can enable maxCache SSD caching, you must assign at least one SSD to the maxCache pool.

Syntax: Read Caching

```
ARCCONF SETMAXCACHE <Controller#> LOGICALDRIVE <LogicalDrive#> READCACHE
<ENABLE|DISABLE>
```

Syntax: Write Caching

```
ARCCONF SETMAXCACHE <Controller#> LOGICALDRIVE <LogicalDrive#> WRITECACHE
<ENABLE|DISABLE> [WRITEPOLICY <policy>]
ARCCONF SETMAXCACHE <Controller#> LOGICALDRIVE ALL WRITECACHE DISABLE
[WRITEPOLICY <policy>]
ARCCONF SETMAXCACHE <Controller#> LOGICALDRIVE <LogicalDrive#> WRITEPOLICY
<policy>
ARCCONF SETMAXCACHE <Controller#> DIRTYPAGETHRESHOLD <dirtyPageThreshold#>
ARCCONF SETMAXCACHE <Controller#> WBCVALID <ENABLE|DISABLE>
```

General Usage

```
ARCCONF SETMAXCACHE <Controller#> <ADDTOPPOOL|REMOVEFROMPOOL> <Channel# Device#>
ARCCONF SETMAXCACHE <Controller#> RWBALANCE <Read#> <Write#>
ARCCONF SETMAXCACHE <Controller#> FLUSHANDFETCHRATE <FlushAndFetchRate#>
ARCCONF SETMAXCACHE <Controller#> CLEAR
```

Parameters

Controller#

The controller number.

LogicalDrive#

The number of the logical drive. You can specify one or more logical drives.

Channel#

The channel number for the SSD.

Device#

The device number for the SSD.

Read#/Write#

The read/write ratio for invalidating data on the SSD. When the ratio is reached, the page is removed from the cache. Values range from 1-10 for each parameter.

FlushAndFetchRate#

The read cache fetch rate from 1 to 1000: 1-50=Low, 51-100=Medium, 101-1000=High. The default is 100.

Note: The lower the rate the longer the page is kept on the SSD before it is flushed from the cache.

dirtyPageThreshold#

Controls the amount cache space allocated to “dirty” data; that is, data that has not been committed to disk. The threshold value ranges from 1-100 (percent). Once the percentage of dirty pages crosses the threshold, the data are flushed to disk.

WBCVALID ENABLE | DISABLE

Enables and disables write caching in non-redundant maxCache. Applies to all logical drives.

Policy

maxCache write cache policy:

- WB - write back enabled. maxCache will store the data on the SSD and write it back to the hard disks when there is little or no impact on performance. This is the default policy.
- INSTWB - instant write back enabled. In addition to the default policy, maxCache will create dirty pages on-the-fly for full-stripe writes if there is room on the SSD and the number of dirty pages is below the threshold.
- WT - write through enabled. Similar to instant write back, but full-stripe writes go to both the cache and hard disk and no dirty pages are created on-the-fly.

Clear

Clears the maxCache pool.

Examples

```
ARCCONF SETMAXCACHE 1 LOGICALDRIVE 1 READCACHE ENABLE
ARCCONF SETMAXCACHE 1 LOGICALDRIVE 1 WRITECACHE ENABLE WRITEPOLICY WT
ARCCONF SETMAXCACHE 1 DIRTYPAGETHRESHOLD 50
ARCCONF SETMAXCACHE 1 ADDTOPPOOL 0 1
ARCCONF SETMAXCACHE 1 REMOVEFROMPOOL 0 1 0 2
ARCCONF SETMAXCACHE 1 RWBALANCE 4 1
ARCCONF SETMAXCACHE 1 FLUSHANDFETCHRATE 200
ARCCONF SETMAXCACHE 1 CLEAR
```

2.44 arconf setname

Description

Renames a logical drive.

Syntax

```
ARCCONF SETNAME <Controller#> LOGICALDRIVE <LogicalDrive#> <New Name>
```

Parameters

Controller#

Controller number

LogicalDrive#

The number of the logical drive to be renamed

New Name

The new name of the logical drive

Examples

```
ARCCONF SETNAME 1 LOGICALDRIVE 1 BACKUP_A
```

2.45 **arccnf setncq**

Description

Changes the controller's Native Command Queuing (NCQ) setting to enabled or disabled. This setting affects the SATA disk drives on the controller. It takes effect when the SATA drives are restarted.

Syntax

```
ARCCNF SETNCQ <Controller#> ENABLE|DISABLE
```

Parameters

Controller#

The controller number

Examples

```
ARCCNF SETNCQ 1 ENABLE
```

2.46 **arccnf setperform**

Description

Changes controller settings based on the application type.

Syntax

```
ARCCNF SETPERFORM <Controller#> <Performance Mode> [nologs]
ARCCNF SETPERFORM <Controller#> MNPDELAY <Delay> [no logs]
ARCCNF SETPERFORM <Controller#> DPO <Enable | Disable> [no logs]
```

Parameters

Controller#

The controller number

Performance Mode

Setting	Behavior
1 (DYNAMIC/Default)	Performance criteria adjusts automatically based on controller usage, RAID level, and disk drive type.
2 (OLTP/Database)	Performance criteria is optimized for transaction-oriented applications such as data entry and retrieval.
3 (Big Block Bypass)	DRAM write cache is bypassed based on IO write size; performance is optimized for serving Web pages and retrieving data.
4 (User-Defined)	User-defined performance mode. See arccnf setcustommode on page 48.

MNPDELAY <Delay>

Sets the monitor and performance delay for the controller, in seconds. Default is 60 minutes (3600 seconds).

DPO

Enables or disables the degraded performance setting for the controller. Default is disabled.

Examples

```
ARCCONF SETPERFORM 1 2
ARCCONF SETPERFORM 1 3
ARCCONF SETPERFORM 1 MNPDELAY 1800
ARCCONF SETPERFORM 1 DPO enable
```

2.47 **arccnf setphy**

Description

Sets the maximum connection speed for SAS devices to 6Gb/s or 12Gb/s.

Syntax

```
ARCCONF SETPHY <Controller#> MAXSASPHYLINKRATE <MaxSASPhylinkrate#> [noprompt]
[nologs]
```

Parameters

Controller#

The controller number

MaxSASPhylinkrate#

The Phy link rate. Valid values are 6 and 12 (for 6Gb/s and 12Gb/s, respectively).

Noprompt

No prompt for confirmation.

Examples

```
ARCCONF SETPHY 1 MAXSASPHYLINKRATE 6
ARCCONF SETPHY 1 MAXSASPHYLINKRATE 12
```

2.48 **arccnf setpower**

Description

Changes power management settings for disk drives on a controller or logical drive.

Syntax

```
ARCCONF SETPOWER <Controller#> Stayawake DISABLE | <starttime> <endtime> [DAYS] [nologs]
ARCCONF SETPOWER <Controller#> Spinup <internal#> <external#>
ARCCONF SETPOWER <Controller#> LD <LD#> <disable> | [slowdown st#] | [poweroff pt#] |
[verify vt#]> [nologs]
```

```
ARCCONF SETPOWER <Controller#> POWERMODE <mode>
```

Parameters

Controller#

The controller number

Stayawake

Sets the stayawake period for the disk drives on the controller. During the stayawake period, the disk drives always operate at their peak spin rate.

Disable

Is a keyword that disables the stayawake period for the disk drives on a controller.

starttime

Specifies the beginning of the stayawake period, in the form HHMM (24-hour format)

endtime

Specifies the end of the stayawake period, in the form HHMM (24-hour format).

DAYS

Days of the week on which the stayawake period is enabled; default is all days.

Spinup

Sets the spin-up limits for the controller—the maximum number of drives that the controller may spin up at one time.

internal#

The maximum number of internal drives that the controller may spin up at one time, from 0-20.

external#

The maximum number of external drives (such as the drives in a JBOD) that the controller may spin up at one time, from 0-20.

LD#

The logical drive number.

Slowdown st#

Sets the disk drive slow-down timer, in minutes. Valid values are 0 (never), 3, 5, 10, 20, 30, 60, 120, 180.

Poweroff pt#

Sets the disk drive power-off timer, in minutes. Valid values are 0 (never), 3, 5, 10, 20, 30, 60, 120, 180.

Verify vt#

Sets the period of inactivity, in hours, after which an inactive drive (a drive that's already powered down) is restarted to verify its operating condition. Once the check is completed, the drive is powered down and returns to its inactive state. Valid values are 0 (never), 1, 2, 3, 8, 12, 24.

Note: For the Slowdown, Poweroff, and Verify timers, st# must be less than pt#, and pt# must be less than vt#. You can set one or more timers, in any order, in a single command. Keep in mind that the Verify timer, vt#, is specified in hours; the other two timers are specified in minutes.

mode

Sets the power mode for the controller. Valid values are 1, 2, and 3:

- 1: Minimum power - Set static settings to lowest possible values and reduces dynamically based on workload
- 2: Balanced - Set static settings based on configuration and reduce dynamically based on workload
- 3: Maximum power - Set static settings to highest possible values and do not reduce dynamically

Examples

```
ARCCONF SETPOWER 1 STAYAWAKE DISABLE
ARCCONF SETPOWER 1 SPINUP 4 4
ARCCONF SETPOWER 1 LD 2 POWEROFF 60
ARCCONF SETPOWER 1 LD 2 SLOWDOWN 20 POWEROFF 60 VERIFY 12
ARCCONF SETPOWER 1 POWERMODE 2
```

2.49 **arccconf setpriority**

Description

Changes a task's execution priority or a controller's global background task priority.

Syntax

```
ARCCONF SETPRIORITY <Controller#> [TASK ID] <New Priority> [current]
ARCCONF SETPRIORITY <Controller#> <REBUILD|EXPAND> <New Priority>
```

Parameters

Controller#

The controller number

Task ID

Task ID is the number of the task to be changed. Use `arccconf getstatus` to obtain the task ID. Omit this parameter to set the controller's global background task priority; that is, the execution priority for all tasks on the controller.

New Priority

LOW, MEDIUM, or HIGH. For REBUILD only: MEDIUMHIGH (if rapid rebuild priority is supported on the controller).

Current

Applies a global task priority change to running tasks. By default, a global priority change does not apply to running tasks.

REBUILD

Sets the controller's rebuild priority.

EXPAND

Sets the controller's capacity expansion (OCE) priority.

Examples

```
ARCCONF SETPRIORITY 1 <task_id> HIGH
ARCCONF SETPRIORITY 1 LOW CURRENT
ARCCONF SETPRIORITY 1 EXPAND LOW
SETPRIORITY 1 REBUILD MEDIUM
```

2.50 **arccconf setstate**

Description

Changes the state of a physical device or logical device from its current state to the designated state.

Syntax

```
ARCCONF SETSTATE <Controller#> DEVICE <Channel#> <Device#> <State> [MAXCACHE]
[LOGICALDRIVE <LD#>[LD#] ... ] [noprompt]
ARCCONF SETSTATE <Controller#> LOGICALDRIVE <LD#> OPTIMAL [ADVANCED <option>]
[noprompt]

ARCCONF SETSTATE <Controller#> DEVICE <Channel#> <Device#> <State> [ARRAY
<AR#>] [noprompt] [nologs]
```

```
ARCCONF SETSTATE <Controller#> LOGICALDRIVE <LD#> OPTIMAL [ADVANCED <option>]
[noprompt]

ARCCONF SETSTATE <Controller#> DEVICE <Channel#> <Device#> <State> [noprompt]
```

Syntax

```
ARCCONF SETSTATE <Controller#> DEVICE <Channel#> <Device#> <State> [LOGICALDRIVE
<LD#>[LD#] ... ] [noprompt]
ARCCONF SETSTATE <Controller#> LOGICALDRIVE <LD#> OPTIMAL [ADVANCED <option>]
[noprompt]
```

Parameters

Controller#

The controller number

Channel#

The channel number for the drive.

Device#

Device number for the device.

LD#

Logical drive number.

AR#

Array number.

State

- HSP—Create a hot spare from a ready drive. Dedicates the HSP to one or more arrays logical devices.
- RDY—Remove a hot spare designation. Attempts to change a drive from Failed to Ready. To remove a dedicated HSP from one or more logical devices, use the optional LOGICALDRIVE <LD#> ... parameter.
- DDD—Force a drive offline (to Failed).
- EED—Enable the erased drive.

MAXCACHE

Optional keyword for maxCache devices only. Include if State is HSP or RDY, and the hot spare is for a maxCache device.

ADVANCED <option>

Optional keyword/option pair. Set option to Nocheck to force a logical drive to the Optimal state without performing a consistency check.

Caution: Using Advanced options may result in data loss!

Noprompt:

No prompt for confirmation.

Examples

```
ARCCONF SETSTATE 1 DEVICE 0 0 HSP LOGICALDRIVE 1 2 3
ARCCONF SETSTATE 1 DEVICE 0 0 RDY LOGICALDRIVE 2
ARCCONF SETSTATE 1 LOGICALDRIVE 1 OPTIMAL ADVANCED nocheck
ARCCONF SETSTATE 1 DEVICE 0 0 DDD
ARCCONF SETSTATE 1 DEVICE 0 0 RDY
ARCCONF SETSTATE 1 DEVICE 0 0 HSP ARRAY 0
```

2.51 **arconf setstatsdatacollection**

Description

Enables or disables statistics collection for a controller. To display the statistics, see [arconf getlogs](#) on page 28 .

Syntax

```
ARCCONF SETSTATSDATACOLLECTION <Controller#> Enable|Disable
```

Parameters

Controller#

The controller number

Enable

Turns statistics collection on.

Disable

Turns statistics collection off.

Examples

```
ARCCONF SETSTATSDATACOLLECTION 1 ENABLE
```

2.52 **arconf setvmcredential**

Description

Resets the Hypervisor login credentials for VMware Guest OSs running Remote ARCCONF.

Note: This command is available for VMware Guest OSs running Remote ARCCONF only.

Syntax

```
SETVMCREDENTIAL <Esxip> <Esxcimomport> <Esxuserid> <Esxpassword> [noprompt]
```

Parameters

Esxip

Hypervisor IP address.

Esxcimomport

Hypervisor CiMOM port number.

Esxuserid

Hypervisor user name.

Esxpassword

Hypervisor password.

Examples

```
ARCCONF SETVMCREDENTIAL 172.18.46.101 5989 root passwd
```

2.53 **arccconf smp**

Description

Sends a SAS Management Protocol (SMP) function request to a SMP target device.

Syntax:

```
ARCCONF SMP <Controller#> Enclosure <Connector# Channel# Device#> Expander
<Expander#> <CommandType1> [ASCII]
ARCCONF SMP <Controller#> Enclosure <Connector# Channel# Device#> Expander
<Expander#> <CommandType2 PHY#> [ASCII]
```

Parameters

Controller#

Controller number.

Connector# Channel# ID#

Connector ID, Channel ID and Device ID of the enclosure that contains the expander.

Expander#

Expander number on the controller (SMP target device).

PHY#

The PHY Identifier (valid only for Discover and PHY Error Log Request).

CommandType#

CommandType1:

- RGR - Report General Request
- RMR - Report Manufacturer Request

CommandType2:

- DR - Discover Request
- RPELR - Report PHY Error Log Request

ASCII

Displays the SMP response in ASCII format along with Hex formatted output.

Examples

```
ARCCONF SMP 1 Enclosure 1 2 0 Expander 0 RGR
ARCCONF SMP 1 Enclosure 1 2 0 Expander 1 DR 0
```

2.54 **arccconf task**

Description

Performs a task on a logical drive, physical drive, or maxCache logical device. Uninitializes physical drives on a controller.

Syntax: General Usage

```
ARCCONF TASK
TASK START <Controller#> LOGICALDRIVE <LogicalDrive#> <options> [noprompt]
TASK STOP <Controller#> LOGICALDRIVE <LogicalDrive#>
TASK START <Controller#> DEVICE <Channel> <ID> <options> [noprompt]
TASK STOP <Controller#> DEVICE <Channel> <ID>
TASK START <Controller#> DEVICE ALL UNINITIALIZE

ARCCONF TASK
TASK START <Controller#> DEVICE <Channel> <ID> <options> [noprompt]
TASK START <Controller#> DEVICE ALL UNINITIALIZE
TASK STOP <Controller#> DEVICE <Channel> <ID>

ARCCONF TASK START <Controller#> DEVICE ALL UNINITIALIZE
```

Syntax: maxCache Usage

```
ARCCONF TASK
TASK START <Controller#> MAXCACHE COHERENCYCHECK [ONCE|ALWAYS]
TASK START <Controller#> MAXCACHE <VERIFY_FIX|VERIFY>
TASK STOP <Controller#> MAXCACHE
```

Parameters

Controller#

The controller number

LogicalDrive#

Number of the logical drive in which the task is to be performed

Options:

- Logical drive options:
 - `verify_fix` (Verify with fix)—verifies the logical drive redundancy and repairs the drive if bad data is found.
 - `verify`—verifies the logical drive redundancy without repairing bad data.
 - `clear`—removes all data from the drive.
- Physical device options:
 - `verify_fix`—verifies the disk media and repairs the disk if bad data is found.
 - `verify`—verifies the disk media without repairing bad data.
 - `clear`—removes all data from the drive.
 - `initialize`—returns a drive to the READY state (erases the metadata).
 - `secureerase` [`password`] [`PATTERN` <pattern>]—removes all data from the drive in a secure fashion to prevent any possible recovery of the erased data. (See [arccconf atpassword](#) on page 17 for details about setting the password.) Erase patterns:
 - 1 : Zero - Initializes all blocks to zero.
 - 2 : Random Zero - Initializes block to random value then zero.
 - 3: Random Random Zero - Initializes block to random value, next block to random value, then zero.
 - `UNINITIALIZE`—When specified with `ALL`, clears Microsemi Adaptec meta-data and any OS partitions from all drives on the controller; existing data on the drive is destroyed.

MAXCACHE options:

- `coherencycheck`—compares valid pages of the maxCache Device with their corresponding logical drive storage. Once is the default.
- `verify_fix` (Verify with fix)—verifies the maxCache Device redundancy and repairs the logical drive if bad data is found.
- `verify`—verifies the maxCache Device redundancy without repairing bad data.

Examples

```
ARCCONF TASK START 1 LOGICALDRIVE 1 VERIFY
ARCCONF TASK START 1 DEVICE 0 0 SECUREERASE <password> PATTERN 1
ARCCONF TASK START MAXCACHE COHERENCYCHECK ONCE
ARCCONF TASK STOP 1 DEVICE 0 0
ARCCONF TASK START 1 DEVICE ALL UNINITIALIZE
```

2.55 **arccnf uninit**

Description

Uninitializes one or more physical drives. The uninitialize command clears Microsemi Adaptec meta-data and any OS partitions from a drive; existing data on the drive is destroyed. Drives can be uninitialized only if they are in the Raw or Ready state (that is, not part of any logical drive). A drive in the Raw state has no Microsemi Adaptec meta-data but may or may not have an OS partition.

Note: Uninitialized drives are compatible with any HBA and can be exchanged with drives on the motherboard's SATA interface. For more information about uninitialized devices, see [arccnf setcontrollermode](#) on page 46.

Syntax:

```
ARCCONF UNINIT <Controller#> <Channel# Drive#> [Channel# Drive#] ... [nologs]
ARCCONF UNINIT <Controller#> ALL [nologs]
```

Parameters

Controller#

Controller number.

Channel#

The channel number of the device to be uninitialized.

Drive#

The drive number of the device to be uninitialized.

ALL

Uninitializes all physical devices on the controller.

nologs

Suppresses log output for the command.

Examples

```
ARCCONF UNINIT 1 0 12 0 13
ARCCONF UNINIT 1 ALL
```

2.56 **arccnf verifywrite**

Description

Enables or disables the verify write feature on the controller.

Syntax

```
ARCCONF VERIFYWRITE <Controller#> <ENABLE | DISABLE> [nologs]
```

Parameters

Controller#

The controller number.

ENABLE

Enables verify write feature.

DISABLE

Disables verify write feature.

Examples

```
ARCCONF VERIFYWRITE 1 ENABLE
ARCCONF VERIFYWRITE 1 DISABLE
```

A getconfig Output Summary

Table 3 • getconfig output summary

getconfig Command Field	Description	Possible Values/Units
Controller status	Overall status of the controller based on its resources.	optimal,failed,passive,removed,Signature error,inaccessible,Down,driver update required
Controller mode	Mode of the controller on which it is operating.	RAID(Expose RAW),Auto Volume, HBA,RAID(Hide RAW),Simple Volume, SmartHBA
Controller Cache Preservation	Data on DRAM of controller can be preserved.	Enabled, Disabled
Channel description	Technology type of the channel(s) on the specified controller.	SCSI,SATA,SAS,IDE,FIBRE,SATA_ON_SAS
Controller Model	Model number of the controller.	n/a
Controller Serial Number	Serial number of the controller.	n/a
Controller World Wide Name	Unique World Wide Name of the controller.	n/a
Controller Alarm	The state of the alarm on the controller.	Not available,Enabled,Disabled,Unknown
Physical Slot	Slot number of this controller	n/a
Temperature	Current temperature of the controller	degree Celsius and degree Fahrenheit
Installed Memory	Memory capacity of DRAM installed on controller .	Memory in MB
Global task priority	The execution priority for all tasks running on the controller	Low,Medium,High
Performance Mode	An application-specific performance mode to improve I/O throughput based on the needs of your application.	Dynamic,OLTP/Database,DataCenter, User Defined
Host Bus type	Type of host expansion bus standard	Unknown,PCI,PCI-X,PCIE,NA
Host Bus Speed	Speed of host expansion bus standard in MHz	n/a
Host bus link width	Actual width bits /links depending on host bus type	n/a
Stayawake Period	The period during which disk drives on the controller always operate at their peak spin rate.	n/a
Spinup limit internal drives	Maximum number of internal disk drives (drives in an enclosure) that the controller may spin-up at the same time.	n/a
Spinup limit external drives	Maximum number of external disk drives (drives in an enclosure) that	n/a

getconfig Command Field	Description	Possible Values/Units
	the controller may spin-up at the same time.	
Defunct disk drive count	Number of dead drives connected to the controller.	n/a
Logical devices/Failed/Degraded	The number of logical devices on the controller, number of failed logicals and number of degraded logical on the controller.	n/a
NCQ status	Lets SATA disk drives arrange commands into the most efficient order for optimum performance	Enabled, Disabled
Statistics data collection mode	Whether the statistics collection on the controller .The stats can be seen by arconf getlogs command is enabled or not.	Enabled, Disabled
Global Physical Device Write Cache Policy	The write cache policy for all physical drives on a controller	Enable All, Disable All, Drive Specific
Monitor Log Severity Level	The severity level of monitor logs captured from firmware.	Emergency, Alert, Critical, Error, Warning, Notification, Informational, Debug, Unknown
Global Max SAS Phy Link Rate	The maximum connection speed (or PHY link rate) for SAS devices on a controller.	6GBps, 12GBps, Unknown
Smart Poll	SMART poll setting on the controller.	Enabled, Disabled for RAW drives, Unknown
RAID Properties		
Copyback	When a logical drive is rebuilt using a hot spare (see Failed Disk Drive Protected by a Hot Spare), data from the failed drive is transferred to the hot spare	Enabled, Disabled
Background consistency check	Lets maxView Storage Manager continually and automatically checks your logical drives for bad or inconsistent data once they're in use.	Enabled, Disabled
Background consistency check period	The background consistency check period in days	Days
Automatic Failover	Controls the rebuilding of a logical drive when a failed drive is replaced.	Enabled, Disabled
Error Tunable Profile	The current error tunable profile	Aggressive, Normal, Relaxed, User Defined
maxCache flush and fetch rate	To optimize the read cache performance of maxCache container	Valid range is 1 to 1000. 1-50 Low, 51-100 Medium, 101-1000 High
maxCache Read, Write Balance Factor	The read/write ratio is for invalidating data on the SSD. When the ratio is reached, the page is removed from	Valid range is 1 to 10

getconfig Command Field	Description	Possible Values/Units
	the cache. Values range from 1-10 for each parameter.	
maxCache Dirty Page Threshold	Controls the amount cache space allocated to “dirty” data; that is, B105 . The threshold value ranges from 1-100 (percent). Once the percentage of dirty pages crosses the threshold, the data are flushed to disk.	Valid range is 1 to 100
Controller BIOS Setting Information		
Runtime BIOS	Allows the controller to act as a bootable device.	Enabled,Disabled
Array BBS Support	The controller presents attached bootable devices up to the BIOS for boot device selection. This is relevant for logical arrays.	Enabled,Disabled
Physical Drives Displayed during POST	Connected disk drives are displayed during system Power On Self Test (POST). Displaying the disk drives adds a few seconds to the overall POST time.	Enabled,Disabled
Backplane Mode	Adaptec Series 6 Controllers (except Series 6E/6T): When set to Auto, controller automatically detects backplane signal type: I2C or SGPIO. To set the backplane mode explicitly select SGPIO, I2C, or Disabled. Default is Auto. Adaptec Series 7, Series 8, and Series 6E/6T Controllers: When set to Default, controller automatically sets the backplane mode to IBPI. To set the backplane mode explicitly, select IBPI, SGPIO, or Disabled. Default is IBPI.	IBPI,SGPIO,N/A ,Unknown
BIOS Halt on Missing Drive Count	The number of missing drives during POST. If => "count", halt. Default is 8 .	
Controller Version Information		
BIOS	Current version of BIOS flashed onto the controller	n/a
Firmware	Current version of Firmware flashed onto the controller	n/a
Driver	Current version of driver installed on the system	n/a
Boot Flash	Firmware version that will run on re-boot	n/a
CPLD(Load version/Flash Version)	CPLD version that is loaded and that is available in flash	n/a
SEEPROM(Load Version/Flash Version)	SEEPROM version that is loaded and that is available in flash	n/a

getconfig Command Field	Description	Possible Values/Units
Controller Cache Backup Unit Information		
Overall Backup Unit Status	Status of flash backup unit connected to the controller. For more information, see Logical Drive, HDD, and Flash Backup System Status and Error Conditions on page 70.	Not Present,Not Ready,Ready,Failed,Fatal,Preparing,Health Normal,Health Low,Health Dead,Invalid
Backup Unit Type	Type of back up unit connected to the controller or on controller	AFM700/700-LP
Non-Volatile Storage Status	The status of the non volatile storage	Not Present,Not Ready,Ready,Failed,Fatal,Preparing,Health Normal,Health Low,Health Dead,Invalid
Supercap Status	Super cap attached to the backup unit. For more information, see Logical Drive, HDD, and Flash Backup System Status and Error Conditions on page 70.	Not Present,Not Ready,Ready,Failed,Fatal,Preparing,Health Normal,Health Low,Health Dead,Invalid
Current Temperature	Temperature of supercap	degrees Celsius
Threshold temperature	Temperature above which the supercap will become overheated	degrees Celsius
Life -time Temperature Recorded(Min/max)	Life-time min/max temperature recorded	degrees Celsius
Voltage(Present/Max)	Voltage in mV and max voltage in mV	Millivolts (mV)
Life-time Max Voltage Recorded	Life-time max Voltage of BU system	Millivolts (mV)
Current Drawn(Present/Max)	Current Drawn in mA present and max	Millivolts (mV)
Health	Health level of BU system	percentage
Charge level	Charge level of BU system	percentage
Estimated Life-time	Life -time estimate in years and months	n/a
Serial number	Super cap serial number	n/a
Learn Status	Calibration operation run by controller periodically to know status of battery	Not Ready,Idle,Pending,"Active,Scheduled","Active Requested","Active,Manual",Passed,Failed,not Ready,Fatal,Unknown
Next Scheduled Learn Cycle	Time until next schedule learn cycle in hours	Hours
Present Capacitance	Capacitance in Farad	Farad
Connector Information		
Connector Id	Connector number on the controller	n/a
Lane Information		
Channel ID	channel identifier for this lane	n/a
Device ID	device identifier for this lane	n/a

getconfig Command Field	Description	Possible Values/Units
SAS Address	SAS address for this lane	n/a
PHY Identifier	phy identifier for this lane	n/a
Lane SAS Phy Information		
SAS Address	SAS address for this lane SAS Phy	n/a
Attached Phy Identifier	Attached phy identifier for this lane sas phy	n/a
Attached SAS Address	Attached SAS address for the lane sas phy	n/a
Negotiated Link Rate	link rate for the lane SAS phy	n/a
Logical device information		
Logical device number	Unique ID of logical drive listed	n/a
Logical device name	Logical Drive name	n/a
Block Size of member drives	Block size reported by logical member drives.	512 Bytes,4k
RAID level	RAID Level on which logical drive has been created	0,1,1E,5,5E,5EE,00,10,1E0,50,5E0, Spanned Volume,RAID_Volume,Simple_volume,6 XOR,6 Reed-Solomon, 60 XOR,60 Reed- Solomon
Unique Identifier	Unique ID of logical drive	n/a
Status of logical device	State of logical drive based on health of RAID members of logical device along with running task information on the logical. For more information, see Logical Drive, HDD, and Flash Backup System Status and Error Conditions on page 70.	<ul style="list-style-type: none"> • Optimal • Impacted • Failed • Clearing • Logical Device Reconfiguring • Suboptimal, Fault Tolerant • Suboptimal, Reconfiguring • Suboptimal, Rebuilding • Degraded • Degraded, Reconfiguring • Degraded, Rebuilding • Flushing • Does not exist
Size	Size where actual data is striped across the disk drives	n/a
Parity Space	Parity size in logical drive calculated by RAID level specifications.	n/a
Stripe-unit size	The stripe size is the amount of data (in KB) written to one disk drive, before moving to the next disk drive in the logical device.	n/a
Read-cache setting	The controller monitors read access to a logical drive and, if it sees a pattern, pre-loads the cache with data that seems most likely to be read next, thereby improving performance.	Enabled,Disabled

getconfig Command Field	Description	Possible Values/Units
Read-cache status	Whether the read cache setting is on or off	On ,Off
Write-cache setting	Determines when data is stored on a disk drive and when the controller communicates with the operating system.	Enabled,Disabled
Write-cache status	Whether the write cache is enabled, disabled or enabled with backup support	wt,wb,wbw
maxCache write cache status	whether the maxcache write caching is enabled for logical drives or not	On ,Off
Physical Device information		
Device #	Drive number	n/a
State	current state of physical drive based on operations done on it.	Ready,online,Failed,standby,Hots-pare,Rebuilding,Partitioned,Does not Exist,Unsupported,copying back, RAW(Pass through),RAW(Smart HBA), Unknown
Block Size	Maximum size of data block on disk drives which are RAID members of logical device	512KB,4K
Supported	Whether the connected drive is supported by the controller.	Yes,No
Programmed Max Speed	The maximum transfer speed supported by this drive	Basic SCSI,SCSI 2,Fast SCSI 2,Ultra SCSI,Ultra2 SCSI,Ultra 160,Ultra 320, SATA 1.5Gb/s,SATA3.0Gb/s,SATA 6.0Gb/s,SATA12.0Gb/s,SAS 1.5Gb/s, SAS3.0Gb/s,SAS6.0Gb/s,SAS12.0Gb/s,SATA on SAS 1.5Gb/s,SATA on SAS3.0Gb/s,SATA on SAS 6.0Gb/s,SATA on SAS12.0Gb/s,Unknown
Transfer Speed	Negotiated link rate of the device connected	Basic SCSI,SCSI 2,Fast SCSI 2,Ultra SCSI,Ultra2 SCSI,Ultra 160,Ultra 320, SATA 1.5Gb/s,SATA3.0Gb/s,SATA 6.0Gb/s,SATA12.0Gb/s,SAS 1.5Gb/s, SAS3.0Gb/s,SAS6.0Gb/s,SAS12.0Gb/s,SATA on SAS 1.5Gb/s,SATA on SAS3.0Gb/s,SATA on SAS 6.0Gb/s,SATA on SAS12.0Gb/s,Unknown
Reported Channel,Device(T:L)	Virtual path/target/lun for device. Target (T) is the SCSI ID of the device, and LUN (L) corresponds to the SCSI LUN number.	n/a
Reported Location	Location of the connector and device relative to connector	n/a
Vendor	Physical device manufacturer name	n/a
Model	Product model name of physical device	n/a

getconfig Command Field	Description	Possible Values/Units
Firmware	Firmware version of the physical device	n/a
Serial number	Serial number of physical device.	n/a
World wide name	Reported world wide name provided by manufacturer	n/a
Reserved Size	Reserved capacity of the drive	n/a
Used size	Used capacity of the drive	n/a
Unused size	Unused or available capacity of the drive	n/a
Total size	Sum of used,unused capacity of the drive	n/a
Write Cache	The write cache setting determines when data is stored on a disk drive and when the controller communicates with the operating system.	Write back,Write through
S.M.A.R.T	Self-Monitoring, Analysis, and Reporting Technology is supported or not	Yes,No
S.M.A.R.T Warnings	any SMART warning generated or not	Smart event from drive sense data, e.g. code = 0x0B
Power State	The power management options for a controller affect all logical drives on that controller.	Full RPM,Powered off,Reduced RPM
Supported Power States	These are power management states supported by different vendor hard drives	Full RPM,Powered off,Reduced RPM, Standby
SSD	The connected drive is SSD or not	Yes,No
Temperature	The recent temperature of the drive in celsius and fahrenheit.	n/a
NCQ status	Lets SATA disk drives arrange commands into the most efficient order for optimum performance.NCQ status is enabled or not	Enabled,Disabled
Device Phy Information		
PHY Identifier	Phy identifier for this device	n/a
SAS Address	SAS address for the device	n/a
Attached Phy Identifier	Attached phy identifier for this device	n/a
Attached SAS Address	Attached SAS address for this device	n/a
Runtime Error Counters		
Hardware error count	sense key 4 value	n/a
Medium error count	count of the number of medium errors	after drive encounters a medium error, FW will attempt bad block recovery

getconfig Command Field	Description	Possible Values/Units
Parity error count	count of the number of parity errors	SCSI parity error encountered i.e. sense code = 47h . This will also consequently abort a command and increment the respective counter.
Link error count	count of the number of link errors	<ul style="list-style-type: none"> • SMP Response frame received with errors e.g. zero frame size, exceeds max length, missing EOF, len mismatch with FIS type • Link timeout while transmitting frame, IO could not be delivered to drive • Encountered open Reject (Bad/ Wrong Destination) i.e. something is wrong with the topology • Unable to deliver/issue command to drive, break received • LUN reset or I_T nexus reset • Open zone violation i.e. requested phy is not in the same zone as initiator or zoning permissions are invalid • No PHY's in the port or the port itself is down • Encountered DMA transmit error
Aborted command count	count of the number of aborted commands	<ul style="list-style-type: none"> • Disk not accepting commands because format is in progress • A passthrough command received invalid response • Timeout, receiving OPEN_REJECT(Retry) • Open error due to IO abort • A scsi task management command was issued but the response was invalid • Task management response has incorrect LUN • Cannot communicate due to protocol mismatch • Unable to successfully open a connection during the data phase of a command
Smart warning count	count of the number of smart warnings on the device	n/a
maxCache information		
maxCache device number	Always 100 for a maxCache device	n/a
maxCache device name	name of maxCache container	n/a
Block Size of member drives	Block size of SSD constituting the maxCache	512 Bytes,4k,Unknown

getconfig Command Field	Description	Possible Values/Units
maxCache dirty status	Does the maxCache contain dirty data that is data that has not been committed to disk or is it clean	Dirty,Clean
RAID level	RAID level of maxcache	0,1,1E,5,5E,5EE,00,10,1E0,50,5E0,Spanned Volume,RAID_Volume,Simple_volume,6 XOR,6 Reed-Solomon,60 XOR,60 Reed- Solomon
Background Coherency Check	Chooses to verify the maxCache Device without fixing inconsistent or bad data, or run a coherency check to compare valid pages of the max-Cache Device with their corresponding logical drive storage.	Active Always,Inactive,Unknown
Status of maxCache	state of maxCache device based on health of RAID members in the max-Cache device	Does not exist,Failed,Optimal,Degraded,Logical Device Reconfiguring,"Degraded,System", "suboptimal,Fault tolerant","Suboptimal,Reconfiguring","Suboptimal,System","Degraded,Rebuilding",Flushing,"Suboptimal,Rebuilding"
Size	size of maxCache device in MB	n/a
maxCache write cache status	maxCache write caching status for each logical device in your storage space.	On,Protected,Disabled(No Battery Protection),Off(Non redundant max-Cache Device),Off
Protected by Hot-Spare	If the maxCache device is protected by hot spare. A hot spare is a SSD (Solid State Drive) that automatically replaces any failed drive in a max-Cache device, and can subsequently be used to rebuild that maxCache device.	Yes,No
Failed stripes	any bad stripes or bad blocks for a logical	Yes,No

B Logical Drive, HDD, and Flash Backup System Status and Error Conditions

Logical Drive States

ARCCONF displays the following states for a logical drive.

Optimal	<ul style="list-style-type: none"> The logical drive is healthy. In case of redundant Logical Drive types: it has full redundancy RAID 1, RAID 1E and RAID10 volumes created using “quick init” are shown as “optimal” as redundancy is being established on every write I/O
Impacted	<ul style="list-style-type: none"> The logical drive has been created. Redundancy information has not yet been built completely
Failed	<ul style="list-style-type: none"> More member disks than supported by the redundancy level of the logical drive have failed. Logical Drive is taken offline
Clearing	<ul style="list-style-type: none"> Observed when an array is created using method ‘clear’. The logical drive enters the clearing state when firmware zeros out first and last 8 blocks of the container space.
Logical device Reconfiguring	<ul style="list-style-type: none"> A logical drive that is morphing (eg, raid level migrations / online capacity expansion)
Suboptimal, Fault Tolerant	<ul style="list-style-type: none"> There are one or more drive failures but the logical drive is still fault tolerant (ie, single drive failure on RAID-6 or RAID-60). The logical drive is in steady state
Suboptimal, Reconfiguring	<ul style="list-style-type: none"> There are one or more drive failures but the logical drive is still fault tolerant (ie, single drive failure on RAID-6 or RAID-60). The logical drive is morphing.
Suboptimal, Rebuilding	<ul style="list-style-type: none"> There are one or more drive failures but the logical drive is still fault tolerant (ie, single drive failure on RAID-6 or RAID-60). The array is recalculating parity.
Degraded	<ul style="list-style-type: none"> The redundant logical drive has suffered at least one member disk failure and any more disk failures would fail the logical drive (ie, two drive failure on RAID 6 or one drive failure on other RAIDs)
Degraded, Reconfiguring	<ul style="list-style-type: none"> A degraded logical drive that is morphing
Degraded, Rebuilding	<ul style="list-style-type: none"> A degraded logical drive where rebuild has started on any remaining members
Flushing	<ul style="list-style-type: none"> There is a flushing task on a logical drive

HDD Error Statistics

ARCCONF displays the following HDD error statistics.

Aborted Command Count	Types of aborted command instances: <ul style="list-style-type: none"> • Timeout receiving OPEN_REJECT(Retry) • Open error due to IO abort • SCSI task management command was issued but the response was invalid • Task management response has incorrect LUN • Cannot communicate due to protocol mismatch • Unable to successfully open a connection during the data phase of a command
Link Failure count	Link failure characterized by the following scenarios: <ul style="list-style-type: none"> • SMP Response frame received with errors eg, zero frame size, exceeds max length, missing EOF, len mismatch with FIS type • Link timeout while transmitting frame, I/O could not be delivered to drive • Encountered open Reject (Bad/Wrong Destination) ie, something is wrong with the topology • Unable to deliver/issue command to drive, break received • LUN reset or I_T nexus reset • Open zone violation ie, requested phy is not in the same zone as initiator or zoning permissions are invalid • No PHYs in the port or the port itself is down • Encountered DMA transmit error
Medium Error Count	<ul style="list-style-type: none"> • The drive has encountered a medium error and FW will attempt bad block recovery
Parity Error Count	<ul style="list-style-type: none"> • SCSI parity error encountered i.e. sense code = 47 h. This will also consequently abort a command and increment the respective counter.
Smart Warning Count	<ul style="list-style-type: none"> • Smart event from drive sense data eg, code = 0x0 B

Flash Backup Status

ARCCONF displays the following status for the Flash Backup system.

General Backup Unit status	<p>Preparing:</p> <ul style="list-style-type: none"> • The GB unit is preparing the NAND flash for backup. The supercap can take up to 10 minutes to charge to 100% from zero charge and report ready status <p>Ready:</p> <ul style="list-style-type: none"> • The backup unit is enabled with the supercap charged and NAND flash prepared <p>Not Ready:</p> <ul style="list-style-type: none"> • Observed if the supercap is not present or has suffered a fatal error or if the BU temperature has exceeded allowed maximum
----------------------------	---

Supercapacitor status	<p>Fatal:</p> <ul style="list-style-type: none">FW could not retrieve green backup information or configuration due to hardware issues , overvoltage, etc <p>Health Normal / Low / Dead:</p> <ul style="list-style-type: none">Health parameter indicates overall energy holding ability of the capacitor and mathematically represents (supercap capacitance / initial capacitance)Health > 90% will be displayed as normalDead status implies that capacitor would need replacement <p>Not Supported:</p> <ul style="list-style-type: none">FW does not have green backup feature enabled <p>Not Present:</p> <ul style="list-style-type: none">The backup unit is not installed
-----------------------	---



Microsemi Corporate Headquarters
One Enterprise, Aliso Viejo,
CA 92656 USA

Within the USA: +1 (800) 713-4113
Outside the USA: +1 (949) 380-6100
Fax: +1 (949) 215-4996
Email: sales.support@microsemi.com
www.microsemi.com

© 2017 Microsemi Corporation. All rights reserved. Microsemi and the Microsemi logo are trademarks of Microsemi Corporation. All other trademarks and service marks are the property of their respective owners.

Microsemi makes no warranty, representation, or guarantee regarding the information contained herein or the suitability of its products and services for any particular purpose, nor does Microsemi assume any liability whatsoever arising out of the application or use of any product or circuit. The products sold hereunder and any other products sold by Microsemi have been subject to limited testing and should not be used in conjunction with mission-critical equipment or applications. Any performance specifications are believed to be reliable but are not verified, and Buyer must conduct and complete all performance and other testing of the products, alone and together with, or installed in, any end-products. Buyer shall not rely on any data and performance specifications or parameters provided by Microsemi. It is the Buyer's responsibility to independently determine suitability of any products and to test and verify the same. The information provided by Microsemi hereunder is provided "as is, where is" and with all faults, and the entire risk associated with such information is entirely with the Buyer. Microsemi does not grant, explicitly or implicitly, to any party any patent rights, licenses, or any other IP rights, whether with regard to such information itself or anything described by such information. Information provided in this document is proprietary to Microsemi, and Microsemi reserves the right to make any changes to the information in this document or to any products and services at any time without notice.

Microsemi Corporation (Nasdaq: MSCC) offers a comprehensive portfolio of semiconductor and system solutions for aerospace & defense, communications, data center and industrial markets. Products include high-performance and radiation-hardened analog mixed-signal integrated circuits, FPGAs, SoCs and ASICs; power management products; timing and synchronization devices and precise time solutions, setting the world's standard for time; voice processing devices; RF solutions; discrete components; enterprise storage and communication solutions; security technologies and scalable anti-tamper products; Ethernet solutions; Power-over-Ethernet ICs and midspans; as well as custom design capabilities and services. Microsemi is headquartered in Aliso Viejo, California, and has approximately 4,800 employees globally. Learn more at www.microsemi.com.

ESC-2160659