

User's Guide
Microsemi Adaptec Host Bus Adapter 1000 Series
Command Line Utility

Released
September 2016





Microsemi Corporate Headquarters
One Enterprise, Aliso Viejo,
CA 92656 USA

Within the USA: +1 (800) 713-4113
Outside the USA: +1 (949) 380-6100
Fax: +1 (949) 215-4996
Email: sales.support@microsemi.com
www.microsemi.com

© 2016 Microsemi Corporation. All rights reserved. Microsemi and the Microsemi logo are trademarks of Microsemi Corporation. All other trademarks and service marks are the property of their respective owners.

Microsemi makes no warranty, representation, or guarantee regarding the information contained herein or the suitability of its products and services for any particular purpose, nor does Microsemi assume any liability whatsoever arising out of the application or use of any product or circuit. The products sold hereunder and any other products sold by Microsemi have been subject to limited testing and should not be used in conjunction with mission-critical equipment or applications. Any performance specifications are believed to be reliable but are not verified, and Buyer must conduct and complete all performance and other testing of the products, alone and together with, or installed in, any end-products. Buyer shall not rely on any data and performance specifications or parameters provided by Microsemi. It is the Buyer's responsibility to independently determine suitability of any products and to test and verify the same. The information provided by Microsemi hereunder is provided "as is, where is" and with all faults, and the entire risk associated with such information is entirely with the Buyer. Microsemi does not grant, explicitly or implicitly, to any party any patent rights, licenses, or any other IP rights, whether with regard to such information itself or anything described by such information. Information provided in this document is proprietary to Microsemi, and Microsemi reserves the right to make any changes to the information in this document or to any products and services at any time without notice.

Microsemi Corporation (Nasdaq: MSCC) offers a comprehensive portfolio of semiconductor and system solutions for aerospace & defense, communications, data center and industrial markets. Products include high-performance and radiation-hardened analog mixed-signal integrated circuits, FPGAs, SoCs and ASICs; power management products; timing and synchronization devices and precise time solutions, setting the world's standard for time; voice processing devices; RF solutions; discrete components; enterprise storage and communication solutions; security technologies and scalable anti-tamper products; Ethernet solutions; Power-over-Ethernet ICs and midspans; as well as custom design capabilities and services. Microsemi is headquartered in Aliso Viejo, California, and has approximately 4,800 employees globally. Learn more at www.microsemi.com.

Revision History

Issue	Issue Date	Details of Change
1-3	Aug/Sept/Oct 2015	Pre-production releases.
4	December 2015	First Production release.
5	April 2016	V1.1.0 Maintenance Release
6	September 2016	V1.2.0 Maintenance Release. Add SAVECONFIG/PLAYCONFIG, SETCONTROLLERPARAM I2CADDRESS, static linked arcconf install for Linux x64.

Contents

Microsemi Adaptec® Product Support.....	6
Software License Agreement.....	7
1 Getting Started with the Command Line Utility.....	10
1.1 Installing the Command Line Utility.....	10
1.1.1 Downloading the Installation Packages.....	10
1.2 Starting the Command Line Utility.....	10
2 Using the Command Line Utility.....	11
2.1 ARCCONF Commands.....	11
2.2 arccconf atapassword.....	12
2.3 arccconf driverupdate.....	12
2.4 arccconf expanderlist.....	13
2.5 arccconf expanderupgrade.....	13
2.6 arccconf getconfig.....	14
2.7 arccconf getlogs.....	15
2.8 arccconf getsmartstats.....	16
2.9 arccconf getversion.....	16
2.10 arccconf identify.....	17
2.11 arccconf imageupdate.....	17
2.12 arccconf key.....	18
2.13 arccconf list.....	19
2.14 arccconf phyerrorlog.....	19
2.15 arccconf playconfig.....	20
2.16 arccconf rescan.....	21
2.17 arccconf romupdate.....	21
2.18 arccconf saveconfig.....	22
2.19 arccconf savesupportarchive.....	22
2.20 arccconf setboot.....	23
2.21 arccconf setcontrollerparam.....	24
2.22 arccconf setstate.....	24
2.23 arccconf smp.....	25
2.24 arccconf task.....	26
2.25 arccconf uartlog.....	26
2.26 arccconf uninit.....	27

List of Tables

Table 1 • ARCCONF Batch Environments	11
Table 2 • ARCCONF Commands	11

Microsemi Adaptec® Product Support

If you have questions about installing or using your Microsemi Adaptec® product, check this document first—you will find answers to most of your questions. If you need further assistance, use the support options listed below. To expedite your service, have your computer in front of you.

Note: Please visit the Support section of www.adaptec.com for the most up to date contact information.

Self Help and Support in English

- Visit our Web site at www.adaptec.com.
- Search the Adaptec Support Knowledgebase (ASK) at ask.adaptec.com for articles, troubleshooting tips, and frequently asked questions for your product.
- For support via e-mail, submit your question at ask.adaptec.com.
- To contact Technical Support, visit our product support site at start.adaptec.com and click on "Contact Support" for options.

Technische Informationen und Support in Deutsch

- Besuchen Sie unsere Webseite www.adaptec.com/de-de
- Suchen Sie in der Adaptec Support Knowledgebase (ASK) unter ask-de.adaptec.com nach Artikeln, Tipps zur Fehlerbehebung und häufig gestellten Fragen zu Ihrem Produkt.
- Support per Email erhalten Sie unter ask-de.adaptec.com.
- Um den Technischen Support zu kontaktieren, besuchen Sie uns bitte unter start.adaptec.com und klicken Sie auf „Support kontaktieren“, für Auswahlmöglichkeiten.

Техническая поддержка и информация на русском языке

- Посещаете наш сайт www.adaptec.com/ru-ru/.
- База знаний Adaptec (ASK) на сайте ask-ru.adaptec.com ask-ru.adaptec.com – статьи, советы по устранению неисправностей и часто задаваемые вопросы о Вашем продукте.
- Для поддержки по электронной почте отправьте Ваш запрос на сайте ask-ru.adaptec.com
- Для обращения в службу Технической Поддержки, пожалуйста, посетите наш web сайт start.adaptec.com и используйте ссылку "Contact Support".

日本語での技術情報とサポート

- 弊社のウェブサイト、www.adaptec.com/ja-jp をご覧ください。
- ask.adaptec.co.jp のAdaptec Support Knowledgebase (ASK)で、お使いの製品の情報 トラブルシューティングのヒント、よくある質問を検索してください。
- Eメールでのサポートには ask.adaptec.co.jp から質問を送ってください。
- テクニカルサポートへコンタクトするには、弊社ウェブサイトstart.adaptec.comをご覧ください、"Contact Support"をクリックして下さい。

Software License Agreement

PLEASE READ CAREFULLY: THE USE OF THIS SOFTWARE IS SUBJECT TO THE SOFTWARE LICENSE TERMS OF MICROSEMI, INC. AND OTHER LICENSORS WHOSE SOFTWARE MAY BE BUNDLED WITH THIS PRODUCT.

BY YOUR USE OF THE SOFTWARE INCLUDED WITH THIS PRODUCT YOU AGREE TO THE LICENSE TERMS REQUIRED BY THE LICENSOR OF THAT SOFTWARE, AS SET FORTH DURING THE INSTALLATION PROCESS. IF YOU DO NOT AGREE TO THE LICENSE TERMS APPLICABLE TO THE SOFTWARE, YOU MAY RETURN THE ENTIRE UNUSED PRODUCT FOR A FULL REFUND.

In return for acquiring a license to use the Microsemi software, which may include software from third party licensors and patches made available by Microsemi ("Software"), and the related documentation, you agree to the following terms and conditions:

1. License. This Agreement grants you, the Licensee, a license to:
 - a. Use the Software on a single computer system, which is not intended for use by more than five (5) users; and:
 - b. Make one copy of the Software in machine readable form solely for back-up purposes, provided you reproduce Microsemi's copyright proprietary legends. Notwithstanding the foregoing, the Software may be used on the home, laptop or other secondary computer of the principal user of the Software, and an additional copy of the Software may be made to support such use. As used in this license, the Software is "in use" when it is either loaded into RAM or installed on a hard disk or other permanent memory device. The Software may be "in use" on only one computer at any given time. (Different license terms and fees are applicable for networked or multiple user applications.) As a specific condition of this license, you agree to use the Software in compliance with all applicable laws, including copyright laws, and that you will not copy, transmit, perform or distribute any audio or other content using the Software without obtaining all necessary licenses or permissions from the owner of the content.
2. Restrictions. You may not distribute copies of the Software to others or electronically transfer the Software from one computer to another over a network. You may not post or otherwise make available the Software, or any portion thereof, in any form, on the Internet. You may not use the Software in a computer service business, including in time sharing applications. The Software contains trade secrets and, in order to protect them, you may not decompile, reverse engineer, disassemble, or otherwise reduce the Software to a human-perceivable form. YOU MAY NOT MODIFY, ADAPT, TRANSLATE, RENT, LEASE, LOAN, RESELL FOR PROFIT, DISTRIBUTE, NETWORK OR CREATE DERIVATIVE WORKS BASED UPON THE SOFTWARE OR ANY PART THEREOF.
3. Ownership of Software. As Licensee, you own the media upon which the software is recorded or fixed, but Microsemi and its licensors retain title and ownership of the Software recorded on the original media and all subsequent copies of the Software, regardless of the form or media in which or on which the original and other copies may exist. This license is not a sale of the Software or any copy.
4. Confidentiality. You agree to maintain the Software in confidence and that you will not disclose the Software to any third party without the express written consent of Microsemi. You further agree to take all reasonable precautions to preclude access of unauthorized persons to the Software.
5. Term. This license is effective until January 1, 2045, unless terminated earlier. You may terminate the license at any time by destroying the Software (including the related documentation) together with all copies or modifications in any form. Microsemi will have the right to terminate our license immediately if you fail to comply with any term or condition of this Agreement. Upon any termination, including termination by you, you must destroy the Software (including the related documentation), together with all copies or modifications in any form.

6. **Special Terms Applicable to Databases.** Where a database is included with the Software, you acknowledge that it is licensed only in connection with the use of the Software to perform disc creation, and that the database and all data derived therefrom must be maintained in confidence in accordance with the provisions of Section 4. This license does not grant you any rights to distribute or disclose such database or data.
7. **Limited Warranty.** Microsemi and its Licensor warrant only that the media upon which the Software is furnished will be free from defects in material or workmanship under normal use and service for a period of thirty (30) days from the date of delivery to you. MICROSEMI AND ITS LICENSORS DO NOT AND CANNOT WARRANT THE PERFORMANCE OR RESULTS YOU MAY OBTAIN BY USING THE SOFTWARE OR DOCUMENTATION. THE FOREGOING STATES THE SOLE AND EXCLUSIVE REMEDIES MICROSEMI AND ITS LICENSORS WILL PROVIDE FOR BREACH OF WARRANTY. EXCEPT FOR THE FOREGOING LIMITED WARRANTY, MICROSEMI AND ITS LICENSORS MAKE NO WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED, AS TO NON-INFRINGEMENT OF THIRD PARTY RIGHTS, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow the exclusion of implied warranties or limitations on how long an implied warranty may last, so the above limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.
8. **The entire liability of Microsemi and its licensors, and your exclusive remedy for a breach of this warranty, shall be:**
 - a. The replacement of any media not meeting the above limited warranty which is returned to Microsemi; or
 - b. if Microsemi or its distributor is unable to deliver replacement media which is free from defects in materials or workmanship, you may terminate this Agreement by returning the Software and your money will be refunded.
9. **Limitation of Liability.** IN NO EVENT WILL MICROSEMI OR ITS LICENSORS BE LIABLE TO YOU FOR ANY INCIDENTAL, CONSEQUENTIAL OR INDIRECT DAMAGES, INCLUDING ANY LOST PROFITS, LOST SAVINGS, OR LOSS OF DATA, EVEN IF MICROSEMI OR A LICENSOR HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, OR FOR ANY CLAIM BY ANY OTHER PARTY. Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation or exclusion may not apply to you.
10. **Export.** You acknowledge that the laws and regulations of the United States and other countries may restrict the export and re-export of the Software. You agree that you will not export or re-export the Software or documentation in any form in violation of applicable United States and foreign law.
11. **Government Restricted Rights.** The Software is subject to restricted rights as follows. If the Software is acquired under the terms of a GSA contract: use, reproduction or disclosure is subject to the restrictions set forth in the applicable ADP Schedule contract. If the Software is acquired under the terms of a DoD or civilian agency contract, use, duplication or disclosure by the Government is subject to the restrictions of this Agreement in accordance with 48 C.F.R. 12.212 of the Federal Acquisition Regulations and its successors and 49 C.F.R. 227.7202-1 of the DoD FAR Supplement and its successors.
12. **General.** You acknowledge that you have read this Agreement, understand it, and that by using the Software you agree to be bound by its terms and conditions. You further agree that it is the complete and exclusive statement of the agreement between Microsemi and you, and supersedes any proposal or prior agreement, oral or written, and any other communication between Microsemi and you relating to the subject matter of this Agreement. No additional or any different terms will be enforceable against Microsemi unless Microsemi gives its express consent, including an express waiver of the terms of this Agreement, in writing signed by an officer of Microsemi. You assume full responsibility for the use of the Software and agree to use the Software legally and responsibly. This Agreement shall be governed by California law, except as to copyright matters, which are covered by Federal law. This Agreement is deemed entered into at Sunnyvale, California by both parties. Should any provision of this Agreement be declared unenforceable in any jurisdiction, then such

provision shall be deemed severable from this Agreement and shall not affect the remainder hereof.
All rights in the Software not specifically granted in this Agreement are reserved by Microsemi.

Should you have any questions concerning this license, contact:

Microsemi Corporation
Legal Department
One Enterprise
Aliso Viejo, CA 92656
(949) 380-6100

1 Getting Started with the Command Line Utility

This utility allows you to:

- Display configuration settings
- Flash new firmware and BIOS onto the controller
- Enable the controller to check the removal and connection of any disk drives
- Provides access to the status and event logs of a controller

1.1 Installing the Command Line Utility

1.1.1 Downloading the Installation Packages

Complete these steps to download the ARCCONF installation package for your operating system(s):

1. Open a browser window, then type `start.adaptec.com` in the address bar.
2. Enter your product or adapter model number, then select HBA 1000.
3. Select **Storage Manager Downloads**, then select **Adaptec ARCCONF Command Line Utility** from the list of installers.
4. Download the ARCCONF installation package.
Note: The installation package includes a statically-linked ARCCONF executable, which allows you to run the program without any OS library dependencies.
5. When the download completes, extract the package contents to the installation directory on your machine (`Program Files` or `/opt`, for instance).
6. On Linux systems, ensure that `arccconf` has 'execute' privilege:
`chmod arccconf.exe +x`

1.2 Starting the Command Line Utility

1. To start ARCCONF, enter one of the following commands:

Options	Description
Windows	<code><install_dir>\arccconf.exe</code>
Linux	<code>/<install_dir>/arccconf</code>

where `Install_dir` is the directory where the utility is installed.

2. To see a list of available commands, type `ARCCONF` at the prompt. For help with a specific command, type `ARCCONF <command_name> help`.

2 Using the Command Line Utility

This chapter explains how to use the command line utility interactively or in batch mode. With interactive mode, enter commands at the prompt. In batch mode, create scripts and run the script in the appropriate shell, as described in the table below.

Table 1 • ARCCONF Batch Environments

Environment	Batch File	Run Script
Windows	.bat	CMD.EXE
Linux/Unix	.sh	sh / bash

In either mode, if your command fails, you immediately see an error message of Command failed. Other script messages that you can get are Command completed successfully, or Command aborted.

The return values for each command are the same:

0x00: SUCCESS

0x01: FAILURE - The requested command failed

0x02: ABORT - The command was aborted because parameters failed validation

0x03: INVALID_ARGUMENTS - The arguments are incorrect. (Displays COMMAND help)

To view a list of commands at the command line, type ARCCONF and press Enter.

To access the online help for a specific command, type ARCCONF <command>, then press Enter.

2.1 ARCCONF Commands

The following commands are available in ARCCONF for the Microsemi Adaptec HBA 1000 Series adapter. The commands are described on the following pages, in alphabetical order. In the command descriptions, <> indicates a required parameter and [] indicates an optional parameter.

Table 2 • ARCCONF Commands

atapassword	getversion	rescan	smp
driverupdate	identify	romupdate	task
expanderlist	imageupdate	saveconfig	uartlog
expanderupgrade	key	savesupportarchive	uninit
getconfig	list	setboot	
getlogs	phyerrorlog	setcontrollerparam	
getsmartstats	playconfig	setstate	

Note: This guide describes commands that are supported by Microsemi Adaptec HBA 1000 Series adapters only. ARCCONF supports commands for other controllers that are not listed in the table above. If you attempt to execute any command that is not described in this guide, the firmware returns an error.

2.2 arcconf atapassword

Description

Sets or clears the drive's password for SATA drives.

Syntax

```
ARCCONF ATAPASSWORD <Controller#> SET <new password> <Channel# ID#> ...  
ARCCONF ATAPASSWORD <Controller#> CLEAR <current password> <Channel# ID#> ...
```

Parameters

new password | current password

New password, current password.

Channel/ID

Lists the space-delimited channel number and device number (ID) pairs for each drive on which to set or clear the password.

Examples

```
ARCCONF ATAPASSWORD 1 SET uR8ryx 0 1  
ARCCONF ATAPASSWORD 1 CLEAR uR8ryx 0 1
```

2.3 arcconf driverupdate

Description

Updates the Windows device driver for the controller.

Note: This command is available on Windows systems only.

Syntax

```
ARCCONF DRIVERUPDATE <DirName> [nologs]
```

Parameters

DirName

Absolute path to directory containing the Windows driver.

Nologs

Optional parameter that suppresses log output.

Examples

```
ARCCONF DRIVERUPDATE C:\WINDOWSALL
```

2.4 **arcconf expanderlist**

Description

Returns a list of disk drive expanders on a controller.

Syntax

```
ARCCONF EXPANDERLIST <Controller#>
```

Parameters

Controller#

Controller number.

Examples

```
ARCCONF EXPANDERLIST 1
```

2.5 **arcconf expanderupgrade**

Description

Allows new firmware to be flashed to an enclosure or expander.

Syntax:

```
ARCCONF EXPANDERUPGRADE <Controller#> ENCLOSURE <Connector# Channel# ID#>  
[ChunkSize#] <UpgradeType> <Filename> [Mode#] [noprompt]
```

Parameters

Controller#

Controller number.

Channel#

Channel number of the device to be updated.

ID#

Device number of the device to be updated.

Connector#

Connector number of the device to be updated.

ChunkSize#

Chunk size, in bytes, to be used to update the firmware. Default is 65536 bytes.

Filename

Name of the firmware update file.

UpgradeType

EXPANDER—update the firmware image on the expander or enclosure

MFG—update the manufacturing image (BOOT SEEPROM) on the expander or enclosure

CPLD—update the CPLD image on the expander or enclosure

Note: MFG and CPLD upgrade types are supported on the Microsemi Adaptec AEC-82885T expander only.

Mode#

The Mode parameter applies to EXPANDER and MFG upgrade types only. Valid values are:

- 2—download microcode only; requires system reset or power cycle to activate (default)
- 6—download microcode with offsets and activate
- 7—download microcode with offsets, save, and activate

Noprompt

Optional parameter that suppresses alert messages.

Examples

```
arcconf EXPANDERUPGRADE 1 ENCLOSURE 2 0 0 1024 EXPANDER C:\FirmwareImage.bin 7
arcconf EXPANDERUPGRADE 1 ENCLOSURE 2 0 0 512 MFG C:\FirmwareImage.rom 6
arcconf EXPANDERUPGRADE 1 ENCLOSURE 2 0 0 256 CPLD C:\CPLDImage.bin noprompt
```

2.6 arconf getconfig

Description

Lists information about controllers, physical drives, including:

- Controller type, status, World Wide Name (WWN), and mode
- BIOS, boot block, device driver, and firmware versions
- Device type, device ID, presence of PFA
- Physical device state, mount point (for drives with OS partition)
- Enclosure information: fan, power supply, and temperature status
- SGPIO virtual SEP information (virtual enclosure device for SGPIO backplanes)
- Connector/Lane/Phy mapping

Also displays controller BIOS settings if you do not include a device-type keyword.

Note: When displaying adapter information (AD keyword), the Controller Status field is set to `Ok` or `Not Ok`. Its value is set to `Not Ok` only if:

1. Communication with the controller fails. This occurs when the driver returns an error code after attempting to send a command to the controller.

Syntax

```
ARCCONF GETCONFIG <Controller#> [AD|PD|AL|CN]
```

Parameters

Controller#

Controller number

AD/PD/AL...

- AD—Adapter information only
- PD—Physical device information only
- CN—Connector information only
- AL—All information

Examples

```
ARCCONF GETCONFIG 1
-----
Controller BIOS Setting Information
-----
Runtime BIOS                               : Enabled
```

```

Array BBS Support           : Enabled
Physical Drives Displayed during POST : Disabled
Backplane Mode              : SGPIO
MissingDrvCount             : 8
...
```

```
ARCCONF GETCONFIG 1 CN
```

2.7 arccnf getlogs

Description

Provides access to controller status, event logs, and usage statistics, including:

- A log of device errors that the controller encountered
- A log that records any occurrences of defunct devices
- A log of special events that may have occurred
- A log of controller usage statistics, including Inter-I/O Read and Write times and I/O Completion Read and Write times
- A log of supported hardware components on the controller

Syntax

```

ARCCONF GETLOGS <Controller#> <Type1> [clear|tabular] [nologs]
ARCCONF GETLOGS <Controller#> <Type2> [tabular] [nologs]
ARCCONF GETLOGS <Controller#> <Type4> <HardwareType#> [nologs]
ARCCONF GETLOGS <Controller#> DEVICE <clear> <ErrorType#> [<Channel# ID#>|ALL]
[nologs]
```

Parameters

Controller#

Controller number.

Type1

One of the following:

- DEVICE—device error log
- DEAD—dead (failed) drive log
- EVENT—controller event log

Type2

One of the following:

- STATS—controller statistics data

Type4

One of the following:

1. Cache Memory
2. NVSRAM

ErrorType

One of the following:

- 1 - Parity Error Counter
- 2 - Link Failure Counter
- 3 - Hardware Error Counter
- 4 - Aborted Commands Counter
- 5 - Medium Error Counter
- 6 - SMART Warning Counter

Clear

Clears the specified log from the controller or a specific error counter for one or all physical drives on a controller.

Channel/ID

Channel and number of the physical device on the controller.

Tabular

Displays the log or statistics in tabular format.

Examples

```
ARCCONF GETLOGS 1 EVENT
ARCCONF GETLOGS 1 STATS tabular
ARCCONF GETLOGS 1 DEVICE clear 3 ALL
```

2.8 **arccconf getsmartstats**

Description

Displays SMART statistics for the hard drives and Solid State Drives (SSDs) on a controller.

Syntax

```
ARCCONF GETSMARTSTATS <Controller#> [Tabular]
```

Parameters**Controller#**

Controller number.

Tabular

Creates output in tabular format.

Examples

```
ARCCONF GETSMARTSTATS 1
ARCCONF GETSMARTSTATS 1 TABULAR
```

2.9 **arccconf getversion**

Description

Lists version information for all controllers or a specific controller's software components, including information about the BIOS, driver, firmware currently running, and firmware that will run after a reboot.

Syntax

```
ARCCONF GETVERSION
ARCCONF GETVERSION <Controller#>
```

Parameters**Controller#**

Controller# is the controller number

Examples

```
ARCCONF GETVERSION
ARCCONF GETVERSION 1
```

2.10 arconf identify

Description

Identifies a physical device by blinking its LEDs.

Syntax

```
ARCCONF IDENTIFY <Controller#> DEVICE <Channel# ID#> [TIME <BlinkTime>] [nologs]
ARCCONF IDENTIFY <Controller#> ALL [STOP]
```

Parameters

Controller#

Controller number

Channel# ID#

Channel number and ID number for the physical device(s) to be identified

ALL

Blinks all physical devices on the controller for 1 hour or until the STOP command is issued

TIME <BlinkTime>

Time, in seconds, for the LEDs to continue blinking

STOP

Stops blinking the device

Examples

```
ARCCONF IDENTIFY 1 DEVICE 0 0
```

```
ARCCONF IDENTIFY 1 ALL
ARCCONF IDENTIFY 1 ALL STOP
```

2.11 arconf imageupdate

Description

Allows new firmware to be flashed to the hard drive.

Syntax:

```
ARCCONF IMAGEUPDATE <Controller#> DEVICE <Channel# ID# ChunkSize# Filename>
[Mode#] [BufferID#] [noprompt]
```

Parameters

Controller#

Controller number.

Channel#

Channel number of the device to be updated.

ID#

Device number of the device to be updated.

ChunkSize#

Chunk size, in bytes, to be used to update the firmware.

Note: For SATA drives, the chunk size must be a multiple of 512.

Filename

Name of the firmware update file.

Mode#

Firmware update mode. Valid values for physical drives are:

- 3-(SATA) Download with offsets and save image for immediate and future use
- 7-(SAS) Download microcode with offsets, save, and activate

BufferID#

Mandatory for tape drive firmware update.

Noprompt

Optional parameter that suppresses alert messages.

Examples

```
ARCCONF IMAGEUPDATE 1 DEVICE 0 0 16384 ados.lod 3
```

2.12 arccnf key

Description

Loads a feature key onto a Microsemi Adaptec controller.

Syntax

```
ARCCONF KEY <Controller#> SET <Key#>
```

Parameters

Controller#

The controller number.

Key#

The key number provided by Microsemi.

Examples

```
ARCCONF KEY 1 SET ABCDEFGHIJKLMNOPQRSTUVWXYZ
```

2.13 **arccnf list**

Description

Lists all controllers in the system, or the configuration of a specific controller.

Syntax

```
ARCCNF LIST [Controller#]
```

Parameters

Controller#

The controller number.

Examples

```
ARCCNF LIST  
ARCCNF LIST 1
```

2.14 **arccnf phyerrorlog**

Description

Displays PHY error logs for physical devices on a controller.

Syntax

```
ARCCNF PHYERRORLOG <Controller#> DEVICE <Channel# ID#>  
ARCCNF PHYERRORLOG <Controller#> DEVICE ALL
```

Parameters

Controller#

Controller number.

Channel/ID

Channel and number of the physical device on the controller.

ALL

Displays PHY error log for all physical devices.

Examples

```
ARCCNF PHYERRORLOG 1 DEVICE 0 0  
ARCCNF PHYERRORLOG 1 DEVICE ALL
```

2.15 arcconf playconfig

Description

Configures a controller using a XML server template file produced by the SAVECONFIG command (see [arcconf saveconfig](#) on page 22). Use this command to deploy the same controller configuration on multiple servers in your storage space.

Note:

1. The XML server template file (default, saveconfig.xml) is editable. For example, you may need to change the disk drive capacity.
2. Drives from the same vendor with slightly different capacities (147GB vs 150GB, for instance) are considered interchangeable. If the interchange results in a change in logical drive capacity, the drive is scaled, as needed. For example, if the new drives have 4% more capacity due to vendor or model changes, then all logical drives are increased in size by 4%.
3. Be sure to check the log file to verify that the controller was configured successfully. The exit codes, shown below, indicate the success or failure of the operation and if the system needs to be rebooted.

Code	Value	Meaning
SUCCESS	0	Configuration succeeded, no reboot is required.
FAILURE_GENERAL	1	An error occurred and the configuration could not be completed.
SUCCESS_REBOOT	2	Configuration succeeded, but a reboot is required.

Syntax

```
ARCCONF PLAYCONFIG <Config XML File> [LogFile] [FORCE ALL] [SLOTID]
```

Parameters

Config XML File

The pathname of the server template file. If not specified, the default server template file is checked at C:\PMCS\Logs\saveconfig.xml.

LogFile

Sets the pathname of the error log file. By default, the error log is available at C:\PMCS\Logs\playconfig.log.

FORCE

Forces deployment of the server even if the controller does not support all features, or the drive capacity does not match the configuration in the input XML file. Use FORCE ALL to force deployment of all features.

SLOTID

Apply the configuration based on Slot ID instead of Device ID.

Examples

```
ARCCONF PLAYCONFIG server1_config.xml playconfig.log FORCE ALL
```

2.16 **arcconf rescan**

Description

Enables the controller to check for the removal of any disk drives and to check for the connection of any new disk drives to the controller. Controller rescan runs in the background, asynchronously. When rescan is started, a message is displayed stating that the process is running in the background and may take 10 minutes to complete. Another message is displayed if a rescan is started while one is already in progress.

Syntax

```
ARCCONF RESCAN <Controller#> [nologs]
ARCCONF RESCAN ALL [nologs]
```

Parameters

Controller#

The controller number

ALL

Rescans all controllers in the system

Examples

```
ARCCONF RESCAN 1
ARCCONF RESCAN ALL
```

2.17 **arcconf romupdate**

Description

Allows new firmware and BIOS to be flashed to the controller. A reboot is required for the new firmware to take effect.

Note:

1. This command is supported on all OSs that support maxView Storage Manager.
2. You can download the .bin update files from the Support area at www.adaptec.com.

Syntax

```
ARCCONF ROMUPDATE <Controller#> <BaseName> [newversion <build#> [force]]
[noprompt] [nologs]
```

Parameters

Controller#

The controller number.

BaseName

Absolute path to the controller image file.

Newversion <build#>

Specifies the version of the firmware build.

Force

An optional parameter used to force a down-level firmware update. Valid only if Newversion parameter is specified.

Noprompt

An optional parameter that suppresses the confirmation prompt.

Examples

```
ARCCONF ROMUPDATE 1 /usr/home/AC220001.BIN
ARCCONF ROMUPDATE 1 C:\firmwareImage\as483c.bin newversion 12345 force noprompt
```

2.18 **arccnf saveconfig**

Description

Note: This command is supported on all OSs that support maxView Storage Manager.

Saves the controller configuration to a XML server template file, including the controller type, operational settings, physical drive size. Use this file with the PLAYCONFIG command to deploy the same controller configuration to other servers in your storage space; see [arccnf playconfig](#) on page 20 for more information.

Note: Be sure to check the log file to verify that the configuration XML file was created successfully. The exit codes, shown below, indicate the success or failure of the operation.

Code	Value	Meaning
SUCCESS	0	Configuration XML generated successfully.
FAILURE_GENERAL	1	An error occurred and the configuration XML could not be generated.

Syntax

```
ARCCONF SAVECONFIG [Config XML File] [LogFile]
```

Parameters

Config XML File

The pathname of the server template file. The default name (if you omit this parameter) is C:\PMCS\Logs\saveconfig.xml.

LogFile

The pathname of the error log file. By default, the error log is available at C:\PMCS\Logs\saveconfig.log.

Examples

```
ARCCONF SAVECONFIG server1_config.xml C:\LOGS\SERVER1.LOG
```

2.19 **arccnf savesupportarchive**

Description

Saves configuration and status information to help diagnose a problem with your system. Saved information includes device logs, drive logs, event logs, error logs, controller logs, history logs, basecode logs, and SSD SMART statistics.

By default, the log files are saved in the Support folder in the standard logs directory for your operating system (/var/log for Linux, and so on).

Syntax

```
ARCCONF SAVESUPPORTARCHIVE [Path] [Firmware|Arcconf|Storlib|Basecode]
```

Parameters

Path

Path to store the log files.

Log type:

One of these log files:

- Firmware: saves Firmware logs
- Arcconf: saves Arcconf logs
- Storlib: saves StorLib logs
- Basecode: saves basecode logs

Examples

```
ARCCONF SAVESUPPORTARCHIVE
ARCCONF SAVESUPPORTARCHIVE Firmware
```

2.20 arcconf setboot

Description

Sets the controller as a boot device for the system. This command is available only when the controller is offline.

Syntax

```
ARCCONF SETBOOT <Controller#> DEVICE <Channel# ID#> TYPE <Boot Type> [nologs]
ARCCONF SETBOOT <Controller#> ENABLE
```

Parameters

Controller#

Controller number

Channel# ID#

Channel and ID of the physical device to mark as the boot device

TYPE <Boot Type>

Boot type:

- Primary - Primary boot device
- Secondary - Secondary boot device
- None - Non-bootable

ENABLE

Sets the controller as a boot controller

Examples

```
ARCCONF SETBOOT 1 DEVICE 0 5 TYPE secondary
ARCCONF SETBOOT 1 ENABLE
```

2.21 **arccnf setcontrollerparam**

Description

Changes a parameter of a controller.

Syntax

```
ARCCONF SETCONTROLLERPARAM <Controller#> QUEUEDEPTH <QDepth> [nologs]
ARCCONF SETCONTROLLERPARAM <Controller#> ELEVATORSORT <Enable | Disable>
[nologs]
ARCCONF SETCONTROLLERPARAM <Controller#> LATENCY <Latency> [nologs]
ARCCONF SETCONTROLLERPARAM <Controller#> I2CADDRESS <I2Caddress> [nologs]
```

Parameters

Controller#

Controller number

QUEUEDEPTH <QDepth>

Sets the queue depth for the controller. Valid values are 0, 2, 4, 8, 16, and 32. A value of 0 indicates automatic queue depth.

ELEVATORSORT

Sets the behavior of the controller cache write Elevator sort algorithm.

LATENCY

Sets the flexible latency scheduler. Valid values are:

- 0 : Disable (default).
- 1 : Low. Sets value to 250.
- 2 : Medium. Sets value to 100.
- 3 : High. Sets value to 50.
- 4 : Aggressive level 1. Sets value to 30.
- 5 : Aggressive level 2. Sets value to 10.

I2CADDRESS <I2Caddress>

I2C address for PBSI Interface, in Hex, from 0x00 to 0xFF.

Examples

```
ARCCONF SETCONTROLLERPARAM 1 QUEUEDEPTH 16
ARCCONF SETCONTROLLERPARAM 1 ELAVATORSORT disable
ARCCONF SETCONTROLLERPARAM 1 LATENCY 2
SETCONTROLLERPARAM 1 I2CADDRESS 0x05
```

2.22 **arccnf setstate**

Description

Changes the state of a physical device to the designated state.

Syntax

```
ARCCONF SETSTATE <Controller#> DEVICE <Channel#> <Device#> <State> [noprompt]
```

Parameters

Controller#

The controller number

Channel#

The channel number for the drive.

Device#

Device number for the device.

State

- RDY—Attempts to change a drive from Failed to Ready.
- DDD—Force a drive offline (to Failed).

Noprompt:

No prompt for confirmation.

Examples

```
ARCCONF SETSTATE 1 DEVICE 0 0 DDD
ARCCONF SETSTATE 1 DEVICE 0 0 RDY
```

2.23 arccconf smp

Description

Sends a SAS Management Protocol (SMP) function request to a SMP target device.

Syntax:

```
ARCCONF SMP <Controller#> Enclosure <Connector# Channel# Device#> Expander
<Expander#> <CommandType1> [ASCII]
ARCCONF SMP <Controller#> Enclosure <Connector# Channel# Device#> Expander
<Expander#> <CommandType2 PHY#> [ASCII]
```

Parameters

Controller#

Controller number.

Connector# Channel# ID#

Connector ID, Channel ID and Device ID of the enclosure that contains the expander.

Expander#

Expander number on the controller (SMP target device).

PHY#

The PHY Identifier (valid only for Discover and PHY Error Log Request).

CommandType#

CommandType1:

- RGR - Report General Request
- RMR - Report Manufacturer Request

CommandType2:

- DR - Discover Request
- RPELR - Report PHY Error Log Request

ASCII

Displays the SMP response in ASCII format along with Hex formatted output.

Examples

```
ARCCONF SMP 1 Enclosure 1 2 0 Expander 0 RGR
ARCCONF SMP 1 Enclosure 1 2 0 Expander 1 DR 0
```

2.24 arconf task

Description

Performs a task on a physical drive. Uninitializes physical drives on a controller.

Syntax:

```
ARCCONF TASK START <Controller#> DEVICE ALL UNINITIALIZE
```

Parameters

Controller#

The controller number

Options:

- Physical device options:
 - UNINITIALIZE—When specified with ALL, clears Microsemi Adaptec meta-data and any OS partitions from all drives on the controller; existing data on the drive is destroyed.

Examples

```
ARCCONF TASK START 1 DEVICE ALL UNINITIALIZE
```

2.25 arconf uartlog

Description

Starts a console for UART command execution.

Syntax

```
ARCCONF UARTLOG <Controller#> CONSOLE [noprompt] [nologs]
```

Parameters

Controller#

Controller number

CONSOLE

Starts an interactive UART console to run commands. Enter commands one line at a time. Type "exit" to stop.

Noprompt:

No prompt for confirmation.

Example

```
ARCCONF UARTLOG 1 CONSOLE
```

2.26 **arccconf uninit**

Description

Uninitializes one or more physical drives. The uninitialize command clears Microsemi Adaptec meta-data and any OS partitions from a drive; existing data on the drive is destroyed.

Note: Uninitialized drives are compatible with any HBA and can be exchanged with drives on the motherboard's SATA interface.

Syntax:

```
ARCCONF UNINIT <Controller#> <Channel# Drive#> [Channel# Drive#] ... [nologs]  
ARCCONF UNINIT <Controller#> ALL [nologs]
```

Parameters

Controller#

Controller number.

Channel#

The channel number of the device to be uninitialized.

Drive#

The drive number of the device to be uninitialized.

ALL

Uninitializes all physical devices on the controller.

nologs

Suppresses log output for the command.

Examples

```
ARCCONF UNINIT 1 0 12 0 13  
ARCCONF UNINIT 1 ALL
```