

Adaptec RAID Controller Command Line Utility User's Guide

CDP-00284-02-A Rev. A Issue : November 22, 2013



Copyright [©] PMC-Sierra, Inc. All rights reserved.

The information in this document is proprietary and confidential to PMC-Sierra, Inc. In any event, no part of this document may be reproduced or redistributed in any form without the express written consent of PMC-Sierra, Inc.

CDP-00284-02-A Rev. A, IssueNumber

None of the information contained in this document constitutes an express or implied warranty by PMC-Sierra, Inc. as to the sufficiency, fitness or suitability for a particular purpose of any such information or the fitness, or suitability for a particular purpose, merchantability, performance, compatibility with other parts or systems, of any of the products of PMC-Sierra, Inc., or any portion thereof, referred to in this document. PMC-Sierra, Inc. expressly disclaims all representations and warranties of any kind regarding the contents or use of the information, including, but not limited to, express and implied warranties of accuracy, completeness, merchantability, fitness for a particular use, or non-infringement.

In no event will PMC-Sierra, Inc. be liable for any direct, indirect, special, incidental or consequential damages, including, but not limited to, lost profits, lost business or lost data resulting from any use of or reliance upon the information, whether or not PMC-Sierra, Inc. has been advised of the possibility of such damage.

For a complete list of PMC-Sierra's trademarks and registered trademarks, visit: http://www.pmc-sierra.com/legal/.

Other product and company names mentioned herein may be the trademarks of their respective owners.



Revision History

Issue	Issue Date	Details of Change
1.04	November 22, 2013	Adaptec Firmware/BIOS/Drivers/Utilities Version 1.04



Contents

Adaptec by PMC Product Support	7
Software License Agreement	9
1 Getting Started with the Command Line Utility	12
Installing the Command Line Utility	12
Downloading the Installation Packages	12
Installing on Windows	13
Installing on Red Hat, Cent OS, SuSE, or Fedora Linux	13
Installing on Debian or Ubuntu Linux	14
Installing on Solaris	14
Installing on FreeBSD	14
Installing on VMware ESX 4.1	14
Installing on VMware ESXi 5.x	15
Installing on a VMware Guest OS	16
Starting the Command Line Utility	16
2 Using the Command Line Utility	17
ARCCONF Commands	
arcconf atapassword	
arcconf consistencycheck	
arcconf copyback	19
arcconf create	19
arcconf delete	21
arcconf driverupdate	21
arcconf expanderlist	22
arcconf failover	23
arcconf getconfig	23
arcconf getlogs	24
arcconf getperform	25
arcconf getsmartstats	25
arcconf getstatus	
arcconf getversion	
arcconf identify	27
arcconf imageupdate	27
arcconf key	
arcconf modify	
arcconf phyerrorlog	29
arcconf playconfig	
arcconf rescan	31
arcconf resetstatisticscounters	
arcconf romundate	32
arcconf saveconfig	32
arcconf savesupportarchive	22
arcconfisetalarm	
arcconf setcache	34
arcconf setconfig	
arcconf setcontrollermode	
arcconf setmaxcache	36
arcconfisetname	
arcconfisetnon	۵۵ کړ
arcconf catherform	۵۵ ۵۷
arcconf setnower	وح مد
arcconf saturiority	39 ۸۸
arcconf satstata	40. 1 م
arcconf satstatscalaction	41 גו
arcconf sotumerodontial	
מוננטווו לפנטוונופטפונומו	



arcconf	task	.43
arcconf	uninit	.44



List of Tables

Table 1: ARCCONF Batch Environ	nents	
Table 2: ARCCONF Commands		17



Adaptec by PMC Product Support

If you have questions about installing or using your Adaptec by PMC product, check this document first—you will find answers to most of your questions. If you need further assistance, use the support options listed below. To expedite your service, have your computer in front of you.

Note: The phone numbers below are subject to change. Please visit the Support section of *www.adaptec.com* for the most up to date contact information.

Technical Support Identification (TSID) Number

- Before contacting Technical Support, you need your product unique TSID number. The TSID number identifies your product and support status.
- The TSID number is included on a white, bar-coded label, like this example:

	TSID: PTNNNNNYYWW
THIS TSID NUMBER WILL	(1P) PRODUCT P/N: PPPPPPPPPPPPPPPP
BE REQUIRED WHEN CONTACTING TECHNICAL	
SUPPORT.	(S) PRODUCT S/N: XXXXXXXXXXXXXXX

 It's recommended that you register your product so that you have easy access to your TSID when contacting product support.

Self Help and Support in English

- Visit our Web site at *www.adaptec.com*.
- Search the Adaptec Support Knowledgebase (ASK) at *ask.adaptec.com* for articles, troubleshooting tips, and frequently asked questions for your product.
- For support via e-mail, submit your question at *ask.adaptec.com*.
- To speak with a Technical Support Specialist, call +1 408 934 7274 or +49 89 4366 5544 or +44 845 266 8773.

Technische Informationen und Support in Deutsch

- Besuchen Sie unsere Webseite www.adaptec.com/de-de
- Suchen Sie in der Adaptec Support Knowledgebase (ASK) unter *ask-de.adaptec.com* nach Artikeln, Tipps zur Fehlerbehebung und häufig gestellten Fragen zu Ihrem Produkt.
- Support per Email erhalten Sie unter *ask-de.adaptec.com*.
- Für telefonischen Support wählen Sie +49 89 4366 5522.

Техническая поддержка и информация на русском языке

- Посещаете наш сайт *www.adaptec.com/ru-ru/*.
- База знаний Adaptec (ASK) на сайте *ask-ru.adaptec.com* ask-ru.adaptec.com статьи, советы по устранению неисправностей и часто задаваемые вопросы о Вашем продукте.
- Для поддержки по электронной почте отправьте Ваш запрос на сайте ask-ru.adaptec.com
- Чтобы обратиться к специалисту технической поддержки по телефону, звоните на +7 499 918 7200 или +49 89 4366 5555.

日本語での技術情報とサポート

- 弊社のウェブサイト、www.adaptec.com/ja-jp をご覧ください。
- ask.adaptec.co.jp のAdaptec Support Knowledgebase (ASK)で、お使いの製品の情報 トラブルシュー ティングのヒント、よくある質問を検索してください。
- Eメールでのサポートには ask.adaptec.co.jp から質問を送ってください。



Information Technique et d'assistance en Français

- Visitez notre site Web à l'adresse *www.adaptec.com/fr-fr*.
- Rechercher dans le base de connaissances Adaptec (ASK) *ask-fr.adaptec.com* pour des articles, conseils de dépannage et les questions fréquemment posées pour votre produit.



Software License Agreement

PLEASE READ CAREFULLY: THE USE OF THIS SOFTWARE IS SUBJECT TO THE SOFTWARE LICENSE TERMS OF PMC-SIERRA, INC. AND OTHER LICENSORS WHOSE SOFTWARE MAY BE BUNDLED WITH THIS PRODUCT.

BY YOUR USE OF THE SOFTWARE INCLUDED WITH THIS PRODUCT YOU AGREE TO THE LICENSE TERMS REQUIRED BY THE LICENSOR OF THAT SOFTWARE, AS SET FORTH DURING THE INSTALLATION PROCESS. IF YOU DO NOT AGREE TO THE LICENSE TERMS APPLICABLE TO THE SOFTWARE, YOU MAY RETURN THE ENTIRE UNUSED PRODUCT FOR A FULL REFUND.

In return for acquiring a license to use the PMC-Sierra software, which may include software from third party licensors and patches made available by PMC-Sierra ("Software"), and the related documentation, you agree to the following terms and conditions:

- 1. License. This Agreement grants you, the Licensee, a license to:
 - **a.** Use the Software on a single computer system, which is not intended for use by more than five (5) users; and:
 - b. Make one copy of the Software in machine readable form solely for back-up purposes, provided you reproduce PMC-Sierra's copyright proprietary legends. Notwithstanding the foregoing, the Software may be used on the home, laptop or other secondary computer of the principal user of the Software, and an additional copy of the Software may be made to support such use. As used in this license, the Software is "in use" when it is either loaded into RAM or installed on a hard disk or other permanent memory device. The Software may be "in use" on only one computer at any given time. (Different license terms and fees are applicable for networked or multiple user applications.) As a specific condition of this license, you agree to use the Software in compliance with all applicable laws, including copyright laws, and that you will not copy, transmit, perform or distribute any audio or other content using the Software without obtaining all necessary licenses or permissions from the owner of the content.
- 2. Restrictions. You may not distribute copies of the Software to others or electronically transfer the Software from one computer to another over a network. You may not post or otherwise make available the Software, or any portion thereof, in any form, on the Internet. You may not use the Software in a computer service business, including in time sharing applications. The Software contains trade secrets and, in order to protect them, you may not decompile, reverse engineer, disassemble, or otherwise reduce the Software to a human-perceivable form. YOU MAY NOT MODIFY, ADAPT, TRANSLATE, RENT, LEASE, LOAN, RESELL FOR PROFIT, DISTRIBUTE, NETWORK OR CREATE DERIVATIVE WORKS BASED UPON THE SOFTWARE OR ANY PART THEREOF.
- **3.** Ownership of Software. As Licensee, you own the media upon which the software is recorded or fixed, but PMC-Sierra and its licensors retain title and ownership of the Software recorded on the original media and all subsequent copies of the Software, regardless of the form or media in which or on which the original and other copies may exist. This license is not a sale of the Software or any copy.
- **4.** Confidentiality. You agree to maintain the Software in confidence and that you will not disclose the Software to any third party without the express written consent of PMC-Sierra. You further agree to take all reasonable precautions to preclude access of unauthorized persons to the Software.
- 5. Term. This license is effective until January 1, 2045, unless terminated earlier. You may terminate the license at any time by destroying the Software (including the related documentation) together with all copies or modifications in any form. PMC-Sierra will have the right to terminate our license immediately if you fail to comply with any term or condition of this Agreement. Upon any termination, including termination by you, you must destroy the Software (including the related documentation), together with all copies or modifications in any form.
- **6.** Special Terms Applicable to Databases. Where a database is included with the Software, you acknowledge that it is licensed only in connection with the use of the Software to perform disc creation, and that the database and all data derived therefrom must be maintained in confidence in accordance with the provisions of Section 4. This license does not grant you any rights to distribute or disclose such database or data.



- 7. Limited Warranty. PMC-Sierra and its Licensor warrant only that the media upon which the Software is furnished will be free from defects in material or workmanship under normal use and service for a period of thirty (30) days from the date of delivery to you. PMC-SIERRA AND ITS LICENSORS DO NOT AND CANNOT WARRANT THE PERFORMANCE OR RESULTS YOU MAY OBTAIN BY USING THE SOFTWARE OR DOCUMENTATION. THE FOREGOING STATES THE SOLE AND EXCLUSIVE REMEDIES PMC-SIERRA AND ITS LICENSORS WILL PROVIDE FOR BREACH OF WARRANTY. EXCEPT FOR THE FOREGOING LIMITED WARRANTY, PMC-SIERRA AND ITS LICENSORS MAKE NO WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED, AS TO NON-INFRINGEMENT OF THIRD PARTY RIGHTS, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow the exclusion of implied warranties or limitations on how long an implied warranty may last, so the above limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.
- **8.** The entire liability of PMC-Sierra and its licensors, and your exclusive remedy for a breach of this warranty, shall be:
 - **a.** The replacement of any media not meeting the above limited warranty which is returned to PMC-Sierra; or:
 - **b.** if PMC-Sierra or its distributor is unable to deliver replacement media which is free from defects in materials or workmanship, you may terminate this Agreement by returning the Software and your money will be refunded.
- 9. Limitation of Liability. IN NO EVENT WILL PMC-SIERRA OR ITS LICENSORS BE LIABLE TO YOU FOR ANY INCIDENTAL, CONSEQUENTIAL OR INDIRECT DAMAGES, INCLUDING ANY LOST PROFITS, LOST SAVINGS, OR LOSS OF DATA, EVEN IF PMC-SIERRA OR A LICENSOR HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, OR FOR ANY CLAIM BY ANY OTHER PARTY. Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation or exclusion may not apply to you.
- **10.** Export. You acknowledge that the laws and regulations of the United States and other countries may restrict the export and re-export of the Software. You agree that you will not export or re-export the Software or documentation in any form in violation of applicable United States and foreign law.
- 11. Government Restricted Rights. The Software is subject to restricted rights as follows. If the Software is acquired under the terms of a GSA contract: use, reproduction or disclosure is subject to the restrictions set forth in the applicable ADP Schedule contract. If the Software is acquired under the terms of a DoD or civilian agency contract, use, duplication or disclosure by the Government is subject to the restrictions of this Agreement in accordance with 48 C.F.R. 12.212 of the Federal Acquisition Regulations and its successors and 49 C.F.R. 227.7202-1 of the DoD FAR Supplement and its successors.
- 12. General. You acknowledge that you have read this Agreement, understand it, and that by using the Software you agree to be bound by its terms and conditions. You further agree that it is the complete and exclusive statement of the agreement between PMC-Sierra and you, and supersedes any proposal or prior agreement, oral or written, and any other communication between PMC-Sierra and you relating to the subject matter of this Agreement. No additional or any different terms will be enforceable against PMC-Sierra unless PMC-Sierra gives its express consent, including an express waiver of the terms of this Agreement, in writing signed by an officer of PMC-Sierra. You assume full responsibility for the use of the Software and agree to use the Software legally and responsibly. This Agreement shall be governed by California law, except as to copyright matters, which are covered by Federal law. This Agreement is deemed entered into at Sunnyvale, California by both parties. Should any provision of this Agreement be declared unenforceable in any jurisdiction, then such provision shall be deemed severable from this Agreement and shall not affect the remainder hereof. All rights in the Software not specifically granted in this Agreement are reserved by PMC-Sierra.

Should you have any questions concerning this license, contact:

PMC-Sierra, Inc. Legal Department 1380 Bordeaux Drive

Adaptec RAID Controller Command Line Utility User's Guide



Sunnyvale, CA 94089 (408) 239-8000



1 Getting Started with the Command Line Utility

This chapter explains how your Adaptec by PMC[®] RAID controllers support the use of the ARCCONF command line utility.

This utility allows you to:

- Create and delete logical drives
- · Display and modify configuration settings
- Copy configurations from one computer to another
- · Recover from a failed physical device and rebuild an affected logical drive
- Flash new firmware and BIOS onto the controller
- Enable the controller to check the removal and connection of any disk drives
- Provides access to the status and event logs of a controller
- Isolate problems and determine their causes

Installing the Command Line Utility

You can install ARCCONF with the Adaptec maxView Storage Manager application. Alternatively, if you prefer to install just the command line utility, without also installing the maxView Storage Manager GUI, you can install just the ARCCONF executable for your operating system.

Follow the instructions in this section to install ARCCONF with maxView Storage Manager. (For more information about maxView Storage Manager, see the *maxView Storage Manager User's Guide*.)

Note: On FreeBSD systems, you *must* use ARCCONF to perform storage management tasks. FreeBSD does not support the maxView Storage Manager GUI. For more information, see *Downloading the Installation Packages* on page 12 and *Installing on FreeBSD* on page 14.

Downloading the Installation Packages

Complete these steps to download the installation package for your operating system(s) from the Adaptec Web site:

- 1. Open a browser window, then type start.adaptec.com in the address bar.
- 2. Select your RAID controller family (Series 7, Series 8, and so on) and controller model.
- **3.** Select **Storage Manager Downloads**, then select the appropriate installer package from the list; for instance, maxView Storage Manager for Windows x64 or maxView Storage Manager for Linux.

Note: To install ARCCONF without the GUI, select **Adaptec ARCCONF Command Line Utility** from the list of installers. This package includes the ARCCONF executable for Windows, Linux, Solaris, and FreeBSD.

- 4. Click Download Now and accept the license agreement.
- 5. When the download completes, extract the contents of the installer archive file to a temporary location. If the archive includes installers for multiple operating system versions (VMware, for instance), each installer is stored in a separate folder, including one each for 32-bit and 64-bit operating systems.

Note: If you are installing maxView Storage Manager and ARCCONF on a different machine–for instance, you downloaded the Linux installer onto a Windows machine –copy the installer from the download location to a temporary location on the target machine. Use whatever method you prefer to copy the file: USB flash drive; network transfer; Telnet/SSH; whatever is most convenient.

6. Continue with the installation instructions for your operating system.



Installing on Windows

To install ARCCONF on Windows systems:

- 1. Open Windows Explorer or My Computer, then change to the directory where the Windows setup program is located (see *Downloading the Installation Packages* on page 12 for details).
- 2. Double-click the setup program for your operating system version:

Options	Description		
Windows 64-bit	setup_asm_x64.exe		

Windows 32-bit setup asm x86.exe

The Installation wizard opens.

- 3. Click Next to begin the installation, click I accept..., then click Next.
- 4. Add the following configuration settings:
 - a) CIM Server Port: 5988.
 - b) Web Server Port: 8443.
 - c) User Name default: Administrator
 - d) Operating system password.
- 5. Click OK on the password verification window and on the CIM Server and Web Server port number verification window.
- 6. In the Features window, select GUI and Agent and CLI Tools. Optionally, select maxCachePlus, then click Next.

Note: maxCache Plus is supported on qualifying Adaptec Series Q controllers only. See the Readme for a complete list.

7. Follow the on-screen instructions to complete the installation.

Installing on Red Hat, Cent OS, SuSE, or Fedora Linux

To install ARCCONF on Red Hat, Cent OS, SuSE, or Fedora Linux:

- 1. In a shell window, change to the directory where the Linux installer package is located (see *Downloading the Installation Packages* on page 12 for details).
- 2. To install maxView Storage Manager with maxCache Plus support, run the maxCache Plus installation script, install.sh; otherwise skip to Step 3 on page 13.

chmod +x install.sh

./install.sh

If the installer detects a qualifying Adaptec Series Q controller and one of the supported Linux operating systems, it installs the maxCache Plus driver software, then it continues with the maxView Storage Manager installation. (See the Readme for a complete list of controllers and operating systems that support maxCache Plus.)

3. To install maxView Storage Manager without maxCache Plus support, run the .bin file for your operating system version:

Options	Description
Linux 64-bit	./StorMan-1.02.x86_64.bin
Linux 32-bit	./StorMan-1.02.i386.bin

 When prompted for configuration details, enter the following: Enter your username [default: root] Enter your operating system password Enter the CIM Server HTTP Port: [default:5988]



When the installation completes a confirmation message is displayed.

Installing on Debian or Ubuntu Linux

To install ARCCONF on Debian or Ubuntu Linux:

- 1. In a shell window, change to the directory where the Debian or Ubuntu installer package is located (see *Downloading the Installation Packages* on page 12 for details).
- 2. Install the .deb package for your operating system version (where xxxxx=build number):

Options	Description
Linux 64-bit	dpkg -i StorMan-1.02-XXXXX_amd64.deb
Linux 32-bit	dpkg -i StorMan-1.02-XXXXX i386.deb

3. Enter the following configuration details: Enter your username [default: root].

Enter your operating system password.

Enter the CIM Server HTTP Port: [default:5988].

When the installation completes a confirmation message is displayed.

Installing on Solaris

To install ARCCONF on Solaris:

- 1. On the Solaris machine, change to the directory where the Solaris installer package is located (see *Downloading the Installation Packages* on page 12 for details).
- Install maxView Storage Manager: pkgadd -d StorMan.pkg
- **3.** At the prompt to continue, select y, then press Enter.
- Enter the following configuration details: Enter your username [default: root]. Enter your operating system password. Enter the CIM Server HTTP Port: [default:5988].
 When the installation completes a confirmation message is displayed.

Installing on FreeBSD

To install ARCCONF on FreeBSD:

- 1. Copy the arcconf executable from the original download location to your FreeBSD system (see *Downloading the Installation Packages* on page 12 for details).
- 2. Verify that the file has 'execute' privilege.

Installing on VMware ESX 4.1

Use the following procedure to install the .vib files for VMware ESX 4.1. Perform the installation on an ESX 4.1 console or from a remote system running a Telnet/SSH client.

- 1. Copy the following files from the installer download location to your local ESX 4.1 /tmp directory (see *Downloading the Installation Packages* on page 12 for details):
 - vmware-esx-provider-arcconf.vib
 - vmware-esx-provider-arcsmis.vib

The arcconf.vib is for command line communication.

The arcsmis.vib is for remote management communication.

2. Stop operations.



/etc/init.d/./sfcbd-watchdog stop

- **3.** Check for an existing installation of arcconf. esxupdate --vib-view query | grep arcconf
- Remove the existing installation of arcconf.
 esxupdate -b < arcconf module name > --maintenancemode remove
 When the package is removed, you receive the message "The update completed successfully, but the system needs to be rebooted for the changes to be effective".
- **5.** Check for an existing installation of arcsmis. esxupdate --vib-view query | grep arcsmis
- 6. Remove the existing installation of arcsmis. esxupdate -b < arcsmis module name > --maintenancemode remove When the package is removed, you receive the message "The update completed successfully, but the system needs to be rebooted for the changes to be effective."
- 7. Reboot the system.
- Stop operations. /etc/init.d/./sfcbd-watchdog stop
- 9. Install the arcconf package.

esxupdate -b /tmp/vmware-esx-provider-arcconf.vib --nodeps --nosigcheck --maintenancemode update When the package is installed, you receive the message "The update completed successfully, but the system needs to be rebooted for the changes to be effective."

10. Install the arcsmis package.

esxupdate -b /tmp/vmware-esx-provider-arcsmis.vib --nodeps --nosigcheck --maintenancemode update When the package is installed, you receive the message "The update completed successfully, but the system needs to be rebooted for the changes to be effective."

- **11.** Reboot the system.
- 12. Continue the installation with Installing on a VMware Guest OS on page 16.

Installing on VMware ESXi 5.x

Use the following procedure to install the .vib files for VMware ESXi 5.x. Perform the installation from a remote system running a Telnet/SSH client. Use a terminal emulator to access the ESXi server remotely.

- 1. Copy the following files from the installer download location to your local ESXi 5.x /tmp directory (see *Downloading the Installation Packages* on page 12 for details):
 - vmware-esx-provider-arcconf.vib
 - vmware-esx-provider-arcsmis.vib

The arcconf.vib is for command line communication.

The arcsmis.vib is for remote management communication.

2. Stop operations.

/etc/init.d/./sfcbd-watchdog stop

- **3.** Check for existing installation of arcconf. esxcli software vib list | grep arcconf
- Remove the existing arcconf package.
 esxcli software vib remove -n arcconf
 When the package is removed, you receive the message "Reboot Required: false."
- 5. Check for an existing installation of arcsmis. esxcli software vib list | grep arcsmis
- Remove the existing arcsmis package. esxcli software vib remove -n arcsmis When the package is removed, you receive the message "Reboot Required: false."



- **7.** Set the acceptance level if this is the first installation of arcconf and arcsmis: esxcli software acceptance set –-level=CommunitySupported
- 8. Install the arcconf package. esxcli software vib install --maintenance-mode --no-sig-check -v /tmp/vmware-esx-provider-arcconf.vib When the package is installed, you receive the message "Reboot Required: false."
- **9.** Install the arcsmis package. esxcli software vib install --maintenance-mode --no-sig-check -v /tmp/vmware-esx-provider-arcsmis.vib When the package is installed, you receive the message "Reboot Required: false."
- 10. Reboot the system.
- 11. Continue the installation with *Installing on a VMware Guest OS* on page 16.

Installing on a VMware Guest OS

Note: Complete the steps in *Installing on VMware ESX 4.1* on page 14 or *Installing on VMware ESXi 5.x* on page 15 before continuing.

To install ARCCONF on a VMware guest operating system:

- 1. On the VMware guest OS, change to the directory where the Guest OS installer package is located (see *Downloading the Installation Packages* on page 12 for details).
- 2. Type one of the following commands, depending on the operating system:

Options	Description	
Linux 32-bit	./StorMan-1.02.esx32.bin	
Linux 64-bit	./StorMan-1.02.esx86_64.bin	
Windows 32-bit	setup_asm_esx_x86.exe	
Windows 64-bit	setup_asm_esx_x64.exe	

Starting the Command Line Utility

1. To start ARCCONF, enter one of the following commands:

Options	Description
Windows	<install_dir>\arcconf.exe</install_dir>
Linux	/usr/ <install_dir>/arcconf</install_dir>
Solaris	/usr/StorMan/arcconf
FreeBSD	/ <install_dir>/arcconf</install_dir>
VMware	/usr/StorMan/arcconf

where Install_dir is the directory where the utility is installed.

2. To see a list of available commands, type ARCCONF at the prompt.



2 Using the Command Line Utility

This chapter explains how to use the command line utility interactively or in batch mode. With interactive mode, enter commands at the prompt. In batch mode, create scripts and run the script in the appropriate shell, as described in the table below.

Table 1: ARCCONF Batch Environments

Environment	Batch File	Run Script
Windows	.bat	CMD.EXE
Linux/Unix	.sh	sh / bash

In either mode, if your command fails, you immediately see an error message of Command failed. Other script messages that you can get are Command completed successfully, or Command aborted.

The return values for each command are the same:

0x00: SUCCESS

0x01: FAILURE - The requested command failed

0x02: ABORT - The command was aborted because parameters failed validation

0x03: INVALID_ARGUMENTS - The arguments are incorrect. (Displays COMMAND help)

To view a list of commands at the command line, type ARCCONF and press Enter.

To access the online help for a specific command, type ARCCONF <command>, then press Enter.

ARCCONF Commands

The following commands are available in ARCCONF. The commands are described on the following pages, in alphabetical order.

Table 2: ARCCONF Commands

atapassword	getsmartstats	romupdate	setperform
consistencycheck	getstatus	saveconfig	setpower
copyback	getversion	savesupportarchive	setpriority
create	identify	setalarm	setstate
delete	imageupdate	setcache	setstatsdatacollection
driverupdate	key	setconfig	setvmcredential
ovraadoelist	modify	categotrallarmada	task
expanderlist failover getconfig getlogs getperform	modify phyerrorlog playconfig rescan resetstatisticscounters	setcontrollermode setcustommode setmaxcache setname setncq	task uninit

Note: In the command syntax descriptions, <> indicates a required parameter and [] indicates an optional parameter.

arcconf atapassword

Description

Sets or clears the Secure Erase password for SATA drives. See *arcconf task* for more information about Secure Erase.



Syntax

ARCCONF ATAPASSWORD <Controller#> SET <new password> <Channel# ID#> ... ARCCONF ATAPASSWORD <Controller#> CLEAR <current password> <Channel# ID#> ...

Parameters

new password | current password

Channel/ID lists the space-delimited channel number and device number (ID) pairs for each drive on which to set or clear the password.

Channel/ID

Lists the space-delimited channel number and device number (ID) pairs for each drive on which to set or clear the password.

Examples

ARCCONF ATAPASSWORD 1 SET uR8ryx 0 1 ARCCONF ATAPASSWORD 1 CLEAR uR8ryx 0 1

arcconf consistencycheck

Description

Toggles the background consistency check modes of the controller.

Syntax

ARCCONF CONSISTENCYCHECK <Controller#> <on | off | period <DAYS>> [noprompt]

Parameters

Controller#

Controller number.

On

Turns background consistency check on.

Period <DAYS>

Sets the number of days to complete the background consistency check. The minimum value is 10 days (quick), the maximum is 365 days (slow). Setting the period automatically turns background consistency check on.

Noprompt

Optional parameter that suppresses the confirmation prompt.

Examples

ARCCONF CONSISTENCYCHECK 1 PERIOD 30 ARCCONF CONSISTENCYCHECK 1 OFF

arcconf copyback

Description

Enables or disables the copyback feature, which attempts to keep drives in the original slot order after rebuilds.

Syntax

ARCCONF COPYBACK <Controller#> <ON | OFF>

Parameters

Controller#

The controller number On enables the copyback feature Off disables the copyback feature

Examples

ARCCONF COPYBACK 1 ON

arcconf create

Description

Creates a new logical drive, maxCache Container, or JBOD and, optionally, enables logical drive read caching, write caching, and maxCache SSD caching. You must provide the channel and device ID of the physical devices.

On redundant logical drives, ARCCONF performs autosynchronization.

ARCCONF presents JBODs as physical devices, not logical drives.

Syntax

ARCCONF CREATE <Controller#> <LOGICALDRIVE | MAXCACHE> [Options] <Size> <RAID#> <CHANNEL# DRIVE#> [CHANNEL# DRIVE#] ... [noprompt] [nologs] ARCCONF CREATE <Controller#> LOGICALDRIVE RVOLUME <LD#> <LD#> [LD#] ... [noprompt] [nologs]

ARCCONF CREATE <Controller#> JBOD <CHANNEL# DRIVE#> [CHANNEL# DRIVE#] ... [noprompt] [nologs]

Parameters

Controller# The controller number.



Logical Drive

Logical Drive indicates the logical drive stripe size with the following options:

- Stripesize <STRIPE>—Allows the logical drive stripe size to be built. Optional parameters for specifying
 a stripe size. STRIPE is specified in kilobytes 16, 32, 64, 128, 256, 512 and 1024 are supported. The
 default is 256KB.
- Legs <LEG>—Optional parameters for specifying number of legs. Value is an integer.
- LEG—Number of legs for RAID level 50 or 60.
 - RAID 50-2-16 legs, 3-32 drives/leg, 128 drives max.
 - RAID 60-2-16 legs, 4-16 drives/leg, 128 drives max.
- Name <NAME>—Optional parameter for specifying the alias name of a logical device that is displayed in the utilities. Value is a string of up to 16 characters.
- Priority <PRIORITY>—Initialization Priority for logical drive to be created. Valid options are: HIGH, MED, or LOW.
- Method <METHOD>—Initialization method for the logical drive. Valid options include: BUILD, CLEAR, QUICK, SKIP. Use SKIP for recovery only (to skip the initialization step).
- Rcache—Sets the logical drive read cache mode:
 - RON read cache on
 - ROFF read cache off
- Wcache—Sets the logical drive write cache mode:
 - WT write-through disabled
 - WB write-back enabled
 - WBB write-back enabled (when protected by battery or flash backup module)
- MaxCacheReadCache—Sets the logical drive SSD read cache mode:
 - ION maxCache on
 - IOFF maxCache off
- MaxCacheWriteCache—Sets the logical drive SSD write cache mode:
 - ION maxCache on
 - IOFF maxCache off
- MaxCacheWritePolicy—Sets the maxCache write cache policy:
 - WB write back enabled. maxCache will store the data on the SSD and write it back to the hard disks when there is little or no impact on performance. This is the default policy.
 - INSTWB instant write back enabled. In addition to the default policy, maxCache will create "dirty pages" on-the-fly for full-stripe writes if there is room on the SSD and the number of dirty pages is below the threshold.
 - WT write through enabled. Similar to instant write back, but full-stripe writes go to both the cache and hard disk and no dirty pages are created on-the-fly.

This argument is valid only if MaxCacheWriteCache is ION.

Note: For more information about write cache policy, see *arcconf setmaxcache* on page 36.

Size

Indicates the size of the logical drive in megabytes. Use MAX to set size to available space.

RAID#

Indicates the RAID level for the new logical drive: 0, 1, 1E, 10, 5, 5EE, 50, 6, 60, and volume are supported. For maxCache, 0, 1, 1E, 5 and Simple_Volume are supported.

Channel# Drive#

Lists the space-delimited channel number and device number pairs for each device to add to the logical drive or maxCache Container. For maxCache, the devices must be SSDs.

Rvolume

RAID level for a RAID volume logical drive.



LD#

Logical drive numbers for two or more logical drives to be concatenated into the RAID volume.

Noprompt

No prompt for confirmation

Examples

ARCCONF CREATE 1 LOGICALDRIVE STRIPESIZE 64 MAX 0 1 0 2 0 3 2 NOPROMPT ARCCONF CREATE 1 JBOD 0 1 NOPROMPT

arcconf delete

Description

Deletes a logical drive, JBOD, or maxCache logical device. All data stored on the logical drive or JBOD will be lost. Spanned drives cannot be deleted with this function.

Syntax

```
ARCCONF DELETE <Controller#> LOGICALDRIVE <LogicalDrive#> <LD#> <LD#> [noprompt]
ARCCONF DELETE <Controller#> JBOD <CHANNEL# DRIVE#> [CHANNEL# DRIVE#] ... [noprompt]
ARCCONF DELETE <Controller#> LOGICALDRIVE |JBOD ALL [noprompt]
ARCCONF DELETE <Controller#> MAXCACHE
```

Parameters

Controller# Controller# is the controller number

LogicalDrive#

LogicalDrive# is the number of the logical drive to be deleted.

LogicalDrive | JBOD ALL Deletes all logical drives or JBODs.

MAXCACHE Deletes the maxCache Container.

Noprompt Optional parameter that suppresses alert messages.

Examples

ARCCONF DELETE 1 LOGICALDRIVE 1 2 3 ARCCONF DELETE 1 JBOD ALL

arcconf driverupdate

Description

Updates Windows device drivers. When given a directory name, it will attempt to update a driver to the version found in the given directory.

Note: This command is available only on Windows systems.



Syntax

ARCCONF DRIVERUPDATE < DirName>

Parameters

Driverupdate <DirName>

Directory path containing the driver that you want to update.

Examples

ARCCONF DRIVERUPDATE C:\WINDOWSALL

arcconf expanderlist

Description

Returns a list of disk drive expanders on a controller.

Syntax

ARCCONF EXPANDERLIST <Controller#>

Parameters

Controller# Controller number.

Examples

ARCCONF EXPANDERLIST 1



arcconf failover

Description

Turns automatic failover on and off.

Syntax

ARCCONF FAILOVER <Controller#> <on | off>

Parameters

Controller#

The controller number.

On

Turns the controller failover mode on.

Off

Turns the controller failover mode off.

Examples

ARCCONF FAILOVER 1 ON

arcconf getconfig

Description

Lists information about controllers, logical drives, physical drives, and flash backup systems. This information includes (but is not limited to) the following:

- Controller type, status, and mode
- BIOS, boot block, device driver, and firmware versions
- Logical drive status, RAID level and size
- maxCache status, fetch and flush rate policy, read/write balance, SSD information
- Device type, device ID, presence of PFA
- Physical device state
- Enclosure information: fan, power supply, and temperature status
- Flash backup information (for AFM-700 flash backup module): status, charge level, temperature readings, max voltage, current, estimated life, errors, and serial number

Syntax

ARCCONF GETCONFIG <Controller#> [AD|LD [LD#]|PD|MC|AL]

Parameters

Controller#

Controller number



AD/LD/PD/AL

- AD—Adapter information only
- LD—Logical drive information only
- PD—Physical device information only
- MC—maxCache information only
- AL—All information (optional)

Examples

ARCCONF GETCONFIG 1 AD

arcconf getlogs

Description

Provides access to controller status and event logs and usage statistics, including:

- DEVICE—A log of device errors that the controller encountered.
- DEAD—A log that records any occurrences of defunct devices.
- EVENT—A log of special events that may have occurred (rebuilds, LDMs, etc.).
- STATS—A log of controller usage statistics.

Syntax

ARCCONF GETLOGS <Controller#> <Type> [clear | tabular]

Parameters

Controller#

Controller number. Clear clears the specified log.

Туре

One of the following:

- DEVICE
- DEAD
- EVENT
- STATS

Clear

Clears the specified log.

Note: This option is valid only for the DEVICE, DEAD, and EVENT log types.

Tabular

Displays the log or statistics in tabular format.

Examples

ARCCONF GETLOGS 1 DEVICE ARCCONF GETLOGS 1 STATS Tabular

arcconf getperform

Description

Fetches the parameters that define a logical drive performance mode. Default is the current mode.

Syntax

ARCCONF GETPERFORM <Controller#> [Performance Mode] [Save [Filename]] [Nologs]

Parameters

Controller# Controller number.

Performance Mode One of the following:

- 1 Default/Dynamic mode
- 2 OLTP/Database
- 3 Big Block Bypass mode
- 4 User defined mode

Save

Saves the performance mode parameters in a file.

Filename

Name of the file in which to save the parameters. If not specified, the default filename is PerformanceMode.cfg.

Nologs

Suppresses creation of logs for this command.

Examples

ARCCONF GETPERFORM 1 2

arcconf getsmartstats

Description

Displays SMART statistics for the hard drives and Solid State Drives (SSDs) on a controller. **Note:** For more information about SMART statistics, see the maxView Storage Manager User's Guide.

Syntax

ARCCONF GETSMARTSTATS <Controller#> [Tabular]

Parameters

Controller#

Controller number.

Tabular

Creates output in tabular format.



ARCCONF GETSMARTSTATS 1 ARCCONF GETSMARTSTATS 1 TABULAR

arcconf getstatus

Description

The GETSTATUS function displays the status of any background command that is currently running, including information about the most recent rebuild, synchronization, logical-drive migration, and compaction/expansion. The information includes the type of operation, status, logical drive number, logical drive size, and percentage of the operation completed.

Note:

- 1. GETSTATUS reports currently active operations for both ARCCONF commands and commands issued from maxView Storage Manager.
- 2. GETSTATUS reports verify, clear, initialize, and secure erase operations on physical devices.
- 3. GETSTATUS reports the status of controller rescan operations.
- **4.** GETSTATUS only reports active operations. It does not display information if the operation is completed.

Syntax

ARCCONF GETSTATUS <Controller#>

Parameters

Controller#

Controller# is the controller number

Examples

ARCCONF GETSTATUS 1

arcconf getversion

Description

Lists version information for all controllers or a specific controller's software components, including information about the BIOS, driver, firmware currently running, and firmware that will run after a reboot. **Note:** The firmware version that will run after a reboot is called the "staged" firmware.

Syntax

ARCCONF GETVERSION (use this for information on all controllers) ARCCONF GETVERSION <Controller#> (use this for information on a specific controller)

Parameters

Controller# Controller number



ARCCONF GETVERSION

arcconf identify

Description

Identifies a physical or logical device by blinking its LEDs.

Syntax

ARCCONF IDENTIFY <Controller#> LOGICALDRIVE <LogicalDrive#> ARCCONF IDENTIFY <Controller#> DEVICE <Channel#> <ID>

Parameters

Controller# Controller number

Channel/ID Number of the logical drive to be identified

Channel# Channel number for the device to be identified

Device# Device number for the device to be identified

Examples

ARCCONF IDENTIFY 1 DEVICE 0 0 ARCCONF IDENTIFY 1 ALL

arcconf imageupdate

Description

Allows new firmware to be flashed to the hard drive.

Syntax: Physical Device Usage

ARCCONF IMAGEUPDATE <Controller#> DEVICE <Channel# ID# ChunkSize# Filename> [Mode#] [noprompt]

Parameters

Controller# Controller number.

Channel#

Channel number of the device to be updated.

ID#

Device number of the device to be updated.



ChunkSize#

Chunk size, in bytes, to be used to update the firmware.

Note: For SATA drives, the chunk size must be a multiple of 512.

Filename

Name of the firmware update file.

Mode#

Firmware update mode.

Valid values for physical devices are:

- 3-(SATA) Download with offsets and save image for immediate and future use
- 7-(SAS) Download microcode with offsets, save, and activate

Noprompt

Optional parameter that suppresses alert messages.

Examples

ARCCONF IMAGEUPDATE 1 DEVICE 0 83 16384 ados.lod 3

arcconf key

Description

Loads a feature key onto an Adaptec controller.

Syntax

ARCCONF KEY <Controller#> SET <Key#>

Parameters

Controller#

The controller number.

Key#

The key number provided by PMC.

Examples

ARCCONF KEY 1 SET ABCD EFGH IJKL MNOP QRST UVWX

arcconf modify

Description

Morphs a logical device from one raid level to another (RAID Level Migration). Expands a logical device from original to one with larger capacity (Online Capacity Expansion). Can be used to make mirrored sets.

Syntax

MODIFY <Controller#> FROM <LogicalDrive#> TO [Options] <Size> <RAID#> <CHANNEL# DRIVE#> [CHANNEL# DRIVE#] [noprompt]



Parameters

Controller#

The controller number

From

Indicates that the logical drive to be modified will follow

LogicalDrive#

The logical drive number

то

Indicates that the modifications will follow

Options:

- Stripesize—indicates the stripe size in KB. Options are 16, 32, 64, 128, 256, 512, and 1024. the default is 256KB.
- init_priority—is the priority level of the modification. Options are low, med, and high.
- Legs— is the number of subarrays for a RAID level-50 or RAID level 60 array. Possible values are 2-16 legs and 3-16 drives/leg (to 48 drives maximum).

Size is one of the following values:

- MAX indicates that you want to use all available space on the disk.
- Desired size in MB.

RAID# is the RAID level for the logical drive 0, 1, 5, 5EE, or 10.

Note: The CHANNEL# and DRIVE# parameters is the list of devices that will contain the target modification object. Channel and Drive are repeatable parameters.

Channel# is the channel number for the device.

Drive# is the device ID (device number) for the device.

Noprompt is an optional parameter that overrides the user prompt.

Example

ARCCONF MODIFY 1 FROM 2 TO 2048 0 0 123 0 124 0 117

arcconf phyerrorlog

Description

Displays PHY error logs for physical devices on a controller or expander PHYs.

Syntax

```
ARCCONF PHYERRORLOG <Controller#> DEVICE <Channel# ID#>
ARCCONF PHYERRORLOG <Controller#> DEVICE ALL
ARCCONF PHYERRORLOG <Controller#> EXPANDER <ExpanderID#> <PHY#>
ARCCONF PHYERRORLOG <Controller#> EXPANDER <ExpanderID#> ALL
```

Parameters

Controller#

Controller number.

Channel/ID

Channel and number of the physical device on the controller.

ExpanderID#

Expander identifier.



PHY#

PHY identifier.

ALL

Displays PHY error log for all physical devices or expander PHYs.

Examples

ARCCONF PHYERRORLOG 1 DEVICE 0 0 ARCCONF PHYERRORLOG 1 EXPANDER 1 ALL

arcconf playconfig

Description

Note: This command is supported on Windows systems only.

Configures a controller using a XML server template file produced by the SAVECONFIG command (see *arcconf saveconfig* on page 32). Use this command to deploy the same controller configuration on multiple servers in your storage space.

Note:

- 1. The XML server template file (default, saveconfig.xml) is editable. For example, you may need to change the disk drive capacity, logical drive size, or RAID level.
- 2. Drives from the same vendor with slightly different capacities (147GB vs 150GB, for instance) are considered interchangeable. If the interchange results in a change in logical drive capacity, the drive is scaled, as needed. For example, if the new drives have 4% more capacity due to vendor or model changes, then all logical drives are increased in size by 4%.
- **3.** Be sure to check the log file to verify that the controller was configured successfully. The exit codes, shown below, indicate the success or failure of the operation and if the system needs to be rebooted.

Code	Value	Meaning
SUCCESS	0	Configuration succeeded, no reboot is required.
FAILURE_GENERAL	1	An error occurred and the configuration could not be completed.
SUCCESS_REBOOT	2	Configuration succeeded, but a reboot is required.

Syntax

ARCCONF PLAYCONFIG <Input XML File> [LogFile] [FORCE ALL|LOGICALSIZE]

Parameters

Input XML File

The pathname of the server template file. The default server template file is available at C:\PMCS\Logs\saveconfig.xml.

LogFile

Sets the pathname of the error log file. By default, the error log is available at C:\PMCS\Logs\playconfig.log.



FORCE

Forces deployment of the server even if the controller does not support all features, or the drive capacity does not match the configuration in the input XML file. Use FORCE ALL to force deployment of all features; use FORCE LOGICALSIZE to force deployment of just the logical drives.

Examples

ARCCONF PLAYCONFIG server1_config.xml playconfig.log FORCE ALL

arcconf rescan

Description

Enables the controller to check for the removal of any disk drives in the ready state and to check for the connection of any new disk drives to the controller. Controller rescan runs in the background, asynchronously. When rescan is started, a message is displayed stating that the process is running in the background and may take 10 minutes to complete. Another message is displayed if a rescan is started while one is already in progress. Rescan status can be obtained with ARCCONF getstatus; see *arcconf getstatus* on page 26 for more information.

Syntax

ARCCONF RESCAN <Controller#>

Parameters

Controller# The controller number

Examples

ARCCONF RESCAN 1

arcconf resetstatisticscounters

Description

Resets statistics counters for a controller. Use this command to clear the counters and create fresh statistics.

Syntax

ARCCONF RESETSTATISTICSCOUNTERS <Controller#>

Parameters

Controller# The controller number

Examples

ARCCONF RESETSTATISTICSCOUNTERS 1



arcconf romupdate

Description

Allows new firmware and BIOS to be flashed to the controller. A reboot is required for the new firmware to take effect.

Note:

- 1. This command is supported in Windows and Linux only.
- 2. You can download the UFI update files from the Support area on the Adaptec Web site at www.adaptec.com.

Syntax

ARCCONF ROMUPDATE <Controller#> <BaseName> [Newversion <build#> [Force]] [noprompt]

Parameters

Controller#

The controller number

BaseName

The name of the ROM image basename or the fully qualified name if you have a set of controller ROM images.

Note: All UFI files must be in the same directory prior to invoking ARCCONF.

Newversion <build#>

Specifies the version of the firmware build.

Force

An optional parameter used to force a down-level firmware update.

Noprompt

An optional parameter that suppresses the confirmation prompt.

Examples

ARCCONF ROMUPDATE 1 AC2200 ARCCONF ROMUPDATE 1 AC220001.UFI ARCCONF ROMUPDATE 1 AS483C newversion 12345 force noprompt

arcconf saveconfig

Description

Note: This command is supported on Windows systems only.

Saves the controller configuration to a XML server template file, including the controller type, operational settings, physical drive size, logical drive size, RAID level, and more. Use this file with the PLAYCONFIG command to deploy the same controller configuration to other servers in your storage space; see *arcconf playconfig* on page 30 for more information.

Note: Be sure to check the log file to verify that the configuration XML file was created successfully. The exit codes, shown below, indicate the success or failure of the operation.

Code	Value	Meaning
SUCCESS	0	Configuration XML generated successfully.





Code	Value	Meaning
FAILURE_GENERAL	1	An error occurred and the configuration XML could not be generated.

Syntax

ARCCONF SAVECONFIG [Input XML File] [LogFile]

Parameters

Input XML File

The pathname of the server template file. The default name (if you omit this parameter) is C:\PMCS\Logs\saveconfig.xml.

LogFile

The pathname of the error log file. By default, the error log is available at C:\PMCS\Logs\saveconfig.log.

Examples

ARCCONF SAVECONFIG server1_config.xml C:\LOGS\SERVER1.LOG

arcconf savesupportarchive

Description

Saves configuration and status information to help Adaptec Customer Support diagnose a problem with your system. Saved information includes (but is not limited to) device logs, drive logs, event logs, error logs, controller logs, and SSD SMART statistics. (For more information about SMART statistics, see *arcconf getsmartstats* on page 25.)

The log files are saved in the Support folder in the standard logs directory for your operating system (/var/log for Linux, the maxView Storage Manager install directory on Windows, and so on).

Note: Unlike the Save Support Archive feature in maxView Storage Manager, this command does not create a zip ("archive") file. It simply saves the support files and logs in the Support folder.

Syntax

ARCCONF SAVESUPPORTARCHIVE

Parameters

None.

Examples

ARCCONF SAVESUPPORTARCHIVE

arcconf setalarm

Description

Sets the state of the controller audible alarm, if present.



Syntax

ARCCONF SETALARM <Controller#> <on | off | silence | test>

Parameters

Controller#

The controller number

On

Enables the alarm

Off

Disables the alarm

Silence

Quiets the currently sounding alarm

Test Triggers the alarm

Examples

ARCCONF SETALARM 1 TEST ARCCONF SETALARM 1 SILENCE

arcconf setcache

Description

Changes a logical drive's cache mode.

Syntax

ARCCONF SETCACHE <Controller#> LOGICALDRIVE <LogicalDrive#> <logical mode> [noprompt] [nologs] ARCCONF SETCACHE <Controller#> DEVICE <Channel> <ID> <physical mode> [nologs]

Parameters

Controller# The controller number

LogicalDrive#

The number of the logical drive whose cache will be altered

Logical mode

Logical drive cache mode:

- RON read cache on
- ROFF read cache off
- WT write through disabled
- WB write back enabled
- WBB write back enabled (when protected by battery or flash backup module)

Channel/ID

Lists the space-delimited channel number and device number pairs for each device to add to the logical drive.



Physical device cache modes

- WT write through disabled
- WB write back enabled

Examples

ARCCONF SETCACHE 1 LOGICALDRIVE 1 RON ARCCONF SETCACHE 1 DEVICE 0 0 WB

arcconf setconfig

Description

Resets the controller configuration. Logical drives are deleted, hard disks are reset to the READY state, cache contents are lost, and controller settings are reset to default values.

Syntax

ARCCONF SETCONFIG <Controller#> DEFAULT [noprompt]

Parameters

Controller# The controller number

Default

Restores the controller's default configuration.

Noprompt No prompt for confirmation.

Examples

ARCCONF SETCONFIG 1 DEFAULT

arcconf setcontrollermode

Description

Sets the controller operating mode to one of the following:

- RAID: Expose RAW (default)—All RAID functions of the controller are enabled. Attached drives without Adaptec meta-data are surfaced to the host operating system as RAW Pass Through devices (similar to JBODs on legacy Adaptec controllers).
- Auto Volume Mode—All RAID functions of the controller are enabled. Attached drives without Adaptec meta-data, but with an OS partition, are surfaced to the host operating system as RAW devices, where the RAID layer of the controller firmware is bypassed when the host issues commands to the device. Attached drives without Adaptec meta-data and without OS partitions, are automatically configured as Simple Volumes (single drives with Adaptec meta-data), with these settings:
 - Controller read caching is set to "Enabled" for rotating media.
 - Controller write caching is set to "Enabled (write-back) when protected by battery/ZMM" for rotating media.
 - maxCache SSD read and write caching is enabled and the write caching policy is set to "write back" for rotating media.
 - Caching for non-rotating media is disabled.



By using DRAM caching, Auto Volume Mode can help reduce latency and accelerate performance, especially if combined with a custom performance mode, such as Big Block Bypass (see *arcconf setperform* on page 39 for more information).

 HBA Mode—The intent of this mode is to allow the RAID controller to act and be used as an HBA. All attached drives are surfaced as RAW devices. Changing into HBA mode is allowed only if there are no drives with Adaptec meta-data attached to the controller. Uninitialize the drives before changing to HBA mode (see *arcconf uninit* on page 44). Uninitialized drives are also compatible with any HBA and can be exchanged with drives on the motherboard's SATA interface.

Note: In HBA Mode, a hot-plugged new drive is automatically configured as a Raw device (see *arcconf uninit* on page 44). When a Raw device is pulled from the system, the controller does not delete internal data structures associated with the drive. However, the missing RAW device is not remembered across rescans.

• RAID: Hide RAW—All RAID functions of the controller are enabled, but RAW devices are not exposed to the operating system.

You must reboot the controller after you change the controller mode.

Syntax:

ARCCONF SETCONTROLLERMODE <Controller#> <Controller Mode> [nologs]

Parameters

Controller#

Controller number.

Controller Mode

One of the following values:

- 0 RAID: Expose RAW
- 1 Auto Volume Mode
- 2 HBA Mode
- 3 RAID: Hide RAW

nologs

Suppresses log output for the command.

Examples

ARCCONF SETCONTROLLERMODE 1 2 ARCCONF SETCONTROLLERMODE 1 0

arcconf setmaxcache

Description

Enables/disables maxCache SSD caching for one or more logical drives; updates the maxCache write cache policy and "dirty page" threshold (data not committed to disk); adds Solid State Drives to the maxCache pool and removes SSDs from the pool; sets the maxCache read/write balance and cache fetch/flush rate; clears the maxCache pool.

Note: Before you can enable maxCache SSD caching, you must assign at least one SSD to the maxCache pool.

Syntax: Read Caching

ARCCONF SETMAXCACHE <Controller#> LOGICALDRIVE <LogicalDrive#> READCACHE <ENABLE | DISABLE>



Syntax: Write Caching

ARCCONF SETMAXCACHE <Controller#> LOGICALDRIVE <LogicalDrive#> WRITECACHE <ENABLE | DISABLE> [WRITEPOLICY <policy>]

ARCCONF SETMAXCACHE <Controller#> LOGICALDRIVE ALL WRITECACHE DISABLE [WRITEPOLICY <policy>] ARCCONF SETMAXCACHE <Controller#> LOGICALDRIVE <LogicalDrive#> WRITEPOLICY <policy> ARCCONF SETMAXCACHE <Controller#> DIRTYPAGETHRESHOLD <dirtyPageThreshold#> ARCCONF SETMAXCACHE <Controller#> WBCVALID <ENABLE |DISABLE>

General Usage

ARCCONF SETMAXCACHE <Controller#> <ADDTOPOOL|REMOVEFROMPOOL> <Channel# Device#> ARCCONF SETMAXCACHE <Controller#> RWBALANCE <Read#> <Write#> ARCCONF SETMAXCACHE <Controller#> FLUSHANDFETCHRATE <FlushAndFetchRate#> ARCCONF SETMAXCACHE <Controller#> CLEAR

Parameters

Controller#

The controller number.

LogicalDrive#

The number of the logical drive. You can specify one or more logical drives.

Channel#

The channel number for the SSD.

Device#

The device number for the SSD.

Read#/Write#

The read/write ratio for invalidating data on the SSD. When the ratio is reached, the page is removed from the cache. Values range from 1-10 for each parameter.

FlushAndFetchRate#

The read cache fetch rate from 1 to 1000: 1-50=Low, 51-100=Medium, 101-1000=High. The default is 100.

Note: The lower the rate the longer the page is kept on the SSD before it is flushed from the cache.

dirtyPageThreshold#

Controls the amount cache space allocated to "dirty" data; that is, data that has not been committed to disk. The threshold value ranges from 1-100 (percent). Once the percentage of dirty pages crosses the threshold, the data are flushed to disk.

WBCVALID ENABLE DISABLE

Enables and disables write caching in non-redundant maxCache. Applies to all logical drives.

Policy

maxCache write cache policy:

- WB write back enabled. maxCache will store the data on the SSD and write it back to the hard disks when there is little or no impact on performance. This is the default policy.
- INSTWB instant write back enabled. In addition to the default policy, maxCache will create dirty pages on-the-fly for full-stripe writes if there is room on the SSD and the number of dirty pages is below the threshold.
- WT write through enabled. Similar to instant write back, but full-stripe writes go to both the cache
 and hard disk and no dirty pages are created on-the-fly.

Clear

Clears the maxCache pool.



```
ARCCONF SETMAXCACHE 1 LOGICALDRIVE 1 READCACHE ENABLE
ARCCONF SETMAXCACHE 1 LOGICALDRIVE 1 WRITECACHE ENABLE WRITEPOLICY WT
ARCCONF SETMAXCACHE 1 DIRTYPAGETHRESHOLD 50
ARCCONF SETMAXCACHE 1 ADDTOPOOL 0 1
ARCCONF SETMAXCACHE 1 REMOVEFROMPOOL 0 1 0 2
ARCCONF SETMAXCACHE 1 RWBALANCE 4 1
ARCCONF SETMAXCACHE 1 FLUSHANDFETCHRATE 200
ARCCONF SETMAXCACHE 1 CLEAR
```

arcconf setname

Description

Renames a logical drive.

Syntax

ARCCONF SETNAME <Controller#> LOGICALDRIVE <LogicalDrive#> <New Name>

Parameters

Controller# Controller number

LogicalDrive# The number of the logical drive to be renamed

New Name The new name of the logical drive

Examples

ARCCONF SETNAME 1 LOGICALDRIVE 1 BACKUP_A

arcconf setncq

Description

Changes the controller's Native Command Queuing (NCQ) setting to enabled or disabled. This setting affects the SATA disk drives on the controller. It takes effect when the SATA drives are restarted.

Syntax

ARCCONF SETNCQ <Controller#> ENABLE | DISABLE

Parameters

Controller# The controller number

Examples

ARCCONF SETNCQ 1 ENABLE



arcconf setperform

Description

Changes controller settings based on the application type.

Syntax

ARCCONF SETPERFORM <Controller#> <Performance Mode> [nologs]

Parameters	
Controller# The controller number	
Performance Mode	
Setting	Behavior
1 (DYNAMIC/Default)	Performance criteria adjusts automatically based on controller usage, RAID level, and disk drive type.
2 (OLTP/Database)	Performance criteria is optimized for transaction- oriented applications such as data entry and retrieval.
3 (Big Block Bypass)	DRAM write cache is bypassed based on IO write size; performance is optimized for serving Web pages and retrieving data.
4 (User-Defined)	User-defined performance mode. Contact Adapted support for more information.

Examples

ARCCONF SETPERFORM 1 2 ARCCONF SETPERFORM 1 3

arcconf setpower

Description

Changes power management settings for disk drives on a controller or logical drive.

Syntax

ARCCONF SETPOWER <Controller#> Stayawake DISABLE | <startime> <endtime>

ARCCONF SETPOWER <Controller#> Spinup <internal#> <external#>

Parameters

Controller#

The controller number

Stayawake

Sets the stayawake period for the disk drives on the controller. During the stayawake period, the disk drives always operate at their peak spin rate.

Disable

Is a keyword that disables the stayawake period for the disk drives on a controller.



starttime

Specifies the beginning of the stayawake period, in the form HHMM (24-hour format)

endtime

Specifies the end of the stayawake period, in the form HHMM (24-hour format).

Spinup

Sets the spin-up limits for the controller—the maximum number of drives that the controller may spin up at one time.

internal#

The maximum number of internal drives that the controller may spin up at one time, from 0-20.

external#

The maximum number of external drives (such as the drives in a JBOD) that the controller may spin up at one time, from 0-20.

LogicalDrive#

The logical drive number.

Slowdown st#

Sets the disk drive slow-down timer, in minutes. Valid values are 0 (never), 3, 5, 10, 20, 30, 60, 120, 180.

Poweroff pt#

Sets the disk drive power-off timer, in minutes. Valid values are 0 (never), 3, 5, 10, 20, 30, 60, 120, 180.

Verify vt#

Sets the period of inactivity, in hours, after which an inactive drive (a drive that's already powered down) is restarted to verify its operating condition. Once the check is completed, the drive is powered down and returns to its inactive state. Valid values are 0 (never), 1, 2, 3, 8, 12, 24.

Note: For the Slowdown, Poweroff, and Verify timers, st# must be less than pt#, and pt# must be less than vt#. You can set one or more timers, in any order, in a single command. Keep in mind that the Verify timer, vt#, is specified in hours; the other two timers are specified in minutes.

Examples

ARCCONF SETPOWER 1 STAYAWAKE DISABLE ARCCONF SETPOWER 1 SPINUP 4 4 ARCCONF SETPOWER 1 LD 2 POWEROFF 60 ARCCONF SETPOWER 1 LD 2 SLOWDOWN 20 POWEROFF 60 VERIFY 12

arcconf setpriority

Description

Changes a task's execution priority or a controller's global background task priority.

Syntax

ARCCONF SETPRIORITY <Controller#> [TASK ID] <New Priority> [current]

Parameters

Controller#

The controller number



Task ID

Task ID is the number of the task to be changed. Use arcconf getstatus to obtain the task ID. Omit this parameter to set the controller's global background task priority; that is, the execution priority for all tasks on the controller.

New Priority

LOW, MEDIUM, or HIGH.

Current (keyword)

Applies a global task priority change to running tasks. By default, a global priority change does not apply to running tasks.

Examples

ARCCONF SETPRIORITY 1 <task_id> HIGH ARCCONF SETPRIORITY 1 LOW CURRENT

arcconf setstate

Description

Changes the state of a physical device or logical device from its current state to the designated state.

Syntax

ARCCONF SETSTATE <Controller#> DEVICE <Channel#> <Device#> <State> [MAXCACHE] [LOGICALDRIVE <LD#>[LD#] ...] [noprompt]

ARCCONF SETSTATE <Controller#> LOGICALDRIVE <LD#> OPTIMAL [ADVANCED <option>] [noprompt]

Parameters

Controller#

The controller number

Channel#

The channel number for the drive.

Device#

Device number for the device.

LD#

Logical drive number.

State

- HSP—Create a hot spare from a ready drive
- RDY—Remove a hot spare designation
- DDD—Force a drive offline (to Failed)

MAXCACHE

Optional keyword for maxCache devices only. Include if State is HSP or RDY, and the hot spare is for a maxCache device.

ADVANCED <option>

Optional keyword/option pair. Set option to Nocheck to force a logical drive to the Optimal state without performing a consistency check.

Noprompt:

No prompt for confirmation.



```
ARCCONF SETSTATE 1 DEVICE 0 0 HSP LOGICALDRIVE 1 2 3
ARCCONF SETSTATE 1 DEVICE 0 0 RDY LOGICALDRIVE 2
ARCCONF SETSTATE 1 LOGICALDRIVE 1 OPTIMAL ADVANCED nocheck
```

arcconf setstatsdatacollection

Description

Enables or disables statistics collection for a controller. To display the statistics, see *arcconf getlogs* on page 24 .

Syntax

ARCCONF SETSTATSDATACOLLECTION <Controller#> Enable | Disable

Parameters

Controller# The controller number

Enable

Turns statistics collection on.

Disable

Turns statistics collection off.

Examples

ARCCONF SETSTATSDATACOLLECTION 1 ENABLE

arcconf setvmcredential

Description

Resets the Hypervisor login credentials for VMware Guest OSs.

Syntax

SETVMCREDENTIAL <Esxip> <Esxcimomport> <Esxuserid> <Esxpassword> [noprompt]

Parameters

Esxip Hypervisor IP address.

Esxcimomport Hypervisor CiMOM port number.

Esxuserid

Hypervisor user name.

Esxpassword

Hypervisor password.



ARCCONF SETVMCREDENTIAL 172.18.46.101 5989 root passwd

arcconf task

Description

Performs a task on a logical drive, physical drive, or maxCache logical device.

Syntax: General Usage

ARCCONF TASK TASK START <Controller#> LOGICALDRIVE <LogicalDrive#> <options> [noprompt] TASK STOP <Controller#> LOGICALDRIVE <LogicalDrive#> TASK START <Controller#> DEVICE <Channel> <ID> <options> [noprompt] TASK STOP <Controller#> DEVICE <Channel> <ID>

Syntax: maxCache Usage

ARCCONF TASK TASK START <Controller#> MAXCACHE COHERENCYCHECK [ONCE|ALWAYS] TASK START <Controller#> MAXCACHE <VERIFY_FIX|VERIFY> TASK STOP <Controller#> MAXCACHE

Parameters

Controller#

The controller number

LogicalDrive#

Number of the logical drive in which the task is to be performed

- Logical drive options:
 - verify_fix (Verify with fix)—verifies the logical drive redundancy and repairs the drive if bad data is found.
 - verify-verifies the logical drive redundancy without repairing bad data.
 - clear—removes all data from the drive.
- Physical device options:
 - verify fix—verifies the disk media and repairs the disk if bad data is found.
 - verify—verifies the disk media without repairing bad data.
 - clear—removes all data from the drive.
 - initialize—returns a drive to the READY state (erases the metadata).
 - secureerase [password]—removes all data from the drive in a secure fashion to prevent any possible recovery of the erased data. See *arcconf atapassword* on page 17 for details about setting the password.

MAXCACHE options:

- coherencycheck—compares valid pages of the maxCache Container with their corresponding logical drive storage. Once is the default.
- verify_fix (Verify with fix)—verifies the maxCache Container redundancy and repairs the logical drive if bad data is found.
- verify—verifies the maxCache Container redundancy without repairing bad data.



ARCCONF TASK START 1 LOGICALDRIVE 1 VERIFY ARCCONF TASK START 1 DEVICE 0 0 INITIALIZE ARCCONF TASK START MAXCACHE COHERENCYCHECK ONCE

arcconf uninit

Description

Uninitializes one or more physical drives. The uninitialize command clears Adaptec meta-data and any OS partitions from a drive; existing data on the drive is destroyed. Drives can uninitialized only if they are in the Raw or Ready state (that is, not part of any logical drive). A drive in the Raw state has no Adaptec meta-data but may or may not have an OS partition.

Note: Uninitialized drives are compatible with any HBA and can be exchanged with drives on the motherboard's SATA interface. For more information about uninitialized devices, see *arcconf setcontrollermode* on page 35.

Syntax:

ARCCONF UNINIT <Controller#> <CHANNEL# DRIVE#> [Channel# Drive#] ... [nologs] ARCCONF UNINIT <Controller#> ALL [nologs]

Parameters

Controller#

Controller number.

Channel#

The channel number of the device to be uninitialized.

Drive#

The drive number of the device to be uninitialized.

ALL

Uninitializes all physical devices in the Raw or Ready state.

nologs

Suppresses log output for the command.

Examples

ARCCONF UNINIT 1 0 12 0 13 ARCCONF 1 ALL



PMC-Sierra, Inc. 1380 Bordeaux Drive Sunnyvale, CA 94089 USA

© Copyright PMC-Sierra, Inc. 2013 All rights reserved. Adaptec and the Adaptec by PMC logo are trademarks of PMC-Sierra, Inc.

Part Number: CDP-00284-02-A Rev A