

=====
Adaptec RAID Release dated: November 11, 2009
=====

These release notes contain the following:

1. Description of the Release
2. Supported Controllers
3. Enhancements and Bugfixes

1. Description of the Release:
=====

This is the official software release containing the list of software components listed below:

- Firmware Version 5.2.0 Build 17544
- Windows Driver (32-bit and 64-bit) Version 5.2.0.17544
- SCO Unixware and OpenServer Driver Version 5.2.0.17544
- FreeBSD Driver Version 5.2.0.17544
- Solaris Driver Version 5.2.0.17544
- Linux Driver Version 1.1.5-24900
- Adaptec Storage Manager (ASM) Version 6.40 Build 18530

2. Supported Controllers:
=====

- Adaptec RAID 5405
- Adaptec RAID 5405z
- Adaptec RAID 5445
- Adaptec RAID 5445z
- Adaptec RAID 5805
- Adaptec RAID 5805z
- Adaptec RAID 5085
- Adaptec RAID 51245
- Adaptec RAID 51645
- Adaptec RAID 52445
- Adaptec RAID 2405
- Adaptec RAID 2045

3. Enhancements and Bug Fixes:
=====

- Added a new option in the "PHY Configuration" menu to change the Phy speed (3.0Gbps/1.5Gbps). Due to onboard expanders, this new option is not available on certain Series 5 controllers (51245, 51645, and 52245).
- Fixed an issue where arrays may become unreadable after performing a firmware upgrade. Please refer to ASK knowledgebase article# 16914 for further detail.
- Fixed an issue where the controller alarm would continue to sound, even after all drive members of the degraded array had been initialized.
- Fixed an issue where a simple volume creation would fail if a secure erase was performed on the drive(s).
- Fixed an issue that would prevent a hotspare from being pulled in and a rebuild from starting if an array became degraded as a result of an array drive member being

initialized.

- Enhancement to drive medium error handling. Drives exhibiting excessive medium errors will be marked offline.
- Enhancement to array morphing and expansion should require less time to complete. This enhancement does not apply to array building or rebuilding.
- Enhancement to the controller BIOS (CTRL-A), now displays the firmware build number at the top of the main menu screen.

=====
(c) 2008 Adaptec, Inc. All Rights Reserved.

This software contains the valuable trade secrets of Adaptec or its licensors. The software is protected under international copyright laws and treaties. This software may only be used in accordance with the terms of its accompanying license agreement.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without prior written consent of Adaptec, Inc.

Adaptec Inc.

691 South Milpitas Blvd.

Milpitas, CA 95035
=====